Artemide Zsu-Zsu 65

Artemide Zsu-Zsu 65 Wall/Ceiling Lamp User Manual

Model: Zsu-Zsu 65

Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Artemide Zsu-Zsu 65 Wall/Ceiling Lamp. Designed by Orin Halloween, the Zsu-Zsu 65 is a versatile lighting fixture suitable for both ceiling and wall mounting, offering diffused incandescent or fluorescent lighting. Please read this manual thoroughly before installation and retain it for future reference.



Figure 1: Front view of the Artemide Zsu-Zsu 65 Wall/Ceiling Lamp, showcasing its circular diffuser and metallic grey lacquered support details.

Setup and Installation

Safety Precautions

- **WARNING:** Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.
- Ensure the mounting surface can support the weight of the fixture.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unsure about wiring.
- Do not install near heat sources or in damp locations.

Package Contents

- Zsu-Zsu 65 Lamp Fixture (metallic grey lacquered finish)

- Diffuser
- Diffuser Support Details
- Mounting Hardware Kit
- Electronic Fluorescent Ballast (for fluorescent models)
- *Note: Bulbs are not included.*

Tools Required (Not Included)

- Phillips head screwdriver
- Flathead screwdriver
- Wire strippers
- Pliers
- Drill (with appropriate drill bits for mounting surface)
- Measuring tape
- Pencil

Installation Steps

1. **Turn Off Power:** Locate the circuit breaker or fuse box controlling the power to the installation location and turn off the power. Verify power is off using a voltage tester.
2. **Prepare Mounting Surface:** Mark the desired mounting location on the wall or ceiling. Use the fixture's mounting bracket as a template to mark drill holes. Drill pilot holes as necessary.
3. **Attach Mounting Bracket:** Secure the mounting bracket to the wall or ceiling using the provided mounting hardware. Ensure it is firmly attached.
4. **Electrical Connections:**
    - Connect the fixture's black wire to the house's black (hot) wire.
    - Connect the fixture's white wire to the house's white (neutral) wire.
    - Connect the fixture's ground wire to the house's ground wire (bare copper or green).
    - Secure all connections with wire nuts and wrap with electrical tape for added safety.
5. **Mount Fixture Body:** Carefully align the lamp fixture body with the mounting bracket and secure it using the provided screws. Ensure the wiring is tucked neatly into the junction box.
6. **Install Bulbs:** Insert the appropriate bulbs into the lamp sockets.
    - For Incandescent models: 3 x 100W E26/A19W INC bulbs.
    - For Fluorescent models: 3 x 26W G24q-3 FLU bulbs.
7. **Attach Diffuser:** Place the diffuser onto the fixture, aligning it with the diffuser support details. Secure the diffuser according to the fixture's design (e.g., twist-lock, clips, or screws).
8. **Restore Power:** Turn the power back on at the circuit breaker or fuse box. Test the lamp to ensure it functions correctly.

Operating Instructions

The Artemide Zsu-Zsu 65 lamp is designed for simple operation. Once properly installed and powered, the lamp is controlled by a standard wall switch connected to its circuit.

- **Turning On/Off:** Flip the wall switch connected to the lamp's circuit to the "ON" position to illuminate the lamp. Flip it to the "OFF" position to turn off the lamp.

- **Bulb Compatibility:** Ensure you use the correct bulb type and wattage as specified in the "Specifications" section to prevent damage to the fixture or improper operation.
- **Dimming:** If your Zsu-Zsu 65 lamp is an incandescent model and is connected to a compatible dimmer switch, you can adjust the light intensity by operating the dimmer. Fluorescent models typically require specific dimmable fluorescent ballasts and compatible dimmers. Consult a qualified electrician for dimmer installation.

Maintenance

Regular maintenance will help preserve the appearance and functionality of your Artemide Zsu-Zsu 65 lamp. Always ensure the power is off before performing any maintenance.

Cleaning

- **Diffuser:** To clean the diffuser, gently wipe it with a soft, damp cloth. For stubborn marks, a mild, non-abrasive cleaner can be used. Avoid harsh chemicals or abrasive materials that could scratch the surface.
- **Metal Finish:** Wipe the metallic grey lacquered finish with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.
- Ensure all parts are completely dry before restoring power.

Bulb Replacement

1. **Turn Off Power:** Disconnect power to the fixture at the circuit breaker or fuse box.
2. **Allow to Cool:** If the lamp has been recently in use, allow the bulbs to cool completely before handling.
3. **Remove Diffuser:** Carefully remove the diffuser to access the bulbs.
4. **Replace Bulbs:** Unscrew the old bulbs and screw in new bulbs of the correct type and wattage (refer to "Specifications").
5. **Reattach Diffuser:** Securely reattach the diffuser.
6. **Restore Power:** Turn the power back on and test the lamp.

Troubleshooting

Before attempting any troubleshooting, ensure the power is disconnected at the circuit breaker.

Problem	Possible Cause	Solution
Lamp does not light up.	• No power to the fixture. • Loose wire connections. • Faulty bulb(s). • Incorrect bulb type/wattage.	• Check circuit breaker/fuse. • Verify all wire connections are secure. • Replace bulb(s). • Ensure correct bulb type and wattage are used.
Lamp flickers.	• Loose bulb. • Incompatible dimmer switch (if applicable). • Faulty wiring.	• Tighten bulb(s). • Ensure dimmer is compatible with bulb type (especially for fluorescent). • Check wiring connections.
Lamp is dim or too bright.	• Incorrect bulb wattage. • Dimmer setting (if applicable).	• Use bulbs with the specified wattage. • Adjust dimmer setting.

If the problem persists after attempting these solutions, please contact a qualified electrician or Artemide customer

support.

Specifications

Feature	Detail
Brand	Artemide
Model	Zsu-Zsu 65
Designer	Orin Halloween (1994-1996)
Dimensions (H x Diameter)	7"h x 26" diameter
Mounting	Wall or Ceiling
Material	Metal (metallic grey lacquered finish)
Voltage	120 Volts
Bulb Type (Incandescent)	3 x 100W E26/A19W INC (Bulbs not included)
Bulb Type (Fluorescent)	3 x 26W G24q-3 FLU (Bulbs not included)
Ballast (Fluorescent)	Standard 120V Electronic Fluorescent Ballast supplied

Warranty and Support

Warranty Information

Artemide products are manufactured to high-quality standards. For specific warranty terms and conditions applicable to your Zsu-Zsu 65 lamp, please refer to the warranty card included with your purchase or visit the official Artemide website. Retain your proof of purchase for warranty claims.

Customer Support

Should you require assistance with installation, operation, or troubleshooting beyond the scope of this manual, please contact Artemide customer support.

- **Artemide Official Website:** www.artemide.com (for product information, FAQs, and contact details)
- **Contact a Qualified Electrician:** For complex electrical issues or if you are unsure about any wiring procedures, it is recommended to consult a licensed electrician.

© 2023 Artemide. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question