

Quoizel NY9043K

Quoizel Newbury Outdoor Post Lantern Installation and User Manual

Model: NY9043K | Brand: Quoizel

1. INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Quoizel Newbury 3-Light Mystic Black Outdoor Post Lantern. Please read all instructions carefully before beginning installation and retain this manual for future reference.

The Quoizel Newbury Outdoor Post Lantern is designed to provide reliable and elegant outdoor illumination. Featuring a durable brass construction and clear beveled glass, this fixture is built to withstand various outdoor environments and conditions.





Image 1.1: Quoizel Newbury 3-Light Mystic Black Outdoor Post Lantern. This image displays the full view of the lantern, highlighting its classic design and clear glass panels.

2. SAFETY INFORMATION

WARNING: RISK OF ELECTRIC SHOCK. Disconnect power at the fuse box or circuit breaker before installation or servicing.

- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- This fixture is intended for outdoor use and is ETL-listed for wet locations.
- Ensure the mounting surface is sound and capable of supporting the fixture's weight.

- Do not exceed the maximum wattage specified for the bulbs.
- Wear safety glasses and gloves during installation.
- Keep flammable materials away from the light fixture when in operation.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Outdoor Post Lantern Fixture (1)
- Mounting Hardware Kit (screws, wire nuts, etc.)
- Installation Instructions (this manual)

Note: Light bulbs and the post/junction box are not included.

4. SETUP AND INSTALLATION

Follow these steps to install your Quoizel Newbury Outdoor Post Lantern:

1. **Prepare for Installation:** Turn off power at the circuit breaker or fuse box to avoid electrical shock.
2. **Unpack Contents:** Carefully remove all parts from the packaging. Place them on a clean, flat surface to ensure no parts are missing.
3. **Mounting Location:** This fixture is designed to mount on an existing standard 3-inch diameter post or junction box (not included). Ensure the post is securely anchored.
4. **Wiring Connections:** Connect the fixture's wires to your supply wires according to local electrical codes. Typically, connect the black wire from the fixture to the black (hot) wire from the supply, the white wire from the fixture to the white (neutral) wire from the supply, and the ground wire from the fixture to the ground wire from the supply. Secure connections with wire nuts.
5. **Secure Fixture to Post:** Carefully align the base of the lantern with the top of your post. Use the provided mounting hardware (e.g., set screws) to firmly secure the fixture to the post.
6. **Install Bulbs:** This fixture requires three (3) 60-watt maximum candelabra base (E12) bulbs (not included). Screw the bulbs into the sockets. Do not overtighten.
7. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker or fuse box.

PRODUCT DIMENSIONS



**BULB
NOT
INCLUDED**

NOTE: ALL DIMENSIONS ARE ROUNDED UP TO THE NEAREST 1/4"



Image 4.1: Product Dimensions and Bulb Information. The diagram shows the lantern's dimensions (12.5" diameter, 23" height) and indicates it uses 110-120V, 60W bulbs with an E12 base. Note: This specific model uses 3 bulbs, not 2 as depicted in the generic image.




Image 4.2: Outdoor Post Lantern Installation Height. This diagram illustrates a recommended minimum installation height of 60-65 inches for outdoor post lanterns to ensure optimal illumination and aesthetic balance.

5. OPERATING INSTRUCTIONS

The Quoizel Newbury Outdoor Post Lantern operates like a standard outdoor light fixture. Once properly

installed and wired to a power source, it can be controlled via a wall switch or an external timer/photocell system (if installed separately).

- **Turning On/Off:** Use the connected wall switch to turn the light fixture on or off.
- **Dimmable Feature:** This fixture is dimmable when paired with dimming-compatible bulbs and a compatible dimmer switch (both sold separately).
- **Bulb Replacement:** To replace bulbs, ensure power is off at the circuit breaker. Carefully unscrew the old bulbs and replace them with new 60-watt maximum candelabra base (E12) bulbs.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your outdoor post lantern.

- **Cleaning:** Clean the fixture periodically with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish or glass.
- **Glass Care:** The clear beveled glass can be cleaned with standard glass cleaner.
- **Finish Patination:** The metal finish is designed to naturally mature and patina over time, changing in appearance. This is a characteristic of the material and not a defect.
- **Weather Resistance:** The durable brass construction is designed to withstand various outdoor environments, including heat, water, snow, frost, and rust.

ALL COPPER CONSTRUCTION BUILT TO LAST IN ALL WEATHER

FEATURES



Heat Resistant



Waterproof



Snow and Frostproof



Rust Resistant



Clear Beveled
Glass Panels

Image 6.1: Weather Resistant Features. This image highlights the lantern's resistance to heat, water, snow, frost, and rust, along with its clear beveled glass panels.

7. TROUBLESHOOTING

If your Quoizel Newbury Outdoor Post Lantern is not functioning correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker or fuse. Ensure wall switch is in the 'ON' position.
	Loose or incorrect wiring.	Turn off power and check all wiring connections. Consult a qualified electrician if unsure.
	Faulty bulb.	Replace bulb(s) with new ones of the correct type and wattage.
Light flickers.	Loose bulb.	Turn off power and tighten bulb(s).

Problem	Possible Cause	Solution
---------	----------------	----------

	Incorrect bulb type or wattage.	Ensure bulbs meet specifications (60W max, E12 base).
	Faulty dimmer switch (if applicable).	Ensure dimmer switch is compatible with LED bulbs if using them. Replace dimmer if necessary.

If you are unable to resolve an issue, contact a qualified electrician or Quoizel customer support.

8. SPECIFICATIONS







Feature	Detail
Brand	Quoizel
Model Number	NY9043K
Fixture Type	Outdoor Post Lantern
Color	Mystic Black
Material	Brass, Glass
Dimensions (L x W x H)	12.5" x 12.5" x 23"
Number of Light Sources	3
Bulb Base	E12 (Candelabra)
Max Wattage per Bulb	60 watts
Voltage	120 Volts
Special Feature	Dimmable (with compatible bulbs/switch)
Indoor/Outdoor Usage	Outdoor
Certification	ETL Listed for wet locations
Item Weight	6.9 Pounds

9. WARRANTY AND SUPPORT

This Quoizel product is covered by a manufacturer's warranty. For specific warranty details, claims, or technical support, please refer to the warranty information provided with your purchase or visit the official Quoizel website.

For additional information or to explore other Quoizel lighting products, visit the [Quoizel Store on Amazon](#).

Related Documents - NY9043K

	<p>Quoizel SPL542LG and SPL542K Installation Guide</p> <p>This installation guide provides step-by-step instructions for assembling and installing the Quoizel SPL542LG and SPL542K lighting fixtures. It includes essential safety warnings, required tools, package contents, mounting hardware details, and maintenance tips. Ensure proper electrical safety and consult a licensed electrician if needed.</p>
	<p>Quoizel LANS8624MBK Installation Guide</p> <p>Step-by-step installation guide for the Quoizel LANS8624MBK vanity light fixture, including safety information, package contents, and mounting instructions.</p>
	<p>Quoizel MCI2815MBK Installation Guide</p> <p>This guide provides step-by-step instructions for installing the Quoizel MCI2815MBK pendant ceiling light, including safety information, package contents, tools required, and maintenance tips.</p>
	<p>Quoizel PNT8306MBK & PNT8406MBK Outdoor Wall Lantern Installation Guide</p> <p>Step-by-step installation guide for Quoizel PNT8306MBK and PNT8406MBK matte black outdoor wall lanterns. Includes safety information, package contents, and mounting hardware details.</p>
	<p>Quoizel ABR5132MBK Installation Guide for Abner Chandelier</p> <p>Step-by-step installation guide for the Quoizel ABR5132MBK Abner 18-light matte black chandelier. Includes safety information, package contents, mounting hardware, and wiring instructions.</p>
	<p>Quoizel KEE8624MBK Installation Guide: Matte Black Vanity Light</p> <p>Comprehensive installation guide for the Quoizel KEE8624MBK Matte Black Vanity Light. Includes safety information, package contents, mounting hardware, and step-by-step installation instructions.</p>

