

Manuals.plus /

› LeapFrog /

› LeapFrog My Own Leaptop (Pink) Instruction Manual

LeapFrog 80-19167E

LeapFrog My Own Leaptop (Pink) Instruction Manual

Model: 80-19167E

INTRODUCTION

The LeapFrog My Own Leaptop is an interactive learning toy designed to introduce children aged 2-4 years to letters, animal names, and basic computer concepts through engaging activities and music. This manual provides essential information for setting up, operating, and maintaining your Leaptop.



Image: The LeapFrog My Own Leaptop in pink, shown both closed and open, displaying its keyboard and screen with colorful animal graphics.

WHAT'S IN THE BOX

- LeapFrog My Own Leaptop, Pink
- Quick Start Guide

SETUP

Battery Installation

1. Locate the battery compartment on the underside of the Leaptop.
2. Using a Phillips-head screwdriver, loosen the screw on the battery compartment cover.
3. Remove the cover.
4. Insert 3 new AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment. (Batteries included for demo purposes only; new batteries recommended for regular use.)
5. Replace the cover and tighten the screw.

Personalization

The Leaptop can be personalized to spell your child's name. Follow the instructions in the Quick Start Guide or connect the device to a computer via a USB cable (not included) and visit the LeapFrog Learning Path website for detailed personalization steps.

OPERATING INSTRUCTIONS

To begin, slide the power switch located on the side of the screen to the 'On' position. Adjust the volume using the dedicated switch.

Learning Modes

- **ABCs Mode:** Press any letter key to hear the letter's name, its phonetic sound, and an animal that starts with that letter.
- **Messages Mode:** Pretend to send and receive emails with Scout or Violet. This mode introduces basic communication concepts.
- **Games Mode:** Engage in fun animal trivia and letter games designed to reinforce learning.
- **Music Mode:** Enjoy 16 songs and melodies. Press the paw print button to select different tunes.

On-the-Go Play

The Leaptop is designed with a perfectly sized handle for easy portability, allowing children to carry it wherever they go.



Image: A young child sitting on the floor, actively engaging with the pink LeapFrog My Own Leaptop, pressing keys on its keyboard.

FEATURES

- **Interactive Keyboard:** Full alphabet keyboard with large, easy-to-press buttons.
- **Large Screen:** Features 26 fun animal animations that correspond with letters and activities.
- **Four Learning Modes:** ABCs, Messages, Games, and Music for varied educational play.
- **Personalization:** Ability to program your child's name for personalized learning experiences.
- **Portable Design:** Integrated handle for easy carrying.
- **Educational Objectives:** Supports alphabet, letter, and word recognition, early development, listening skills, literacy, and spatial awareness.

Official Product Video

Video: An official demonstration of the LeapFrog My Own Leaptop, showcasing its various learning modes, interactive features, and portability. The video highlights how children can learn letters, send pretend emails, play games, and enjoy music.

MAINTENANCE

- **Cleaning:** Wipe the Leaptop with a slightly damp cloth. Do not immerse in water.
- **Battery Care:** Remove batteries if the unit will not be used for an extended period.
- **Storage:** Store in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

- **No Power:** Ensure batteries are correctly installed and are fresh. Replace with new AA batteries if necessary.
- **Sound Issues:** Check the volume switch. If sound is still low or distorted, replace batteries.
- **Unresponsive Buttons:** Try turning the unit off and on again. If the issue persists, replace batteries.

SPECIFICATIONS

Brand	LeapFrog
Model Number	80-19167E
Color	Pink
Material Type	Plastic
Age Range	2-4 Years
Power Source	Battery Powered
Batteries Required	3 AA batteries (included for demo, new recommended)
Item Dimensions (L x W x H)	2.01 x 9.5 x 5.59 inches
Item Weight	1.1 Pounds



Image: The LeapFrog My Own Leaptop in pink, with its length and width dimensions clearly indicated.

WARRANTY AND SUPPORT

For warranty information, product support, or to register your LeapFrog My Own Leaptop, please refer to the Quick Start Guide included in the packaging or visit the official LeapFrog website. Contact information for customer service can also be found on the product packaging.