

- Manuals.plus /
- › [Yale](#) /
 - › Yale YTP2/26/216/1R TSA Combination Travel Lock Instruction Manual

Yale YTP2/26/216/1R

Yale YTP2/26/216/1R TSA Combination Travel Lock

Instruction Manual

INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Yale YTP2/26/216/1R TSA Combination Travel Lock. Please read these instructions carefully before using your lock to ensure correct functionality and security. This lock is designed for securing luggage and portable items, featuring a resettable 3-digit combination and TSA acceptance for travel convenience.

PRODUCT OVERVIEW

The Yale YTP2/26/216/1R is a durable metal body travel lock with a 3-digit resettable combination. It is TSA (Transportation Security Administration) accepted, allowing security personnel to inspect your luggage without damaging the lock. The lock features a red finish and compact dimensions suitable for various travel items.



Image: Front view of the Yale YTP2/26/216/1R TSA Combination Travel Lock, displaying the three combination dials and the red TSA Accepted logo.

SETUP

1. Initial Combination

The lock is factory preset to open at **0-0-0**. To open the lock for the first time, align the three dials to 0-0-0 and pull up the shackle.

2. Setting Your Personal Combination

1. Open the lock by setting the dials to the current combination (initially 0-0-0) and pulling up the shackle.
2. With the shackle in the open position, rotate the shackle 90 degrees (or 180 degrees, depending on the model) counter-clockwise until it clicks into the setting notch.
3. Press the shackle down firmly into the lock body while holding it in the rotated position.
4. While holding the shackle down, set your desired 3-digit combination by turning the dials. Choose a memorable number.
5. Release the shackle. Rotate the shackle back to its original open position. The new combination is now set.
6. Scramble the dials to lock the shackle. Test your new combination to ensure it opens the lock correctly before securing any items.

Important: Remember your combination. Yale cannot open your lock if the combination is forgotten.

OPERATING THE LOCK

Opening the Lock

1. Align the three combination dials to your personal 3-digit code.
2. Pull the shackle upwards to release it from the lock body.

Closing the Lock

1. Ensure the shackle is in the open position.
2. Insert the shackle into the lock body.
3. Scramble the combination dials to a random set of numbers. This secures the lock.



Image: A hand holding the Yale travel lock, demonstrating the shackle in the open position, ready for use or combination setting.

TSA Functionality

This lock is TSA Accepted. This means that Transportation Security Administration agents can open your lock using a universal master key without damaging it, allowing them to inspect your luggage. The lock will be relocked by the agent after inspection. The TSA keyhole is located on the side or bottom of the lock and is for official use only; no key is provided to the user.





Image: Side view of the Yale travel lock, highlighting the TSA master keyhole, which is used by security personnel for inspections.

MAINTENANCE

The Yale YTP2/26/216/1R travel lock requires minimal maintenance.

- **Cleaning:** Wipe the lock body with a soft, dry cloth to remove dust and dirt. Avoid using abrasive cleaners or solvents, as these can damage the finish.
- **Lubrication:** If the dials become stiff over time, a small amount of graphite lubricant (e.g., from a pencil lead) can be applied to the moving parts. Avoid oil-based lubricants as they can attract dust.
- **Storage:** Store the lock in a dry environment when not in use to prevent corrosion.

TROUBLESHOOTING

- **Lock will not open with the correct combination:**
 - Ensure the numbers are perfectly aligned in the center of the windows.
 - Double-check that you are using the correct combination. If you recently changed it, try the old combination as well, in case the change was not fully registered.
 - Apply slight pressure to the shackle while turning the dials to ensure all internal components are properly seated.
- **Dials are stiff or hard to turn:**
 - Clean the dials and surrounding areas to remove any accumulated dirt or debris.
 - Apply a small amount of graphite lubricant as described in the Maintenance section.
- **Shackle does not fully close or lock:**
 - Ensure the combination dials are scrambled after inserting the shackle. The lock will not secure if the correct combination is still displayed.
 - Check for any obstructions preventing the shackle from fully seating.

SPECIFICATIONS

Model Number	YTP2/26/216/1R
Brand	Yale
Material	Metal
Color	Red
Lock Type	3-Digit Combination Lock (TSA Accepted)
Dimensions (L x W x H)	48 x 26 x 14 mm (approximate)
Item Weight	0.06 Kilograms
Additional Features	TSA Accepted

STANDARD PROTECTION



Image: Dimensional diagram of the Yale YTP2/26/216/1R travel lock, indicating its length, width, and thickness.

WARRANTY

This Yale YTP2/26/216/1R TSA Combination Travel Lock comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, abuse, unauthorized modification, or normal wear and tear. Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance, technical support, or warranty inquiries regarding your Yale YTP2/26/216/1R TSA Combination Travel Lock, please contact Yale customer service through their official website or the retailer where the product was purchased. Please have your model number and proof of purchase ready when contacting support.

You can find more information and contact details on the official [Yale Home website](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0038JHTFO>

More documents and user manuals: <https://manuals.plus/>