

Bulova B7467

Bulova B7467 Hardwick Mantel Clock Instruction Manual

Model: B7467 | Brand: Bulova

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Bulova B7467 Hardwick Mantel Clock. Please read these instructions carefully before using your clock to ensure proper function and longevity.

SETUP

1. Unpacking

- Carefully remove the clock from its packaging.
- Inspect the clock for any signs of damage. If damage is found, contact customer support immediately.
- Remove all protective materials, including any plastic films or foam inserts.

2. Battery Installation

The Bulova B7467 clock requires 1 AA battery (included). Ensure the battery is inserted with the correct polarity.

1. Locate the battery compartment on the back of the clock.
2. Open the battery compartment cover.
3. Insert one AA battery, matching the (+) and (-) terminals as indicated.
4. Close the battery compartment cover securely.



Figure 1: Rear view of the clock, highlighting the battery compartment and mechanism access.

Image Description: A clear photograph of the back of the Bulova B7467 mantel clock. The wooden casing is visible, and a circular opening near the top reveals the clock mechanism and battery compartment.

3. Placement

- Place the clock on a stable, flat surface such as a mantelpiece, shelf, or desk.

- Avoid direct sunlight or extreme temperature changes, which can affect accuracy and finish.
- Ensure the clock is level to allow the pendulum to swing freely.



Figure 2: Front-side view of the Bulova B7467 Hardwick Mantel Clock, showcasing its elegant design.

Image Description: A three-quarter view of the Bulova B7467 Hardwick Mantel Clock. The clock features a rich walnut brown wooden case with an arched top, a white dial with black Roman numerals, and a visible brass-finish pendulum swinging below the dial.

OPERATING INSTRUCTIONS

1. Setting the Time

1. Locate the time-setting knob on the back of the clock mechanism.
2. Gently turn the knob clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Avoid forcing the hands directly. Always use the setting knob.

2. Pendulum Operation

The clock features a decorative brass-finish metal pendulum. Once the battery is installed, the pendulum should begin to swing automatically. If it does not, gently push the pendulum to one side to initiate its motion.



Figure 3: Close-up view of the brass-finish metal pendulum, visible through the glass.

Image Description: A detailed close-up shot of the shiny, golden brass-finish pendulum of the clock, positioned against a dark background, indicating its movement.

Your browser does not support the video tag.

Video: Official product video demonstrating the Bulova B7467 clock, showcasing its design and the movement of the pendulum.

MAINTENANCE

1. Cleaning

- Wipe the wooden case with a soft, dry cloth. Avoid abrasive cleaners or polishes that may damage the finish.
- For the glass, use a soft cloth dampened with a mild glass cleaner. Spray cleaner onto the cloth, not directly onto the clock.
- Do not immerse the clock in water or expose it to excessive moisture.

2. Battery Replacement

Replace the AA battery annually or when the clock begins to lose time or the pendulum stops swinging. Follow the battery installation steps outlined in the Setup section.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not running / Pendulum not swinging	Dead or incorrectly installed battery.	Check battery polarity or replace with a fresh AA battery. Gently push the pendulum to start its motion.
Clock losing or gaining time	Weak battery or environmental factors.	Replace the battery. Ensure the clock is not exposed to extreme temperatures.
Pendulum stops intermittently	Clock not level or obstruction.	Ensure the clock is on a level surface. Check for any obstructions preventing free pendulum movement.

SPECIFICATIONS

Feature	Detail
Brand	Bulova
Model Number	B7467
Material	Solid Wood and Wood Veneer Case
Finish	Walnut Brown
Display Type	Analog with Roman Numerals
Special Feature	Decorative Brass-Finish Metal Pendulum
Power Source	Battery Powered (1 AA battery)
Product Dimensions	7"W x 10"H x 3.25"D (approximate)
Item Weight	2 Pounds




Figure 4: Diagram illustrating the dimensions of the Bulova B7467 clock, showing a height of 11 inches (26 cm).

Image Description: A silhouette of a person standing next to the Bulova B7467 clock, with measurement lines indicating the clock's height as 11 inches (26 cm). This provides a visual scale for the product dimensions.



WARRANTY AND SUPPORT

The Bulova B7467 Hardwick Mantel Clock comes with a Limited Warranty. For specific warranty details, please refer to the documentation included with your purchase or visit the official Bulova website.

For technical support, replacement parts, or further assistance, please contact Bulova Customer Service. Contact information can typically be found on the Bulova website or on the product packaging.

You can also visit the [Bulova Store on Amazon](#) for more product information and support resources.

Related Documents - B7467

	<p>Bulova Clock Installation Guide: Weights and Chains</p> <p>Instructions for installing weights and chains on a Bulova clock, detailing component identification such as chains, weights, and pendulum, with multilingual labels.</p>
	<p>Bulova Clock Installation Guide: Weights, Chains, and Pendulum Setup</p> <p>Comprehensive instructions for installing weights, chains, and the pendulum on your Bulova clock. Includes multilingual guidance and component identification for model C3381/3/R01.</p>

	<p><u>Bulova Quartz Clock Operating Instructions and Manual</u></p> <p>Detailed user manual for Bulova quartz clocks, covering setup, time setting, melody selection, volume control, pendulum operation, and general maintenance. Includes troubleshooting tips and feature explanations.</p>
	<p><u>Bulova C3542 Clock Operating Instructions and User Manual</u></p> <p>Detailed operating instructions and user manual for the Bulova C3542 analog quartz clock, covering setup, time setting, chime selection, volume control, and pendulum operation.</p>
	<p><u>Bulova Grandfather Clock Instruction Manual: Setup, Care, and Troubleshooting</u></p> <p>Comprehensive guide for Bulova Grandfather Clocks, covering setup, operation, maintenance, chime selection, and troubleshooting for cable-wound, chain-driven, and tubular bell movement models.</p>
	<p><u>Bulova 67J-3-R01 Quartz Clock: Operating Instructions and Manual</u></p> <p>Detailed operating instructions and manual for the Bulova 67J-3-R01 quartz clock. Learn how to set time, select melodies (Westminster, Ave Maria, Bim-Bam), adjust volume, use automatic night shut-off, and maintain your clock.</p>