

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Schonbek](#) /

› [Schonbek Renaissance Rock Crystal Pendant \(Model 3587-76CL\) Instruction Manual](#)

Schonbek 3587-76CL

Schonbek Renaissance Rock Crystal Pendant (Model 3587-76CL) Instruction Manual

Heirloom Bronze Finish with Clear Heritage Handcut and Quartz Rock Crystals

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Schonbek Renaissance Rock Crystal Pendant, Model 3587-76CL. Please read all instructions carefully before beginning installation and retain this manual for future reference.

The Schonbek Renaissance Rock Crystal Pendant is an 8-light fixture featuring a durable alloy steel frame in an Heirloom Bronze finish, adorned with Clear Heritage handcut crystals and sustainably mined Quartz Rock crystals. Each Quartz Rock crystal is hand-selected and polished to enhance its natural splendor. This fixture is designed for indoor use only.



Image: Schonbek Renaissance Rock Crystal Pendant, Model 3587-76CL. This image displays the chandelier in its full assembled form, showcasing the Heirloom Bronze frame, the arrangement of clear and multi-colored handcut and quartz rock crystals, and the overall elegant design. The fixture is suspended from a chain, highlighting its pendant style.

SAFETY INFORMATION

- **WARNING:** Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- This fixture is intended for indoor use only. Do not expose to moisture.
- Ensure the mounting surface can support the weight of the fixture (approximately 37 pounds).
- Use only E12 base, B10 shape 120V light bulbs, 60W maximum incandescent or LED equivalent.
- Wear safety glasses and gloves during installation.

INCLUDED COMPONENTS

Verify that all components are present before beginning installation:

- Lighting Fixture (Chandelier body)
- Mounting Hardware (Canopy, mounting strap, screws, wire nuts)
- Instruction Sheets (This manual)
- Manufacturer Warranty Certificate
- Certificate of Authenticity
- 40 inches of chain (matching finish)
- 144 inches of total wire

Note: Light bulbs (8 x E12 base, B10 shape, 60W max) are sold separately and are not included with the fixture.

SETUP AND INSTALLATION

1. **Turn Off Power:** Before starting, ensure the power to the junction box is turned off at the circuit breaker or fuse box.
2. **Prepare Mounting Location:** This fixture mounts to a standard electrical box. Ensure the electrical box and ceiling structure can safely support the fixture's weight (37 lbs).
3. **Install Mounting Strap:** Attach the mounting strap to the electrical box using the provided screws.
4. **Adjust Chain Length:** The fixture includes 40 inches of chain. Determine the desired hanging height and adjust the chain length by removing links as necessary. The total wire length is 144 inches, allowing for a maximum suspension up to 183.5 inches with additional chain (sold separately).
5. **Wire Connections:**
 - Connect the fixture's black wire to the supply circuit's black (hot) wire.
 - Connect the fixture's white wire to the supply circuit's white (neutral) wire.
 - Connect the fixture's ground wire to the supply circuit's ground wire (bare copper or green).
 - Secure all connections with wire nuts and wrap with electrical tape for added safety.
6. **Secure Canopy:** Carefully push the wired connections into the electrical box. Raise the canopy to the ceiling and secure it to the mounting strap using the provided screws.
7. **Install Crystals:** The crystals may be pre-attached or require individual attachment. Refer to the detailed crystal diagram (if provided separately) for specific placement. Handle crystals carefully to avoid damage.
8. **Install Bulbs:** Screw in 8 E12 base, B10 shape 120V light bulbs (60W max incandescent or LED, sold separately) into the sockets. Do not overtighten.
9. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.

Slope Ceiling Installation: This fixture can be installed on a slope ceiling up to a 45-degree angle. Ensure the canopy is properly seated and secured.

OPERATING INSTRUCTIONS

- **Power On/Off:** Operate the fixture using a standard wall switch connected to the electrical circuit.
- **Dimming Function:** This fixture supports smooth and continuous dimming when used with compatible dimmer switches and dimmable E12 LED or incandescent bulbs (sold separately). Consult your dimmer switch manufacturer's instructions for proper operation.

- **Light Source:** The fixture requires 8 E12 base, B10 shape 120V light bulbs, 60W maximum incandescent or LED. For optimal performance and energy efficiency, LED bulbs are recommended.

MAINTENANCE

- **Cleaning:**
 - *Fixture Frame:* Turn off power before cleaning. Wipe the Heirloom Bronze finish with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
 - *Crystals:* Gently dust crystals with a soft, lint-free cloth. For deeper cleaning, turn off power, carefully remove crystals (if detachable), and wash them in warm water with a mild soap solution. Rinse thoroughly and dry with a soft cloth before reattaching.
- **Bulb Replacement:** Turn off power before replacing bulbs. Allow bulbs to cool completely. Unscrew old bulbs and replace with new E12 base, B10 shape 120V light bulbs (60W max incandescent or LED).
- **Periodic Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fixture does not light up.	No power to the fixture. Loose wire connections. Faulty light bulb(s). Faulty wall switch.	Check circuit breaker/fuse. Turn off power and check all wire connections. Replace light bulb(s). Test wall switch or consult an electrician.
Lights flicker or dim inconsistently.	Loose wire connections. Incompatible dimmer switch or bulbs. Overloaded circuit.	Turn off power and check all wire connections. Ensure dimmer and bulbs are compatible and rated for LED/incandescent. Consult an electrician to check circuit load.
Crystals appear dull or dirty.	Accumulation of dust or residue.	Clean crystals as per maintenance instructions.

SPECIFICATIONS

Model Number:	3587-76CL
Brand:	Schonbek
Dimensions (L x W x H):	26.5" x 26.5" x 35"
Item Weight:	37 Pounds
Material:	Alloy Steel, Crystal
Finish:	Heirloom Bronze (Powder Coated)
Crystal Type:	Clear Heritage Handcut and Quartz Rock Crystals
Number of Lights:	8

Bulb Base:	E12
Max Wattage per Bulb:	60W (Incandescent or LED)
Voltage:	120 Volts
Dimmable:	Yes (with compatible dimmer and bulbs)
Power Source:	AC
Indoor/Outdoor Usage:	Indoor Only
Certifications:	UL, cUL, CSA rated
Assembly Required:	Yes

WARRANTY AND SUPPORT

Your Schonbek Renaissance Rock Crystal Pendant comes with a Manufacturer Warranty Certificate. Please refer to this document for specific warranty terms, conditions, and duration.

For technical assistance, replacement parts, or warranty claims, please contact Schonbek customer support. Contact information can typically be found on the manufacturer's website or on the warranty certificate provided with your product.

Online Resources: For additional information and support, you may visit the official Schonbek website.

