

Technics RS-TR575

Technics RS-TR575 Dual Cassette Deck User Manual

Model: RS-TR575 | Brand: Technics

INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your Technics RS-TR575 Dual Cassette Deck. Please read this manual thoroughly before using the unit and retain it for future reference. The Technics RS-TR575 is an auto-reverse, double compact cassette deck designed for high-quality audio recording and playback.

IMPORTANT SAFETY INFORMATION

- **Power Source:** Ensure the unit is connected to a power supply within the specified voltage range.
- **Ventilation:** Do not block ventilation openings. Allow adequate space around the unit for proper airflow.
- **Water and Moisture:** Do not expose the unit to rain or moisture. Do not place objects filled with liquids, such as vases, on the unit.
- **Heat:** Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the unit from the wall outlet before cleaning. Use a dry cloth for cleaning.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

PRODUCT OVERVIEW

The Technics RS-TR575 features two cassette decks (Deck 1 and Deck 2) for versatile playback and recording options. It includes controls for playback, recording, fast forward, rewind, and various audio adjustments.



Figure 1: Front view of the Technics RS-TR575 Dual Cassette Deck.

This image displays the front panel of the Technics RS-TR575. On the left is Deck 1, and on the right is Deck 2, both with visible tape wells. The central area houses the main control buttons, including transport controls (play, stop, pause, fast forward, rewind) for both decks, recording level knobs, and noise reduction selectors. An input jack for headphones is also visible on the lower central panel. The unit is black with silver feet.

Front Panel Controls

- **Deck 1 / Deck 2:** Cassette compartments for tape insertion.
- **Transport Controls:** Play, Stop, Pause, Fast Forward, Rewind buttons for each deck.
- **Record Button:** Initiates recording (typically with Play).
- **Recording Level Knobs:** Adjusts input audio level for recording.
- **Noise Reduction (Dolby B/C/HX Pro):** Selects noise reduction type.
- **Headphone Jack:** For private listening.
- **Power Button:** Turns the unit on/off.

SETUP

Unpacking and Placement

1. Carefully remove the unit from its packaging.
2. Place the cassette deck on a stable, level surface, away from direct sunlight, heat sources, and excessive dust or vibrations.
3. Ensure adequate ventilation around the unit (at least 10 cm clearance on sides and top).

Connections

Connect the Technics RS-TR575 to your audio system using standard RCA audio cables.

- Connect the **LINE OUT** jacks of the RS-TR575 to the **LINE IN** or **TAPE IN** jacks on your amplifier or receiver.
- Connect the **LINE IN** jacks of the RS-TR575 to the **LINE OUT** or **TAPE OUT** jacks on your amplifier or receiver for recording from other sources.
- Plug the power cord into a suitable AC outlet.

OPERATING INSTRUCTIONS

Playing a Cassette Tape

1. Press the **POWER** button to turn on the unit.
2. Press the **EJECT** button for Deck 1 or Deck 2 to open the cassette door.
3. Insert a cassette tape with the open side facing down and the exposed tape towards you. Close the cassette door firmly.
4. Press the **PLAY** button for the selected deck. The tape will begin to play.
5. Adjust the volume on your amplifier/receiver.
6. To stop playback, press the **STOP** button.
7. Use **FAST FORWARD** or **REWIND** buttons to navigate the tape.

Recording a Cassette Tape

The RS-TR575 supports various recording functions, including tape-to-tape dubbing and recording from external sources.

Tape-to-Tape Dubbing

1. Insert the source tape into Deck 1 (playback deck).
2. Insert a blank recordable tape into Deck 2 (recording deck). Ensure the tape's erase protection tab is intact.
3. Select the desired dubbing speed (Normal or High Speed, if available).
4. Press the **RECORD** button on Deck 2, then immediately press the **PLAY** button on Deck 1. Both decks will start, and recording will begin.
5. To stop recording, press the **STOP** button on Deck 2.

Recording from External Source

1. Ensure your external audio source (e.g., CD player, turntable) is connected to the **LINE IN** jacks of the RS-TR575 via your amplifier/receiver.
2. Insert a blank recordable tape into the desired recording deck (Deck 1 or Deck 2).
3. Start playback on your external audio source.
4. Adjust the **RECORDING LEVEL** knobs to ensure the recording level meters do not consistently peak into the red zone.
5. Press the **RECORD** button, then the **PLAY** button on the recording deck to begin recording.
6. To stop recording, press the **STOP** button.

Noise Reduction (Dolby B/C/HX Pro)

The Technics RS-TR575 features Dolby B, Dolby C, and HX Pro noise reduction systems to improve sound quality by reducing tape hiss. Select the appropriate noise reduction setting based on the recording or playback requirements.

- **Dolby B:** Standard noise reduction for general use.
- **Dolby C:** Provides greater noise reduction than Dolby B, suitable for recordings with a wider dynamic range.
- **HX Pro:** Optimizes bias during recording to extend high-frequency headroom, improving treble response.

MAINTENANCE

Cleaning the Unit

- Wipe the exterior of the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- For stubborn stains, dampen the cloth slightly with water or a mild detergent solution, then wipe dry.

Cleaning Tape Heads and Capstans

Regular cleaning of the tape heads, capstans, and pinch rollers is crucial for optimal sound quality and tape longevity. Perform this cleaning after every 20-30 hours of use or if sound quality degrades.


1. Turn off and unplug the unit.
2. Open the cassette door.
3. Using a cotton swab lightly dampened with isopropyl alcohol (90% or higher), gently clean the tape heads, capstans, and pinch rollers. Avoid excessive pressure.
4. Allow the components to dry completely before inserting a tape or operating the unit.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not connected; Power outlet faulty	Ensure power cord is securely plugged in; Try a different outlet
No sound during playback	Incorrect audio connections; Amplifier/receiver volume too low; Input selector on amplifier incorrect	Check RCA cable connections; Increase amplifier volume; Select correct input on amplifier (e.g., TAPE/CD)
Poor sound quality (muffled, distorted)	Dirty tape heads/capstans; Worn tape; Incorrect noise reduction setting	Clean tape heads and capstans (see Maintenance); Try a different tape; Adjust Dolby setting
Tape does not play/record	Tape not inserted correctly; Erase protection tab broken (for recording); Mechanical issue	Re-insert tape correctly; Cover erase protection tab with tape; If problem persists, seek professional service

SPECIFICATIONS

Feature	Detail
Type	Auto reverse, double compact cassette deck
Track System	4-track, 2-channel stereo
Tape Speed	4.8 cm/s
Heads	2 x record/playback, 2 x erase
Motor	2 x reel, 2 x capstan
Tape Type Support	Type I (Normal), CrO2 (Chrome), Metal
Noise Reduction	Dolby B, Dolby C, HX Pro
Frequency Response (Metal tape)	20Hz to 17kHz
Signal to Noise Ratio (Dolby C)	74dB
Wow and Flutter	0.1%
Input (Line)	100mV
Output (Line)	0.5V
Dimensions (W x H x D)	430 x 136 x 285mm
Weight	4.4kg (9.7 lbs)



Technics Stereo cassette deck **RS-TR575** .5/# O--HN1 79J-.lCj . Operating
Instructions ON13/JY.f5P D----- Before connecting, operating or adjusting this product,
please read these instructions completely. I Dear Customer Thank you for purchasing
this Technics product. For optimum performan...

[\[pdf\]](#) User Manual Instructions

Technics Stereo cassette deck **RS-TR575** Operating Instructions Before connecting : operating or adjusting this product. please read these instructions completely. Dear Customer Thank you for purchasing this Technics product. For optimum performance and sqfety. please read...

[\[pdf\]](#) User Manual Instructions Accessories

TECHNICS SA EX320 01 MANUAL drive google u uc id 1 6IZp9VDsmkiTOAmrKmMzplaDLj7PZj5 export
Sears Parts DirectTECHNICS MANUALTECHNICS MANUALThank you for purchasing this Technics
product For optimum performance and safety please read these instructions carefully User
memo 98060071TECHNICS 01TECHNICS 019806007198060071c searspartsdirect mmh lis OWNM
98060071drive exportc pd content is 98060071c 98060071 |||

AV ControlStereoReceiver SA-EX320 Operating Instructions Dear Customer Thank
you for purchasing ... s remote control. As of February 1998 Cassette deck CD
changer or CD player RS-TR373, RS-TR474, **RS-TR575**, RS-BX501, RS-TR252, RS-
TR262, RS-TR272 SL-PG440, SL-PD847, SL-PD947, SL-PS840, SLOpD667, S...

lang:en score:23 filesize: 4.16 M page_count: 28 document date: 0000-00-00



[\[pdf\]](#) User Manual

Technics RAK SA937MK user manual 459498 text archive org manualsbase id

Technics How to use the remote control transmitter RAK-SA937MK This remote control can be used to ... s remote control. As of February 1998 Cassette deck CD changer or CD player RS-TR373, RS-TR474, **RS-TR575**, RS-BX501, RS-TR252, RS-TR262, RS-TR272 SL-PG440, SL-PD847, SL-PD947, SL-PS840, SL-PD667, S...
lang:en score:23 filesize: 503.85 K page_count: 8 document date: 2020-08-27

AV Control Stereo Receiver SA-EX320

Operating Instructions



[\[pdf\]](#) User Manual Instructions Accessories

TECHNICS SA EX320 01 MANUAL Manual Hub drive google file d 1

6IZp9VDsmkITOAmrKmMzplaDLj7PZj5 preview |||

AV ControlStereoReceiver SA-EX320 Operating Instructions <https://manual-hub.com/>

Dear Customer ... s remote control. As of February 1998 Cassette deck CD changer or CD player RS-TR373, RS-TR474, **RS-TR575**, RS-BX501, RS-TR252, RS-TR262, RS-TR272 SL-PG440, SL-PD847, SL-PD947, SL-PS840, SLopD667, S...

lang:en score:21 filesize: 4.72 M page_count: 28 document date: 2023-10-27



[\[pdf\]](#) Specifications Guide Buyer's Guide

Buyer s Guid 199 Stereo Review 1999 Buyers Guide worldradiohistory Archive All Audio HiFi SPECIALS

|||

Stereo Review PRESENTS STIERIE, Buyer s.Guid 199 I Thousands of HOME THEATER And Audio oof Com ... 15 kHz high -bias; S/N 65 dB Dolby B NR; W F 0.09 wrms. 171/4 x 51/4 x in; 7 lb 139 TECHNICS **RS-TR575** Double Cassette Deck Dolby B, C, HX Pro. Record/play and autoreverse for both transports;...

lang:en score:19 filesize: 16.73 M page_count: 252 document date: 2018-08-01



[\[pdf\]](#) Specifications Guide Buyer's Guide

World Radio History Stereo Review 1998 Buyers Guide worldradiohistory Archive All Audio HiFi

SPECIALS BUYER S GUIDE |||

STEREO Stereo Review Presents. BUYER S GUIDE 1998 Shopping Tips: How To Find The Right Gear 7501/0 ... -15 kHz high -bias; S/N 65 dB Dolby B NR; W F 0.09 wrms. 17 x 5 x 8 in; 71b 139 TECHNICS **RS-TR575** Double Cassette Deck Dolby B, C, HX Pro. Record/play and autoreverse for both transports;...

lang:en score:19 filesize: 18.71 M page_count: 262 document date: 2018-08-01




[\[pdf\]](#) User Manual Specifications Guide Buyer's Guide

World Radio History Stereo Review 1996 Buyers Guide worldradiohistory Archive All Audio HiFi

SPECIALS |||

tereo Review Presents 1=Gi1URIDEE1 199v. udio and A/V 4 Components FEATURES, SPECS, AND PRICES Syst ... D players; bias control; FL level meter; remote con- trol through select Technics receivers 420 **RS-TR575** Double Cassette Deck Dolby B, C, HX Pro. Record/play and autoreverse for both transports;...


lang:en score:15 filesize: 17.55 M page_count: 252 document date: 2018-08-01



[\[pdf\]](#) User Manual

I _ This remote control can be used to operate the receiver you purchased plus other of our compact c ... s remote control. As of February 1997 Cassette deok CD changer or CD player RS-TR373, RS-TR474, **RS-TR575**, RS-BX501, RS-TR252, RS-TR262, RS-TR272 SL-PG440, SL-PD847, SL-PD947, SL-PS840, SL-PD667, S...

lang:en score:10 filesize: 320.36 K page_count: 6 document date: 0000-00-00




[\[pdf\]](#) Instructions

97110220 c searspartsdirect pd content is Sears |||

Technics Stereo cassette deck **RS-TR575** Operating Instructions connecting, operating or adjusting this product, please these Instructions completely. Dear Customer Thank you for purchasing this Technics product. For optimum performance and safety, please read these instructions carefully. The mode...

lang:en **score:10** filesize: 2.21 M page_count: 24 document date: 0000-00-00



[\[pdf\]](#)

book ideafix name stuff |||

.. 240 * . . . , . . 1998 65.9 2 421.5 59 59 . . . , : -- : , ... 50 -60 1 2 . Dolby / Dolby -Pro. TECHNICS **RS-TR575** 287 . . . 1 -- , 2 -- Dolby / ...

lang:es **score:10** filesize: 163.49 M page_count: 402 document date: 2013-04-30