



Manuals.plus /

› HP /

› HP 78A Black Toner Cartridge Instruction Manual for LaserJet Pro P1566, P1606, and MFP M1536 Series

HP CE278A

HP 78A Black Toner Cartridge Instruction Manual

Model: CE278A | For HP LaserJet Pro P1566, P1606 Series, and MFP M1536 Series

INTRODUCTION

This manual provides essential instructions for the proper installation, operation, and maintenance of your HP 78A Black Toner Cartridge (CE278A). This cartridge is designed to work with HP LaserJet Pro P1566, P1606dn, and HP LaserJet Pro MFP M1536dnf printers. Following these guidelines will help ensure optimal performance and print quality.



Image: HP 78A Black Toner Cartridge retail packaging.

SETUP AND INSTALLATION

Before beginning, ensure your printer is powered off. Refer to your specific HP LaserJet Pro printer's manual for detailed instructions on opening the toner compartment.

1. **Unpack the Cartridge:** Carefully remove the HP 78A Black Toner Cartridge from its packaging. The box contains one new Original HP 78A Black Toner Cartridge (CE278A).
2. **Prepare the Cartridge:** Gently rock the cartridge several times to distribute the toner evenly. This helps ensure consistent print quality.
3. **Remove Protective Seals:** Locate and remove any orange protective tabs or sealing tapes from the cartridge. Handle the cartridge by its sides to avoid touching the imaging drum.
4. **Insert into Printer:** Open the toner access door on your HP LaserJet Pro printer. Align the cartridge with the guides inside the printer and push it firmly until it clicks into place.
5. **Close Access Door:** Close the toner access door. The printer will typically perform a short calibration cycle.

Discover the right option for your printing needs



Image: An HP Original Toner cartridge installed within a compatible HP LaserJet printer, illustrating the integration of the toner for precision output.

OPERATING INSTRUCTIONS

Once installed, the HP 78A Black Toner Cartridge is ready for use. Original HP Toner provides a reliable printing experience, helping to avoid common printing problems and ensuring high-quality output.

- **Print Quality:** Expect rich blacks and sharp text for professional-looking documents.
- **Page Yield:** This cartridge has an approximate yield of 2,100 pages, based on ISO/IEC 19752 standards. Actual yield varies considerably based on content of printed pages and other factors.
- **Printer Protection:** Original HP Toner Cartridges feature tamper-resistant chips, firmware, and packaging designed to help protect your printer from malicious code and maintain data integrity.
- **Reliability:** Using Original HP Toner Cartridges helps prevent toner leaks and premature failures, contributing to consistent printer performance.

Help protect your printer and data

Tamper-resistant chips, firmware and packaging



Committed to office air quality

Image: A magnifying glass highlighting the sharp text and rich blacks produced by HP toner on printed documents.

MAINTENANCE AND ENVIRONMENTAL INFORMATION

Proper handling and disposal contribute to the longevity of your cartridge and environmental responsibility.

- **Storage:** Store unused toner cartridges in their original sealed packaging in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Recycling:** HP is committed to sustainability. 100% of Original HP Toner Cartridges contain recycled

content. HP offers a free and convenient recycling program for used cartridges. Visit the official HP website for details on how to return your empty cartridges.

- **Air Quality:** Original HP Toner is designed and tested to meet eco-label emissions guidelines, contributing to better office air quality.




Image: An HP toner cartridge, highlighting its internal components and security features designed to protect the printer and data.



Image: Hands holding small pieces of recycled plastic, illustrating HP's commitment to using recycled materials in new cartridges.

TROUBLESHOOTING

If you encounter issues with your HP 78A Black Toner Cartridge, consider the following common solutions:

- **Poor Print Quality:** If prints are faded, streaky, or have spots, gently rock the toner cartridge side-to-side to redistribute the toner. Ensure the protective seal was fully removed during installation.
- **"Toner Low" or "Replace Cartridge" Message:** If the message appears prematurely, ensure the cartridge is correctly seated. If the issue persists and print quality is poor, the cartridge may be nearing its end of life.
- **Cartridge Not Recognized:** Remove the cartridge and reinstall it, ensuring it clicks firmly into place. Check for any obstructions in the cartridge slot. Clean the electrical contacts on the cartridge and in the printer with a lint-free cloth if necessary.
- **Printer Error:** Consult your HP LaserJet Pro printer's user manual for specific error codes and troubleshooting steps. Restarting the printer can often resolve minor issues.

For persistent problems, refer to your printer's comprehensive troubleshooting guide or contact HP Support.

SPECIFICATIONS

Feature	Detail
Model Number	CE278A
Color	Black
Page Yield (Approx.)	2,100 pages
Compatible Printers	HP LaserJet Pro P1566, P1606dn, MFP M1536dnf
Product Dimensions	5.1 x 14.7 x 4.6 inches
Item Weight	1.74 pounds
Manufacturer	HP
UPC	884420588702

WARRANTY INFORMATION

HP Original Toner Cartridges are covered by HP's standard limited warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the official HP website or the documentation included with your printer. Keep your purchase receipt as proof of purchase.

SUPPORT

For further assistance, technical support, or to access additional resources, please visit the official HP Support website. You can find drivers, manuals, and contact information for customer service there.

HP Official Website: www.hp.com