

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KidKraft](#) /

› [KidKraft Metropolis Wooden Train Set & Table Instruction Manual](#)

KidKraft 17935

KidKraft Metropolis Wooden Train Set & Table Instruction Manual

Model: 17935

1. PRODUCT OVERVIEW

The KidKraft Metropolis Train Table Set offers an expansive urban scene for imaginative play. This set includes 100 colorful pieces, featuring a magnetic three-car train that operates on an elevated track, a double-decker suspension bridge, and a tall mountain. Designed for fun and safety, all pieces can be stored neatly in the jumbo storage drawer.

Key Features:

- Includes a construction crew, bulldozer, and a functional crane for lifting and moving blocks.
- Features an airplane and helicopter with a dedicated runway and heliport.
- Comes with various city elements: people, cars, buildings, and signs, all sized for small hands.
- Equipped with a large storage drawer for convenient organization of all pieces.
- Constructed from durable wood for long-lasting play.
- Compatible with other major toy train brands like Brio and Thomas & Friends.



Image 1: The complete KidKraft Metropolis Wooden Train Set and Table, showcasing the extensive layout and included accessories.

2. SETUP AND ASSEMBLY

Assembly of the KidKraft Metropolis Train Table requires careful attention to detail. It is recommended to unpack all components and verify their condition before beginning. Some users have reported issues with alignment of parts, particularly for the table frame and drawer components. Ensure all pieces fit securely to prevent instability.

Assembly Steps (General):

- 1. Unpack and Inspect:** Carefully remove all components from the packaging. Inspect each piece for any damage or manufacturing defects. It is advisable to unpack outdoors to minimize styrofoam debris indoors.
- 2. Assemble the Table Frame:** Follow the provided diagrams to connect the table frame pieces. Pay close attention to the alignment of all connectors and ensure they are securely fastened.
- 3. Construct the Storage Drawer:** Assemble the large storage drawer. This typically involves attaching the sides and bottom panels. The drawer is designed to slide underneath the table and is not permanently attached.
- 4. Place the Tabletop:** Position the reversible tabletop onto the assembled frame. One side features the city

landscape for the train set, while the other may offer a plain surface.

5. **Set Up the Track and Accessories:** Arrange the wooden track pieces, bridges, buildings, and other accessories according to the desired layout or the included guide.



Image 2: A detailed view of the train track system, showing a police station, construction vehicles, and road elements.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the features and play possibilities of the KidKraft Metropolis Train Table & Set.

3. OPERATING INSTRUCTIONS

The Metropolis Train Set is designed for interactive and imaginative play. Users can engage with various components to create dynamic scenarios.

Interactive Elements:

- **Train Operation:** Place the magnetic three-car train on the wooden tracks. Guide it along the elevated sections and through the city landscape.

- **Crane Functionality:** Utilize the working crane to pick up and move blocks or other small items around the construction area. Turn the knob to lift and lower the crane's hook.
- **Air and Sea Travel:** Use the airplane on the runway and the helicopter on its helipad for aerial adventures. The barge can transport shipping containers across the water sections.
- **City Exploration:** Move the included cars, people, and other figurines around the city roads and buildings to create diverse play scenarios.



Image 3: A child's hand interacting with the helicopter and helipad feature of the train set.

4. MAINTENANCE

Proper maintenance ensures the longevity and continued enjoyment of your KidKraft Metropolis Train Set.

Care Instructions:

- **Cleaning:** Wipe down all wooden and plastic components with a damp cloth. Avoid harsh chemical cleaners that may damage the finish or materials.

- **Storage:** Utilize the integrated storage drawer to keep all 100 pieces organized and protected when not in use. This helps prevent loss and damage.
- **Track Stability:** Periodically check track connections. If tracks frequently separate, consider using small, non-permanent adhesive solutions like velcro strips to secure them, as suggested by some users.
- **Environmental Conditions:** Store the train set in a dry environment to prevent warping or damage to the wooden components.



Image 4: The train table with its spacious storage drawer extended, showing how accessories can be neatly stored.

5. TROUBLESHOOTING

This section addresses common issues that may arise during the assembly or use of the train set.

Common Issues and Solutions:

- **Damaged or Scratched Parts Upon Arrival:** If any components are damaged or scratched upon unboxing, contact KidKraft customer support immediately for a replacement. Do not attempt to assemble damaged parts.

- **Table Frame/Drawer Misalignment:** Double-check all assembly steps and ensure that connectors are correctly aligned and fully inserted. If parts do not fit, verify that you are using the correct pieces as per the instruction manual.
- **Tracks Not Staying Connected:** Ensure track pieces are fully interlocked. For persistent issues, small pieces of non-permanent adhesive (e.g., poster putty, removable tape, or small velcro dots) can be used on the underside of the tracks to improve stability.
- **Missing Parts:** Refer to the parts list in your instruction manual. If any parts are missing, contact KidKraft customer support for assistance.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	46.9 x 32.9 x 26.75 inches
Item Weight	79.2 pounds
Model Number	17935
Manufacturer Recommended Age	36 months - 3 years
Material	Durable Wooden Construction
Number of Pieces	100

7. WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation included with your product or visit the official KidKraft website. For customer support, including inquiries about missing or damaged parts, assembly assistance, or general product questions, please contact KidKraft directly through their official channels.

KidKraft Official Website: www.kidkraft.com

