

QFX REM-115

QFX REM-115 Jumbo Universal Remote Control User Manual

Model: REM-115 | Brand: QFX

1. INTRODUCTION

The QFX REM-115 Jumbo Universal Remote Control is designed to provide a simplified and comprehensive control solution for up to eight of your home entertainment devices. Its oversized design ensures it is easy to locate and handle, while its glow-in-the-dark buttons enhance visibility in low-light conditions. This remote is equipped with dedicated shortcut buttons for popular streaming services, offering quick access to your favorite content.





Figure 1: The QFX REM-115 Jumbo Universal Remote Control. This remote is designed for easy handling and visibility.

2. SETUP

2.1 Battery Installation

The QFX REM-115 requires two (2) AA batteries for operation. To install, open the battery compartment cover on the back of the remote. Insert the batteries, ensuring correct polarity (+ and - ends match the indicators). Close the cover securely.

2.2 Code Pairing (Programming Your Remote)

The remote can be programmed using either an automatic code search or manual code entry. This process links the remote to your specific devices (TV, VCR, DVD, SAT/CABLE, AUX).

1. **Automatic Code Search:** This method scans for compatible codes automatically. Refer to the

included quick start guide for detailed steps on initiating the automatic code search function.

2. **Manual Code Entry:** If you know the specific code for your device's brand, you can enter it directly. A list of common brand codes is typically provided in the remote's packaging.



Figure 2: The remote supports both automatic and manual code pairing for quick setup.

3. OPERATING INSTRUCTIONS

Once programmed, the QFX REM-115 allows you to control various functions of your devices.

3.1 Button Functions Overview



WHERE THE PARTY BEGINS™

REASONS YOU'LL LOVE QFX



QFX BRAND LEADERSHIP

QFX honed its brand reputation over 40 years by providing quality consumer electronics products at an exceptional value.



WIDE RANGE OF PRODUCT OFFERINGS

QFX is a leading provider of a diverse line of consumer audio, video and technology products.



USA CUSTOMER TOUCH POINT

Customer support center provides responsive technical help through its on-site call center at 800.864.2582 or support@qfxusa.com.

Figure 3: Front view of the QFX REM-115 remote, displaying all control buttons.

- **Device Selection Buttons:** Use the dedicated buttons (TV, VCR, DVD, SAT/CABLE, AUX) at the top to select the device you wish to control.
- **Power Button:** Located at the top right, this button turns your selected device on or off.
- **Number Buttons (0-9):** For direct channel input or menu navigation.
- **Channel Up/Down (CH+/-):** Changes channels on your TV or cable box.
- **Volume Up/Down (VOL+/-):** Adjusts the volume of your audio device.
- **Mute Button:** Silences the audio output.
- **Navigation Buttons (UP, DOWN, LEFT, RIGHT, OK):** Used for menu navigation and selection.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Record):** For controlling VCRs, DVDs, or other media players.

3.2 Streaming Service Shortcut Buttons

The REM-115 features five dedicated shortcut buttons for quick access to popular streaming platforms:

- Netflix
- Prime Video
- YouTube

- Hulu
- Disney+

These buttons are designed for use with Smart TVs that have internet capabilities and the respective applications installed. Pressing a shortcut button will launch the corresponding application directly.



Figure 4: The remote features dedicated shortcut buttons for popular streaming services.

3.3 Glow-in-the-Dark Buttons

For enhanced usability in dimly lit environments, the buttons on the QFX REM-115 are designed to glow in the dark. This feature ensures that you can easily locate and operate the remote's functions without needing to turn on additional lights.

CHANNEL SURFING BIG REMOTE



Figure 5: The glow-in-the-dark buttons provide visibility in low-light conditions.

4. MAINTENANCE

4.1 Battery Replacement

When the remote's performance diminishes or the indicator light no longer illuminates, it is time to replace the batteries. Always replace both AA batteries simultaneously. Note that some users have reported needing to re-program the remote after battery replacement. Keep a record of your device codes for convenience.

4.2 Cleaning

To clean the remote, use a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the remote's interior. Avoid using harsh chemicals or abrasive cleaners.

5. TROUBLESHOOTING

If you encounter issues with your QFX REM-115 remote, please refer to the following common solutions:

- **Remote Not Responding:**

- Ensure fresh batteries are installed correctly.
- Verify the remote is pointed directly at the device's IR receiver.
- Confirm the correct device mode (TV, VCR, DVD, etc.) is selected on the remote.
- Attempt to re-program the remote to the device using the code pairing instructions.

- **Shortcut Buttons Not Working:**

- The shortcut buttons (Netflix, Prime Video, etc.) are only compatible with Smart TVs that have internet capabilities and the corresponding applications installed. Ensure your TV meets these requirements.
- Verify your Smart TV is connected to the internet.

- **Remote is Difficult to Handle:**

- Due to its jumbo size, some users may find it easier to hold the remote with one hand and operate buttons with the other.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	10.87 x 4.96 x 0.87 inches
Item Weight	9.6 ounces
Item Model Number	REM-115
Batteries Required	2 AA batteries
Max Number of Supported Devices	8
Special Feature	Universal, Glow-in-the-Dark Buttons, Streaming Shortcuts
Color	Black
Compatible Devices	TV, VCR, DVD, SAT/CABLE, AUX (up to 8 devices)




Figure 6: Dimensions of the QFX REM-115 remote control.

7. SUPPORT

For any questions, problems, or issues regarding your QFX REM-115 Universal Remote Control, please reach out to QFX directly at support@qfxusa.com.

Legal Disclaimer

WARNING: Cancer and Reproductive Harm – www.P65Warnings.ca.gov. QFX cannot be held responsible for any Proposition 65 action by the California Attorney General or private enforcer based on the failure to provide an internet warning.