

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Packard Bell](#) /

› [Packard Bell Silver 320GB External Hard Drive User Manual](#)

Packard Bell PX.T110J.011

Packard Bell Silver 320GB External Hard Drive User Manual

Model: PX.T110J.011

1. INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your Packard Bell Silver 320GB External Hard Drive. Please read this guide thoroughly to ensure optimal performance and longevity of your device.

The Packard Bell Silver 320GB External Hard Drive offers a convenient and portable solution for storing and backing up your digital data. Featuring a compact design and USB 2.0 connectivity, it is designed for ease of use across various operating systems.



Image 1.1: Top view of the Packard Bell Silver 320GB External Hard Drive, showcasing its sleek silver design and Packard Bell logo.

2. SETUP

2.1 Package Contents

- Packard Bell Silver 320GB External Hard Drive

- USB 2.0 Cable
- Quick Start Guide (if included)
- Packard Bell Software Suite (pre-loaded or via download)

2.2 System Requirements

- Available USB 2.0 port
- Operating System: Windows ME / 2000 / XP / Vista, MAC OS v9.0 or later, Linux

2.3 Connecting the Hard Drive

1. Locate an available USB 2.0 port on your computer.
2. Connect one end of the provided USB cable to the USB port on the Packard Bell external hard drive.
3. Connect the other end of the USB cable to the USB 2.0 port on your computer.
4. The drive is USB-powered and does not require an external power adapter. The operating system should automatically detect and install the necessary drivers (Plug and Play).
5. A new drive letter will appear in 'My Computer' (Windows) or on the desktop (Mac) once the drive is ready for use.



Image 2.1: Angled view of the external hard drive, showing its compact form factor and the USB port location.

3. OPERATING THE HARD DRIVE

3.1 Transferring Files

Once the drive is recognized by your computer, you can transfer files using standard operating system functions:

- **Drag and Drop:** Select files or folders from your computer and drag them to the external hard drive's icon or open folder.
- **Copy and Paste:** Right-click on files or folders, select 'Copy', then navigate to the external hard drive, right-click in an empty space, and select 'Paste'.

3.2 Using Packard Bell Software Suite

The included Packard Bell Software Suite may offer additional features such as backup utilities or security options. Refer to the software's documentation for detailed instructions on its use.

3.3 Safely Removing the Device

To prevent data corruption, always safely remove the hard drive before disconnecting it from your computer:

- **Windows:** Click the 'Safely Remove Hardware and Eject Media' icon in the system tray (bottom-right corner), then select the Packard Bell drive. Wait for the 'Safe to Remove Hardware' message before unplugging.
- **Mac:** Drag the drive's icon from the desktop to the Trash, or right-click the icon and select 'Eject'.

4. MAINTENANCE

4.1 Care and Handling

- Avoid dropping or subjecting the drive to strong impacts, as this can damage internal components.
- Keep the drive away from liquids, dust, and extreme temperatures.
- Do not open the drive enclosure; this will void any warranty and may damage the device.
- Clean the exterior with a soft, dry cloth. Do not use harsh chemicals or solvents.

4.2 Data Backup

Regularly back up important data stored on the external hard drive to another storage medium (e.g., your computer's internal drive, cloud storage, or another external drive) to prevent data loss in case of device failure or accidental deletion.



Image 4.1: The external hard drive shown in a hand, illustrating its compact and portable size.

5. TROUBLESHOOTING

5.1 Drive Not Detected

- Ensure the USB cable is securely connected to both the drive and the computer.
- Try connecting the drive to a different USB port on your computer.
- Restart your computer and try connecting the drive again.
- If using a USB hub, try connecting the drive directly to the computer's USB port.
- Check 'Disk Management' (Windows) or 'Disk Utility' (Mac) to see if the drive is listed but not assigned a drive letter or mounted.

5.2 Slow Data Transfer Speeds

- Ensure you are connected to a USB 2.0 port on your computer. Connecting to a USB 1.1 port will result in significantly slower speeds.
- Avoid running multiple data-intensive applications simultaneously during transfers.

- Ensure your computer's drivers are up to date.

5.3 Drive Disconnects Randomly

- Ensure the USB cable is not loose or damaged. Try a different USB cable if available.
- Connect the drive directly to a computer port, avoiding USB hubs.
- Check power management settings on your computer to ensure USB ports are not being powered down to save energy.

6. SPECIFICATIONS

Brand	Packard Bell
Model Number	PX.T110J.011
Series	SILVER 320 GB_C
Capacity	320 GB
Form Factor	2.5 inches
Interface	USB 2.0 (backward compatible with USB 1.1)
Data Transfer Rate (Max)	480 Mbit/s
Rotational Speed	5400 RPM
Power Source	USB Powered
Material	Aluminum
Color	Silver
Dimensions (L x W x H)	13.1 x 7.8 x 1.2 cm (5.16 x 3.07 x 0.47 inches)
Weight	150 g (0.33 lbs)
Compatible Operating Systems	Windows ME / 2000 / XP / Vista, MAC OS v9.0 or later, Linux
Included Software	Packard Bell Software Suite

7. WARRANTY INFORMATION

Specific warranty terms and conditions for the Packard Bell Silver 320GB External Hard Drive are typically provided at the point of purchase or can be found on the official Packard Bell website. Please retain your proof of purchase for warranty claims.

Information regarding spare parts availability and software update guarantees is not available in this manual. For the most current details, please refer to the manufacturer's official resources.

8. SUPPORT


For technical support, driver downloads, or further assistance with your Packard Bell Silver 320GB External Hard Drive, please visit the official Packard Bell support website. You may find FAQs, troubleshooting guides, and contact

information for customer service there.

When contacting support, please have your product model number (PX.T110J.011) and serial number (if applicable) ready.

© 2023 Packard Bell. All rights reserved. Information in this document is subject to change without notice.

Related Documents - PX.T110J.011

	<p>Packard Bell N11250 CloudBook Quick Start Guide</p> <p>A quick start guide for the Packard Bell N11250 CloudBook, covering buttons, ports, touchpad usage, Windows 10 S Mode, storage expansion with SATA M.2 SSD, and warranty information.</p>
	<p>Packard Bell EasyNote TS User Guide</p> <p>Comprehensive user guide for the Packard Bell EasyNote TS laptop, covering setup, software, internet usage, safety, maintenance, and recovery.</p>
	<p>Packard Bell EasyNote LJ65 Service Guide: Disassembly, Repair, and Troubleshooting</p> <p>This comprehensive service guide provides detailed technical information for the Packard Bell EasyNote LJ65 laptop, including disassembly procedures, component replacement instructions, troubleshooting steps, and system specifications.</p>
	<p>Packard Bell EasyNote TR82 Quick Start & Troubleshooting Guide</p> <p>This comprehensive guide provides essential information for setting up, using, and troubleshooting your Packard Bell EasyNote TR82 computer. Learn about basic operations, safety precautions, software, internet connectivity, and common issues.</p>
	<p>Packard Bell PBT200 Non-Contact Infrared Thermometer User Guide</p> <p>User guide for the Packard Bell PBT200 non-contact infrared thermometer. Learn how to use its features, including body/surface modes, fever alert system, and temperature history, along with safety and maintenance instructions.</p>
	<p>Packard Bell cloudBook N14550 Quick Start Guide</p> <p>A quick start guide for the Packard Bell cloudBook N14550 laptop, covering setup, features, Windows 10 S Mode, storage expansion, and legal information.</p>

