

[Manuals.plus](#) /

› [Kikkerland](#) /

› Kikkerland Solar Powered Waving Queen Figurine Instruction Manual

Kikkerland 1601-A

Kikkerland Solar Powered Waving Queen Figurine Instruction Manual

Model: 1601-A

1. INTRODUCTION

Thank you for purchasing the Kikkerland Solar Powered Waving Queen Figurine. This decorative item utilizes solar energy to create a continuous waving motion. This manual provides essential information for the proper setup, operation, and care of your figurine. Please read these instructions carefully before use.

2. PRODUCT OVERVIEW

The Kikkerland Solar Powered Waving Queen Figurine is a unique decorative piece designed to bring a touch of charm to any space. It features a small solar panel that converts light into energy, powering the figurine's waving arm.





Image 2.1: The Kikkerland Solar Powered Waving Queen Figurine.

The figurine is constructed from durable polyresin and measures approximately 1.5 inches (L) x 1.5 inches (W) x 6.5 inches (H). It is designed for indoor use and does not require batteries.

3. SETUP

1. **Unpack:** Carefully remove the figurine from its packaging.
2. **Placement:** Place the figurine on a flat, stable surface. Ensure the small solar panel, typically located on the front or base of the figurine, is exposed to direct sunlight or strong artificial light.

3. **Optimal Light:** For best performance, position the figurine near a window where it can receive ample natural light.

When the sunlight hits, **I wave!**



Image 3.1: Place the figurine where it can receive direct sunlight for activation.

4. OPERATING INSTRUCTIONS

The Waving Queen Figurine operates automatically using solar power.

- Once the solar panel receives sufficient light, the internal mechanism will activate, causing the figurine's arm to wave continuously.
- No on/off switch is required. The waving motion will begin and cease based on the available light.



Image 4.1: The figurine's arm waves when exposed to light.

5. MAINTENANCE

- **Cleaning:** To clean the figurine, gently wipe it with a soft, dry cloth. Avoid using abrasive cleaners or harsh chemicals, as these may damage the finish or the solar panel.
- **Solar Panel:** Ensure the solar panel remains clean and free of dust or obstructions to maintain optimal performance.
- **Storage:** If storing the figurine for an extended period, keep it in a cool, dry place away from direct sunlight to prevent potential fading or material degradation.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Figurine is not waving.	Insufficient light reaching the solar panel.	Move the figurine to a location with more direct sunlight or brighter artificial light. Ensure the solar panel is not obstructed.
Waving motion is weak or intermittent.	Low light conditions or dust on the solar panel.	Clean the solar panel with a soft, dry cloth. Relocate the figurine to a brighter area.

7. SPECIFICATIONS

- **Model Number:** 1601-A
- **Material:** Polyresin
- **Color:** Multicolor (Waving Queen style)
- **Dimensions (L x W x H):** Approximately 1.5" x 1.5" x 6.5" (3.8 cm x 3.8 cm x 16.5 cm)
- **Item Weight:** 0.44 Pounds (0.2 kg)
- **Power Source:** Solar Powered (No batteries required)
- **Recommended Use:** Indoor decorative item

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Kikkerland Solar Powered Waving Queen Figurine, please contact Kikkerland customer service.

Please refer to the official Kikkerland website or product packaging for the most current warranty information and contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B003EGB704>

More documents and user manuals: <https://manuals.plus/>