

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [HCC](#) /

> [1998 Suzuki LT-F500F Quadrunner \(Year Code:W\) - Handmade Black Marine Grade ATV Seat Cover Instruction Manual](#)

HCC HCC 74-709

1998 Suzuki LT-F500F Quadrunner ATV Seat Cover Instruction Manual

Model: HCC 74-709 | Brand: HCC

INTRODUCTION

This manual provides detailed instructions for the installation, care, and maintenance of your HCC Handmade Black Marine Grade ATV Seat Cover, designed specifically for the 1998 Suzuki LT-F500F Quadrunner (Year Code:W). This product is a full replacement seat cover, intended to be installed directly onto the seat pan after the removal of the original seat fabric.

PRODUCT OVERVIEW



Figure 1: The HCC Handmade Black Marine Grade ATV Seat Cover. This image displays the black, textured surface of the seat cover, highlighting its contoured shape designed to fit an ATV seat. The stitching along the edges is visible, indicating a durable construction.

The HCC ATV Seat Cover is crafted from durable material, providing a robust and comfortable surface for your ATV. Its design ensures a precise fit for the specified Suzuki Quadrunner model, enhancing both the aesthetics and functionality of your vehicle's seating.

SETUP AND INSTALLATION

Important: This seat cover is a full replacement. The existing seat cover fabric must be completely removed, exposing the foam on the seat pan, before proceeding with installation.

Required Tools:

- Staple gun (manual or pneumatic)
- Staples (stainless steel, 1/4 inch or 6mm recommended)
- Flathead screwdriver or staple remover
- Pliers
- Heat gun or hairdryer (optional, for stretching material)

Installation Steps:

1. **Remove Old Seat Cover:** Carefully remove all existing staples and the old seat cover from the seat pan. Ensure the foam is clean and free of debris.
2. **Position New Cover:** Place the new HCC seat cover over the foam and seat pan. Center it carefully, ensuring the seams align with the contours of the seat.
3. **Initial Fastening (Front):** Begin by stapling the front edge of the seat cover to the underside of the seat pan. Pull the material taut to remove wrinkles, but do not overstretch. Place a few staples evenly across the front.
4. **Initial Fastening (Rear):** Move to the rear of the seat. Pull the material taut from the front, ensuring it is centered and smooth. Staple the rear edge to the underside of the seat pan.
5. **Side Fastening:** Work from the center outwards on both sides of the seat. Pull the material firmly and evenly, stapling it to the underside of the seat pan. Use a heat gun or hairdryer on a low setting if needed to gently warm and stretch the material around curves, ensuring a smooth, wrinkle-free finish.
6. **Trim Excess Material:** Once all edges are securely stapled, carefully trim any excess material from the underside of the seat pan, leaving a small margin beyond the staples.
7. **Inspect:** Turn the seat over and inspect the new cover for any wrinkles, loose spots, or misalignments. If necessary, remove staples from problem areas, re-stretch, and re-staple.

OPERATING AND CARE

Once installed, the seat cover requires minimal "operation" beyond regular use. Proper care will ensure its longevity and appearance.

General Use:

- Avoid sharp objects that could puncture or tear the material.
- Do not expose the seat cover to extreme heat sources for prolonged periods.

MAINTENANCE

Cleaning Instructions:

- For general cleaning, wipe the seat cover with a damp cloth and mild soap solution.
- Rinse thoroughly with clean water to remove any soap residue.
- Dry with a soft, clean cloth.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the material.
- For stubborn dirt, a soft brush can be used gently.

Storage:

If the ATV is stored outdoors, consider using an ATV cover to protect the seat from prolonged exposure to UV rays and harsh weather conditions, which can extend the life of the seat cover.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Wrinkles or loose spots after installation	Insufficient stretching during installation; uneven stapling.	Carefully remove staples from affected area, re-stretch the material tautly and evenly, then re-staple. A heat gun on low setting can assist in stretching.
Material appears different than expected (e.g., not "marine grade")	Misunderstanding of material properties; manufacturing variation.	Verify product specifications against received item. If discrepancy persists, contact HCC customer support for clarification or resolution.
Tears or punctures	Contact with sharp objects; excessive force.	Small tears may be repaired with a vinyl repair kit. For larger damage, replacement of the seat cover may be necessary.

SPECIFICATIONS

- **Product Type:** Full Replacement ATV Seat Cover
- **Brand:** HCC
- **Model Number:** HCC 74-709
- **Compatibility:** 1998 Suzuki LT-F500F Quadrunner (Year Code:W)
- **Material:** Handmade Black Marine Grade (as per product description)
- **Color:** Black
- **Fit Type:** Universal Fit (*Note: While listed as "Universal Fit" in some specifications, this product is designed for the 1998 Suzuki LT-F500F Quadrunner.*)
- **Position:** Rear (Seat)
- **ASIN:** B003ELUODA
- **First Available:** March 30, 2010

WARRANTY AND SUPPORT

Return Policy:

This product is subject to a 30-day return policy from the date of purchase. Please refer to the retailer's return guidelines for specific terms and conditions.

Customer Support:

For any questions regarding installation, product specifications, or material concerns, please contact the manufacturer, HCC, or the retailer from whom the product was purchased. Keep your purchase receipt and product details readily available when contacting support.