

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Lewis N. Clark](#) /
- › [Lewis N. Clark Triple Security Lock - User Manual](#)

Lewis N. Clark TSA80-Multi-One Size

Lewis N. Clark Triple Security Lock

User Manual

PRODUCT OVERVIEW

The Lewis N. Clark Triple Security Lock is a versatile and durable combination lock designed for securing luggage and other personal items during travel. Its unique design allows for multiple locking configurations, providing enhanced security and peace of mind. This lock is TSA-friendly, allowing security agents to inspect your baggage without damaging the lock.



Image: The Lewis N. Clark Triple Security Lock, featuring its compact black body, three resettable combination dials, and two flexible braided steel cables. The lock is designed for versatile security applications.

Key Features:

- **Triple Security Design:** Allows locking zipper pulls together, securing luggage handles to zipper pulls, or attaching luggage to fixed objects.
- **TSA Friendly:** Approved by the Transportation Security Administration, enabling security personnel to open and re-lock without damage.
- **Keyless Combination:** Features a 3-dial resettable combination for convenient access without keys.
- **Durable Construction:** Made from sturdy cast Zinc Alloy with ABS plastic housing and two braided steel cables.

SETUP: SETTING YOUR COMBINATION

Your Lewis N. Clark Triple Security Lock comes preset to 0-0-0. To set your personal combination, follow these steps:

1. Ensure the lock is set to the current combination (factory default is 0-0-0).
2. Locate the red reset button/lever on the side or back of the lock.
3. Using a pen or a pointed object, press and hold the red reset button/lever. Some models may require you to slide or flip a red plastic piece.
4. While holding the reset mechanism, rotate the dials to your desired 3-digit combination. Choose a memorable number.
5. Release the reset button/lever. Your new combination is now set.
6. **Important:** After setting the combination, ensure the red plastic piece (if applicable) is returned to its original position or removed from the reset slot to prevent accidental combination changes. Test your new combination by scrambling the dials and then entering your new code to open the lock.



Image: Detailed view of the lock's components, highlighting the resettable 3-dial mechanism and the durable construction, essential for understanding the setup process.

OPERATING THE LOCK

The Lewis N. Clark Triple Security Lock offers multiple ways to secure your belongings:

- **Opening the Lock:** Align the dials to your set 3-digit combination. The cable ends will release from the lock body.
- **Closing and Locking:** Insert both cable ends firmly into the lock body until they click into place. Scramble the dials to secure the lock.
- **Securing Zipper Pulls:** Pass one or both cable ends through the zipper pulls of your luggage and then into the lock body.
- **Locking to Fixed Objects:** Use one cable end to secure your bag to a stationary object (e.g., a chair leg, luggage rack) and the other end to your bag's zipper pulls or handle, then insert both into the lock body.
- **Adding a Bag:** Secure smaller bags (laptop bag, purse, toiletry bag) to your main luggage by looping one cable end through the smaller bag's handle and the other through your main luggage's handle or zipper pulls, then lock.



Image: The lock in use, demonstrating how it can secure a luggage handle, providing an additional layer of security for your belongings.



Image: An example of the lock's versatility, securing a bicycle helmet to a bike rack, illustrating its use beyond traditional luggage.

MAINTENANCE

To ensure the longevity and smooth operation of your Lewis N. Clark Triple Security Lock, consider the following maintenance tips:

- **Cleaning:** Wipe the lock body and cables with a soft, damp cloth to remove dirt and grime. Avoid harsh chemicals or abrasive cleaners.
- **Lubrication:** Periodically apply a small amount of silicone-based lubricant to the dial mechanism and cable entry points to ensure smooth operation, especially if used in dusty or humid environments.
- **Storage:** Store the lock in a dry place when not in use to prevent corrosion.
- **Inspection:** Regularly inspect the cables for any signs of fraying or damage, and the lock body for cracks or deformities. Discontinue use if significant damage is observed.

TROUBLESHOOTING

If you encounter issues with your Lewis N. Clark Triple Security Lock, refer to the following common

problems and solutions:

Problem	Possible Cause	Solution
Lock will not open with correct combination.	Dials are not precisely aligned; internal mechanism obstructed; combination accidentally changed.	Ensure each number is perfectly centered in the window. Gently wiggle the dials while attempting to open. If the combination was accidentally changed during reset, unfortunately, there is no master key or override.
Cables do not insert or release smoothly.	Dirt or debris in the cable slots; lack of lubrication; bent cable ends.	Clean the cable slots and cable ends. Apply a small amount of silicone lubricant. Ensure cables are not bent or damaged.
Combination changes unexpectedly.	Reset button/lever was accidentally pressed or not fully disengaged after setting.	Always ensure the reset mechanism is fully disengaged and returned to its locked position after setting a new combination. Be careful not to press it during normal operation.

SPECIFICATIONS




Image: Dimensional drawing of the lock, providing precise measurements for planning its use with various luggage types.

Feature	Detail
Brand	Lewis N. Clark
Model Name	TSA-Approved Triple Security Lockdown Lock With Two Steel Cables
Model Number	TSA80-Multi-One Size
Lock Type	Combination Lock (3-Dial Resettable)
Material	Alloy Steel, Plastic, Acrylonitrile Butadiene Styrene (ABS), Zinc
Color	Black
Item Dimensions (L x W x H)	6 x 2 x 6 inches (approximate, as per product dimensions)
Item Weight	2.11 ounces
Special Feature	Resettable, TSA Friendly

WARRANTY INFORMATION

For specific warranty details regarding your Lewis N. Clark Triple Security Lock, please refer to the product packaging or visit the official Lewis N. Clark website. Warranty terms and conditions may vary.

SUPPORT

If you require further assistance or have questions not covered in this manual, please contact Lewis N. Clark customer support. Contact information can typically be found on the product packaging or their official website.

You may also find additional resources and FAQs on the [Lewis N. Clark Brand Store on Amazon](#).