

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Panasonic](#) /

› [Panasonic ErgoFit Wired Earbuds Instruction Manual](#)

Panasonic RP-HJE120-K

Panasonic ErgoFit Wired Earbuds Instruction Manual

Model: RP-HJE120-K

INTRODUCTION

This manual provides essential information for the safe and effective use of your Panasonic ErgoFit Wired Earbuds. Please read this manual thoroughly before using the product and retain it for future reference.



Image: Panasonic ErgoFit Wired Earbuds in black, showcasing their sleek design.

SAFETY INFORMATION

To ensure safe operation, always observe the following precautions:

- Avoid prolonged listening at high volume levels to prevent hearing damage.
- Do not use the earbuds in situations where inability to hear ambient sounds could be dangerous (e.g., while driving, cycling, or walking in traffic).
- Keep out of reach of small children due to small parts that may pose a choking hazard.
- Do not disassemble, modify, or attempt to repair the earbuds.
- Avoid exposing the earbuds to extreme temperatures, humidity, or direct sunlight.

PACKAGE CONTENTS


Verify that all items are present in the package:

- Panasonic ErgoFit Wired Earbuds (RP-HJE120-K)
- Ear Cushions (S/M/L sizes)



Features / Caractéristiques

Ergonomic Hold Design Forme ergonomique



Cord length 1.1 m/3.6 ft.
Cordon de 1,1 m/3,6 pi



3.5 mm (1/8 in.) stereo plug
Fiche stéréo
de 3,5 mm (1/8 po)

Neodymium Magnet / Aimant au néodyme

Driver units / Excitateurs	9 mm (3/8 in. / 3/8 po)
Frequency response Réponse en fréquence	20 Hz - 20 kHz
Sensitivity / Sensibilité	96 dB/mW
Impedance / Impédance	16 Ω
Power handling capacity Puissance admissible	200 mw (IEC/CEI)

Image: The product packaging, illustrating the earbuds and included ear cushions.

SETUP

1. Selecting the Right Earpiece Size

For optimal sound quality and comfort, it is crucial to select the correct size of ear cushions. The earbuds come with three sizes: Small (S), Medium (M), and Large (L).

1. Try each size to determine which provides the most secure and comfortable fit in your ear canal.
2. A good fit will create a seal that helps to block out external noise and enhance bass response.
3. If the earbud tips do not match your ear canals or are not worn properly, sound quality and performance may be affected.

- **Ergofit earphones**

Sound, fit and comfort

- **Clear dynamic sound**

Large 9mm neodymium drivers

- **In Ear Audio**

Balanced stereo for natural treble and full bass




Image: A visual guide demonstrating how to choose the correct earbud tip size (S, M, L) for a personalized and comfortable fit.

2. Connecting to Your Device

The Panasonic ErgoFit Earbuds feature a standard 3.5mm audio jack for universal compatibility.

1. Locate the 3.5mm headphone jack on your audio device (smartphone, tablet, laptop, MP3 player, etc.).
2. Insert the earbud's 3.5mm plug firmly into the device's headphone jack until it clicks into place.
3. Ensure the connection is secure to prevent audio interruptions.

Personalized Comfort

S 

M 

L 



Image: The 3.5mm audio jack, illustrating its compatibility with a range of devices including cellphones, tablets, laptops, and desktops.

OPERATING INSTRUCTIONS

Listening to Audio

Once connected, you can begin playing audio from your device.

- Adjust the volume directly on your connected device to a comfortable listening level.
- The ErgoFit design ensures the earbuds conform to your ears for a secure fit, ideal for various activities including exercise.
- The 9mm neodymium drivers deliver dynamic, crystal-clear sound with balanced audio, providing crisp highs and deep lows.



Image: A user wearing the Panasonic ErgoFit Earbuds, demonstrating their comfortable and secure fit during use.

MAINTENANCE AND CARE

- **Cleaning:** Gently wipe the earbuds and ear cushions with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in a clean, dry place. Avoid tangling the cord by coiling it neatly. The 3.6-foot cord is designed to thread comfortably through clothing and bags.
- **Protection:** Protect the earbuds from moisture, dust, and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound or low volume	Volume on device is too low or muted. Earbuds not fully plugged in. Incorrect earpiece size affecting seal.	Increase volume on your device. Check if device is muted. Ensure the 3.5mm jack is fully inserted into the device. Try different sized ear cushions (S/M/L) to achieve a snug fit and proper seal.
Poor sound quality (e.g., distorted, lacking bass)	Loose connection. Earpieces not properly seated in ear. Audio source issue.	Check the 3.5mm connection. Adjust earbuds in your ears to ensure a proper seal. Experiment with different earpiece sizes. Test with a different audio source or device to rule out source issues.

Problem	Possible Cause	Solution
Earbuds fall out easily	Incorrect eartip size. Improper insertion.	Try a larger size of ear cushions for a more secure fit. Ensure the earbuds are inserted correctly into your ear canal, utilizing the ErgoFit design.

SPECIFICATIONS

Feature	Detail
Model Name	RP-HJE120-K
Brand	Panasonic
Connectivity Technology	Wired
Headphones Jack	3.5 mm Jack
Ear Placement	In Ear
Form Factor	In Ear
Frequency Response	20 Hz - 20 KHz
Impedance	16 Ohm
Cable Length	3.6 Feet
Item Weight	0.141 ounces (approx. 4 grams)
Material	Silicone, Plastic
Compatible Devices	Cellphones, Tablets, Laptops, Desktops
Country of Origin	China

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Panasonic website. Keep your proof of purchase for any warranty claims.

Manufacturer: Panasonic

