Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Nostalgia /
- > Nostalgia ICMP400BLUE 4-Quart Electric Ice Cream Maker Instruction Manual

Nostalgia ICMP400BLUE

Nostalgia ICMP400BLUE 4-Quart Electric Ice Cream Maker Instruction Manual

Model: ICMP400BLUE | Brand: Nostalgia

Introduction

The Nostalgia ICMP400BLUE 4-Quart Electric Ice Cream Maker provides a convenient method for preparing homemade ice cream, frozen yogurt, or gelato. This unit is designed for ease of use, featuring an electric motor for churning and a durable aluminum canister. The plastic bucket includes an easy-carry handle for portability and a see-through lid for storage. This manual provides instructions for safe and effective operation, maintenance, and care of your ice cream maker.



Figure 1: Overall view of the Nostalgia ICMP400BLUE 4-Quart Electric Ice Cream Maker with prepared ice cream.

IMPORTANT SAFETY INFORMATION

Please read all instructions before operating this appliance to ensure safe use and prevent injury or damage. This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Always exercise caution and follow proper handling procedures.

- Do not immerse the motor unit in water or other liquids.
- Ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Keep hands and utensils out of the freezer bowl during operation to reduce the risk of injury.
- Do not operate any appliance with a damaged cord or plug.
- Supervise children when the appliance is in use.

PRODUCT COMPONENTS

The Nostalgia ICMP400BLUE Ice Cream Maker includes the following components:

- Plastic Bucket: The outer container that holds ice and salt. Features an easy-carry handle.
- Aluminum Canister: The inner container where ice cream ingredients are churned.
- Dasher: The mixing paddle that churns the ingredients inside the canister.
- Motor Unit: The electric motor that drives the dasher. It locks into place on the bucket.

- Lid: A transparent lid for the aluminum canister, allowing for storage of leftover ice cream.
- Lid Cap: A small cap for the lid.



Figure 2: Disassembled components of the ice cream maker.

SETUP INSTRUCTIONS

- 1. Prepare the Canister: Ensure the aluminum canister is clean and dry.
- 2. **Add Ingredients:** Pour your desired ice cream, frozen yogurt, or gelato mixture into the aluminum canister. Do not fill more than 2/3 full to allow for expansion during freezing.
- 3. **Insert Dasher:** Place the dasher (mixing paddle) into the canister, ensuring it is properly seated at the bottom.
- 4. Position Canister: Place the filled canister into the center of the plastic bucket.
- 5. **Add Ice and Salt:** Layer ice and rock salt around the aluminum canister within the plastic bucket. Alternate layers of ice and salt until the canister is surrounded. Ensure the ice and salt mixture reaches the top of the canister.
- 6. **Attach Motor Unit:** Place the motor unit onto the top of the plastic bucket, ensuring it locks securely into place and the dasher shaft engages with the motor.



Figure 3: Adding ice and rock salt to the bucket around the canister.

OPERATING INSTRUCTIONS

1. Plug In: Plug the electric motor unit into a standard electrical outlet. The motor will begin churning

automatically.

- 2. **Churning Process:** Allow the ice cream maker to churn. The duration will vary depending on the recipe and desired consistency, typically 20-40 minutes. The motor will slow down or stop when the ice cream reaches a thick consistency.
- 3. **Monitor Consistency:** Periodically check the ice cream's consistency. For firmer ice cream, you may need to add more ice and salt during the process.
- 4. **Unplug:** Once the desired consistency is achieved, unplug the unit immediately to prevent motor strain.
- 5. Remove Motor and Dasher: Carefully remove the motor unit and then lift out the dasher from the canister.
- 6. **Serve or Store:** Serve the freshly made ice cream immediately for a soft-serve consistency, or transfer it to the included lid-covered canister and place it in the freezer for a firmer texture.

Your browser does not support the video tag.

Video 1: Demonstration of the Nostalgia ICMP400BLUE Electric Ice Cream Maker in operation, showing the churning process.

Your browser does not support the video tag.

Video 2: Overview of the Nostalgia 4-QT Electric Ice Cream Maker, highlighting its ease of use for making sweet treats.



Figure 4: Freshly churned ice cream being scooped from the canister.

RECIPES

The instruction manual included with your Nostalgia ICMP400BLUE Ice Cream Maker contains several recipes to get you started. These recipes are designed for optimal results with your specific unit. Experiment with different ingredients and flavors to customize your homemade treats.

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and performance of your ice cream maker.

- Cleaning: All removable parts (canister, dasher, lid) should be hand washed with warm, soapy water. The plastic bucket can be wiped clean with a damp cloth.
- Motor Unit: The motor unit should never be immersed in water. Wipe it clean with a damp cloth only.
- Storage: Store the ice cream maker in a cool, dry place when not in use. Ensure all components are completely dry before storing.

TROUBLESHOOTING

If you encounter issues with your ice cream maker, consider the following common solutions:

- Motor Not Starting: Ensure the unit is properly plugged into a working outlet and the motor unit is correctly seated and locked onto the bucket.
- Ice Cream Not Freezing: Verify that enough ice and rock salt are used and properly layered around the canister. The ice cream mixture should also be pre-chilled. Ensure the dasher is turning correctly.
- Motor Straining/Stopping: This typically indicates the ice cream has reached its optimal consistency.
 Unplug the unit immediately. If it strains prematurely, check for obstructions or ensure the mixture is not overfilled.

SPECIFICATIONS

• Brand: Nostalgia

• Model Name: Electric

• Item Model Number: ICMP400BLUE

• Capacity: 4 Quarts

. Color: Blue

• Material: Plastic (Bucket), Aluminum (Canister)

Operation Mode: AutomaticItem Weight: 5.15 Pounds

• Product Dimensions: 15 x 17 x 16 inches

• Special Features: See-Through Lid, Easy-Carry Handle

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your product packaging or visit the official Nostalgia website. Keep your purchase receipt for warranty claims.

© 2023 Nostalgia. All rights reserved.

NOSTALGIA* PRODUCTS	Nostalgia ICMCC33 Large Capacity Automatic Clear Ice Cube Maker - User Manual and Recipes Comprehensive user manual and recipe guide for the Nostalgia ICMCC33 automatic clear ice cube maker. Learn how to safely operate, clean, and maintain your ice maker, troubleshoot common issues, and discover delicious drink recipes.
NOSTALGIA PRODUCTS GEOGRA	Nostalgia Coca-Cola Snow Cone Maker CKSCM525CR: Instructions, Recipes, and Safety Official instruction manual and recipe guide for the Nostalgia Coca-Cola Snow Cone Maker (Model CKSCM525CR). Includes safety precautions, operating instructions, cleaning tips, and various recipes for snow cones, slush drinks, and more.
NOSTALGIA* PRODUCTS GOOGLE- CONC	Nostalgia CKFBS40CR Coca-Cola Frozen Beverage Station User Manual & Recipes User manual for the Nostalgia CKFBS40CR Coca-Cola Frozen Beverage Station. Learn how to operate, clean, and maintain your ice shaver, and find delicious drink recipes.
NOSTALGIA PRODUCTS	Nostalgia Retro Kettle Popcorn Maker CKKPTT25CR - Instructions, Recipes, and Warranty Comprehensive guide for the Nostalgia Retro Kettle Popcorn Maker (Model CKKPTT25CR), including operating instructions, safety precautions, cleaning and maintenance tips, delicious recipes, and warranty information. Learn how to make perfect popcorn with this vintage-style appliance.
NOSTALGIA* PRODUCTS	Nostalgia Giant Gummy Candy Maker NGCM6: Instructions, Recipes, and Safety Guide Comprehensive guide for the Nostalgia Giant Gummy Candy Maker (Model NGCM6), including operation instructions, safety precautions, cleaning tips, and delicious recipes for making gummy candies, vitamins, and energy chews.
NOSTALGIA P.R.O.D.U.C.T.S	Nostalgia MyMini Lava & Bundt Cake Maker Instructions and Recipes Comprehensive instructions, safety precautions, and recipes for the Nostalgia MyMini Lava & Bundt Cake Maker. Learn how to operate, clean, and maintain your appliance for making delicious mini cakes, donuts, and more.