

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Coaster Fine Furniture](#) /
- › [Coaster Home Furnishings 2-Door Bar Unit with 1 Drawer \(Model 100175\) Instruction Manual](#)

### Coaster Fine Furniture 100175

# Coaster Home Furnishings 2-Door Bar Unit with 1 Drawer (Model 100175) Instruction Manual

Model: 100175

## INTRODUCTION

---

Thank you for purchasing the Coaster Home Furnishings 2-Door Bar Unit with 1 Drawer. This contemporary bar unit is designed to provide functional storage and a stylish serving area for your home. Please read this manual thoroughly before assembly and use to ensure proper setup and longevity of your product.



Image: Front view of the assembled bar unit, showcasing its sleek black finish and overall design.

## SAFETY INFORMATION

- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.
- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten hardware as needed.
- Do not overload shelves or drawers. Distribute weight evenly.
- Keep small parts and packaging materials away from children during assembly.
- This unit is designed for indoor use only.

## PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- One (1) Bar Unit Base
- One (1) Bar Unit Top
- Assembly Hardware (screws, brackets, etc.)

## SETUP AND ASSEMBLY

This bar unit requires minimal assembly. The main body of the bar unit comes pre-assembled. Only the bar top needs to be attached.

1. **Unpacking:** Carefully remove all components from the packaging. It is recommended to have at least two people for safe handling due to the size and weight of the main unit. Inspect the unit for any damage immediately upon delivery.
2. **Positioning:** Choose a suitable location for your bar unit. Consider the dimensions: 60 inches (W) x 29 inches (D) x 42 inches (H). Ensure there is adequate space around the unit for access and use.



Image: Diagram showing the dimensions of the bar unit: 60 inches wide, 29 inches deep, and 42 inches high.

3. **Attaching the Bar Top:** Place the bar top onto the main base unit, aligning the pre-drilled holes. Secure the top using the provided screws and hardware. Tighten all screws firmly but do not overtighten.




Image: Close-up view of the bar unit's top surface, indicating where the bar top connects to the main structure.

## OPERATING INSTRUCTIONS

---

The bar unit offers various storage options for your convenience.

- **Drawer:** The unit features one drawer for storing bar tools, napkins, or other small accessories.



Image: The single drawer of the bar unit pulled open, revealing its interior storage space.

- **Glassware Racks:** Two hanging stemware racks are integrated, capable of holding up to 24 glasses.
- **Wine Bottle Storage:** The unit includes dedicated storage for up to 6 wine bottles.



Image: Close-up of the interior wine racks, designed to securely hold bottles.

- **Shelves:** Two additional shelves provide open storage for bottles, decor, or other items.



Image: Rear view of the bar unit, displaying the open shelves, wine racks, and stemware holders.



Image: Interior view of the bar unit's cabinet, showing the two shelves behind the glass doors.

## MAINTENANCE

- **Cleaning:** Wipe the unit with a dry cloth to remove dust and spills. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Protection:** The unit is constructed from poplar, MDF, and birch veneer. To prevent scratches, dents, and water damage, use coasters under drinks and protective mats for serving areas.
- **Environmental Conditions:** Avoid placing the unit in direct sunlight or near heat sources, which can cause fading or warping. Maintain a stable room temperature and humidity.

## TROUBLESHOOTING

- **Damage Upon Arrival:** If the unit arrives with cracks, nicks, or other damage, document it with photographs and

contact the retailer or manufacturer immediately before assembly. Note any visible damage to the packaging on the delivery invoice.

- **Odor:** A new furniture odor may be present upon unpacking. This is normal and typically dissipates within a few days. Ensure the room is well-ventilated to help the odor clear more quickly.
- **Scratches/Dents:** The finish can be susceptible to scratches and dents. Always handle items carefully when placing them on the bar top or shelves. Use protective pads or felt on the bottom of bottles and glassware.
- **Wobbly Unit:** If the unit feels unstable after assembly, re-check all hardware connections to ensure they are securely tightened. Ensure the unit is placed on a level surface.

## SPECIFICATIONS

<b>Model Number</b>	100175
<b>Dimensions (W x D x H)</b>	60" x 29" x 42"
<b>Material</b>	Poplar Wood, MDF, Birch Veneer
<b>Color</b>	Black, Clear (glass panels)
<b>Number of Drawers</b>	1
<b>Number of Doors</b>	2
<b>Number of Shelves</b>	2 (internal) + 2 (side)
<b>Glassware Capacity</b>	24 (hanging stemware)
<b>Wine Bottle Capacity</b>	6
<b>Assembly Required</b>	Yes (minimal)

## WARRANTY INFORMATION

This Coaster Home Furnishings product comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, abuse, accidents, modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

## CUSTOMER SUPPORT

For assistance with assembly, missing parts, or warranty claims, please contact the retailer where you purchased this product. You may also visit the official Coaster Fine Furniture website for additional support resources.

**Coaster Fine Furniture Store:** [Visit Store](#)