

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Iomega](#) /

› [Iomega ScreenPlay Director 2 TB HD Media Player - 34653 User Manual](#)

Iomega 34653

Iomega ScreenPlay Director HD Media Player User Manual

Model: 34653

1. INTRODUCTION

The Iomega ScreenPlay Director HD Media Player is designed to provide a comprehensive media experience, allowing users to store, access, and enjoy their digital content on a home theater system. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.

This device connects to your home network, enabling access to videos, music, and photo collections. It supports a wide range of media formats and offers online content access.

2. PRODUCT OVERVIEW

Key Benefits

- **Feature Rich:** Enjoy high definition movies on your home theatre; store and access media files on your home network.
- **Convenient:** Browse your home network to select stored media files to enjoy on your HDTV with a touch of the remote; directly access online media sites; connect to your WIFI network (Iomega adapter required).
- **Versatile:** Supports many CODECs and file types including H.264 so you can enjoy your entire media collection; 3 USB ports for multiple connections to external storage, camera, or flash drives; Listen to music while you watch a photo slide show.
- **Large Capacity:** Available in 1TB and 2TB capacities. The 2TB model can save up to 770 hours of video, 800,000 photos, or 500,000 songs (MP3s).
- **Stylish:** Compact enclosure designed to complement your home entertainment environment.

Product Features

The ScreenPlay Director is a multi-functional device serving as a photo viewer, music player, digital storage device, network device, and an internet device for accessing web content on your television.

- Direct access to online content from sites like Flickr and YouTube, and internet feeds such as internet radio, podcasts, or RSS feeds.
- Includes Iomega Protection Suite software (downloadable) for media file backup and computer virus protection.

- Easy-to-use remote for navigation, playlist creation, slideshows, and subtitle viewing.
- DivX® Home Theatre Certified.



Figure 1: The iomega ScreenPlay Director HD Media Player shown with its accompanying remote control. The media player is a black, rectangular device with a vertical control panel on the front, and the remote is also black with various navigation and playback buttons.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- ScreenPlay Director unit
- Remote control
- Power supply

- HDMI cable
- USB cable
- Composite video cable
- Quick Start Guide and Solutions CD (includes FAT32 format utility, ScreenPlay Discovery Tool, Iomega Protection Suite software: Iomega QuikProtect, EMC Retrospect Express HD (PC), EMC Retrospect Express for Mac, MozyHome Online Backup 2GB Free (PC/Mac), Trend Micro® Internet Security (PC))

4. SETUP

4.1 System Requirements

- **PC:** Microsoft® Windows® 2000 Professional, XP Home/XP Professional/XP Professional x64, Windows Vista™, Windows 7
- **Mac:** Mac® OS X 10.4 – 10.6
- Network router or hub recommended (sold separately)

4.2 Connecting the Device

Follow these steps to connect your ScreenPlay Director to your home entertainment system and network:

1. **Power Connection:** Connect the power supply to the ScreenPlay Director and then to a power outlet.
2. **Video Connection:**
 - For High-Definition (HD) output, use the provided HDMI cable to connect the ScreenPlay Director's HDMI port to an HDMI input on your HDTV.
 - Alternatively, for standard definition, use the composite video cable (yellow, red, white) to connect to your TV's corresponding inputs. Component video (Y, Pb, Pr) is also supported for higher quality analog connections.
3. **Audio Connection:**
 - If using HDMI, audio will be transmitted through the HDMI cable.
 - For separate audio, connect the audio R/L (red/white) cables to your TV or audio receiver. An optical audio output is also available for digital audio connections.
4. **Network Connection:**
 - **Wired:** Connect an Ethernet cable from your network router to the Ethernet port on the ScreenPlay Director.
 - **Wireless (Optional):** If you have an Iomega USB Wi-Fi adapter (sold separately), connect it to one of the USB ports on the ScreenPlay Director for wireless network access (supports 802.11b/g/n).
5. **USB Devices:** Use the additional USB ports to connect external storage devices, cameras, or flash drives.



Figure 2: The iomega ScreenPlay Director HD Media Player positioned in a living room environment, demonstrating its integration with a home entertainment setup. The device is shown on a wooden surface with a remote control nearby, and a television screen displaying content is visible in the background, viewed by people.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

Use the provided remote control to navigate the ScreenPlay Director's interface. The directional pad and 'OK' button are central for menu selection and content playback.

5.2 Accessing Stored Media

To play media stored on the device or connected USB drives:

1. Turn on the ScreenPlay Director and your television.
2. Select the correct input source on your television.
3. Navigate to the 'My Files' section using the remote.
4. Browse through folders (Videos, Music, Photos) to locate your desired content.
5. Select a file to begin playback.

5.3 Network Media Access

The ScreenPlay Director can access media files shared on your home network:

1. Ensure the device is connected to your network (wired or wireless).
2. Navigate to the 'Network' section from the main menu.
3. Browse available network shares and select the media you wish to play.

5.4 Online Content

Access pre-installed online content sites and RSS feeds:

1. From the main menu, select the 'Internet' or 'Online Content' option.
2. Choose from pre-configured sites like Flickr or YouTube.
3. You can also add your favorite RSS media feeds.

6. MAINTENANCE

6.1 Cleaning

To clean the device, use a soft, dry cloth. Do not use liquid cleaners or aerosol sprays, as they may damage the unit.

6.2 Firmware Updates

Periodically check the Iomega support website for firmware updates. Updating the firmware can improve performance, add new features, or resolve issues.

6.3 Data Management

Regularly back up important data stored on the ScreenPlay Director to another storage device to prevent data loss. The included Iomega Protection Suite software can assist with backup solutions.

7. TROUBLESHOOTING

Common Issues and Solutions

- **No Power:**

Ensure the power adapter is securely connected to the device and a working power outlet. Check the power indicator light on the unit.

- **No Video Output:**

Verify that the HDMI or composite video cable is correctly connected to both the ScreenPlay Director and your television. Ensure your television is set to the correct input source (e.g., HDMI 1, AV).

- **No Audio Output:**

Check audio cable connections (if not using HDMI). Ensure your TV or audio receiver volume is not muted or too low. Confirm audio settings on the ScreenPlay Director.

- **Cannot Connect to Network:**

For wired connections, ensure the Ethernet cable is properly connected and your router is functioning. For wireless, verify the Iomega USB Wi-Fi adapter is connected and configured correctly. Check network settings on the device.

- **Slow Performance/Freezing:**

If the device is slow or freezes, try restarting it by disconnecting and reconnecting the power. Ensure the device is not overheating. Large media libraries or network traffic can sometimes affect performance.

- **Cannot Play Certain Files:**

Refer to the Specifications section for supported CODECs and file types. Ensure your media files are compatible. Some files may require specific codecs not supported by the device.

If issues persist, consult the full user manual on the Solutions CD or visit the Iomega support website for further assistance.

8. SPECIFICATIONS

Feature	Detail
Capacity	2 TB
Interfaces	10/100 Ethernet, USB 2.0, AV
Wireless Ready	Supports Iomega USB Wi-Fi adapters (802.11b/g/n, adapter sold separately)
Video CODECs	MPEG-1; MPEG-2 (AVI/VOB); MPEG-4 (AVI/DivX®/XViD); H.264; WMV; AVCHD
Audio CODECs	MP3, AC3 (Dolby® Digital Encoding), WAV, OGG, WMA, AAC
Photo Formats	JPEG, BMP, GIF, PNG, TIFF
Resolution	Full 1080p High-Definition (24fps)
File Types	.mkv, .avi, .ASF, .iso, .vob, .mp4, .mov, .wmv, .flv
Standards	NTSC/PAL
AV Connections	HDMI, composite video, audio R/L; component video: Y, Pb, Pr, optical audio
Hard Drive Format	NTFS (default), FAT32
Product Dimensions	5.63 x 7.6 x 8.39 inches
Item Weight	3.71 pounds

9. WARRANTY AND SUPPORT


9.1 Warranty Information

The Iomega ScreenPlay Director comes with a 3-year warranty upon product registration. Please refer to the warranty card included in your package or visit the official Iomega website for detailed terms and conditions.

9.2 Customer Support

For technical support, product registration, or to download the latest drivers and firmware, please visit the official Iomega support website. The Solutions CD also contains helpful tools and documentation.

Note: Contact information for Iomega support may vary by region. Please check the official Iomega website for the most current contact details.

	<p><u>iomega StorCenter px4-300d User Guide</u></p> <p>This user guide provides detailed instructions for setting up, configuring, and managing the iomega StorCenter px4-300d network-attached storage device, covering features like data sharing, cloud integration, security, and remote access.</p>
	<p><u>iomega StorCenter ix2-200 User Guide</u></p> <p>Comprehensive user guide for the iomega StorCenter ix2-200, covering setup, configuration, features, and troubleshooting.</p>
	<p><u>iomega Screenplay HD Replacement Remote Control Button Comparison</u></p> <p>A detailed comparison of buttons between the original iomega Screenplay HD remote control and a compatible replacement, including a comprehensive button mapping guide.</p>
	<p><u>iomega StorCenter ix2-200 Network Storage: Features, Specs, and Ordering</u></p> <p>Discover the iomega StorCenter ix2-200 Network Storage, a versatile solution for content sharing, data backup, and media streaming. Ideal for small offices and home users, it offers advanced features like RAID support, iSCSI, remote access, and compatibility with various operating systems and media devices.</p>
	<p><u>iomega StorCenter ix4-200r Network Storage Array: Product Release Information</u></p> <p>Comprehensive details on the iomega StorCenter ix4-200r Network Storage Array, a powerful NAS solution for small to medium businesses and remote offices, featuring EMC LifeLine software, robust data protection, and extensive connectivity options.</p>
	<p><u>iomega StorCenter ix2 Network Storage: Product Overview and Specifications</u></p> <p>Comprehensive product release information for the iomega StorCenter ix2 Network Storage, a 2-bay NAS device designed for small businesses and home offices. Details features, benefits, specifications, system requirements, and ordering information.</p>