

[Manuals.plus](#) /

› [Hasbro](#) /

› Hasbro FURREAL FRIENDS LUV CUBS Baby Honey Bear Instruction Manual

Hasbro M571

Hasbro FURREAL FRIENDS LUV CUBS Baby Honey Bear Instruction Manual

Model: M571

INTRODUCTION

Welcome to the world of FURREAL FRIENDS LUV CUBS! Your new Baby Honey Bear is an interactive plush toy designed to provide companionship and engaging play. This cuddly bear responds to interaction with giggling sounds, peek-a-boo play, and even gives hugs. It comes with a bottle accessory for feeding.



Image: The Baby Honey Bear in its original packaging, showcasing its soft fur and the included feeding bottle. A small girl is pictured on the packaging interacting with the bear.

SETUP AND BATTERY INSTALLATION

Your Baby Honey Bear requires batteries for operation. Please follow these steps for proper installation:

1. Locate the battery compartment on the back or underside of the bear. This is typically secured with a small screw.
2. Using a Phillips head screwdriver, carefully open the battery compartment cover.
3. Insert **3 x 1.5V AA (LR6) batteries**, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.
5. Turn the bear's power switch to the "ON" position. The power switch is usually located near the battery compartment.

Note: Batteries are included with the product. If the bear does not respond, ensure batteries are fresh and correctly installed.

OPERATING INSTRUCTIONS

Interact with your Baby Honey Bear to activate its various features:

- **Feeding:** Place the included bottle accessory into the bear's mouth. The bear will make sucking sounds and may lift its arms as if holding the bottle.
- **Giggling:** Gently squeeze or tickle the bear's tummy or paws to hear it giggle.
- **Peek-a-boo:** Cover the bear's eyes and then uncover them to initiate a peek-a-boo response.
- **Hugging:** Give the bear a hug, and it will hug you back, demonstrating its affection.
- **"Try Me" Mode:** The bear may initially be in a "Try Me" mode for demonstration. To fully activate all features, ensure the power switch is set to "ON" and not "Try Me" (if applicable).

Experiment with different interactions to discover all the bear's responses.

MAINTENANCE AND CARE

To ensure the longevity of your Baby Honey Bear, follow these care instructions:

- **Cleaning:** Surface wash only. Use a damp cloth with mild soap to clean soiled areas. Do not immerse the bear in water, as this can damage the electronic components.
- **Drying:** Allow the bear to air dry completely after cleaning. Do not use a machine dryer.
- **Storage:** Store the bear in a clean, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent battery leakage and corrosion.

TROUBLESHOOTING

Problem	Solution
Bear does not respond or makes weak sounds.	• Check if the power switch is in the "ON" position. • Replace the batteries with fresh 1.5V AA (LR6) batteries. • Ensure batteries are inserted with correct polarity.
Bear's movements are sluggish.	This often indicates low battery power. Replace all batteries with new ones.
Bear does not hug back.	Ensure you are hugging the bear firmly enough to activate the internal sensor. Check batteries.

SPECIFICATIONS

- **Brand:** Hasbro
- **Model Name:** Honey Bear
- **Model Number:** M571 (244750000)
- **Toy Figure Type:** Stuffed Toy
- **Character:** Bear
- **Material Type:** Plush Fabric, Cotton Plush
- **Color:** Brown
- **Item Weight:** 2 pounds
- **Item Dimensions:** 7.56 x 10.91 x 11.06 inches

- **Batteries Required:** 3 x 1.5V AA (LR6) batteries (included)
- **Manufacturer Minimum Age:** 48 months (4 years)

SAFETY INFORMATION

Please read and retain this information for future reference. Adult supervision is recommended.

- **Battery Safety:**
 - Do not mix old and new batteries.
 - Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
 - Only batteries of the same or equivalent type as recommended are to be used.
 - Batteries are to be inserted with the correct polarity.
 - Exhausted batteries are to be removed from the toy.
 - The supply terminals are not to be short-circuited.
 - Non-rechargeable batteries are not to be recharged.
 - Rechargeable batteries are only to be charged under adult supervision.
 - Rechargeable batteries are to be removed from the toy before being charged.
- **Choking Hazard:** Small parts may be generated. Not for children under 3 years. The manufacturer minimum age is 4 years (48 months).
- **General Use:** Do not throw, hit, or intentionally damage the toy. Keep away from open flames and excessive heat.

WARRANTY AND SUPPORT

Hasbro products are manufactured to high-quality standards. For any questions regarding your FURREAL FRIENDS LUV CUBS Baby Honey Bear, please refer to the contact information provided on the product packaging or visit the official Hasbro website for customer support.

Specific warranty details may vary by region. Please retain your proof of purchase for any warranty claims.

© 2023 Hasbro. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question