

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Ford](#) /

› 2008 Ford E-Series Owner's Manual

Ford E-Series

2008 Ford E-Series Owner's Manual

Your comprehensive guide to operating and maintaining your vehicle.

INTRODUCTION

This owner's manual provides detailed information about your 2008 Ford E-Series vehicle. It covers essential topics such as vehicle operation, safety features, maintenance schedules, and troubleshooting tips. Familiarizing yourself with this manual will help ensure safe and efficient use of your vehicle.

Please keep this manual in your vehicle for quick reference. For specific details not covered here, refer to the full printed manual or contact an authorized Ford service center.



Image: Front cover of the 2008 Ford E-Series Owner's Guide, displaying the Ford logo and vehicle series name.

Safety Information

Your safety and the safety of your passengers are paramount. This section highlights critical safety advice and guidelines for operating your Ford E-Series.

Seat Belts and Child Safety

Always ensure all occupants wear their seat belts correctly. Adjust the shoulder belt height for optimal fit. For children, use appropriate child restraints based on their age, weight, and height. Refer to the child restraint manufacturer's instructions and your vehicle's manual for proper installation.



Image: A page titled 'Safety Advice' from the manual, illustrating proper seat belt usage, child restraint types (rear-facing infant seat, forward-facing child seat, booster seat), and LATCH anchor locations for child safety seats.

Quick Reference Safety Guide

For quick access to essential safety tips, consult the Van and Wagon Quick Reference Safety Guide. This guide provides supplemental safety information for driving a passenger van and wagon, emphasizing the importance of following safety guidelines to protect yourself and your passengers.




Image: A quick reference card titled 'VAN AND WAGON QUICK REFERENCE SAFETY GUIDE', providing supplemental safety tips

VEHICLE OPERATION

This section covers the fundamental aspects of operating your 2008 Ford E-Series. It includes information on starting and stopping the engine, using the transmission, understanding dashboard indicators, and operating various controls such as lights, wipers, and climate control. Always refer to the specific pages in your full owner's manual for detailed instructions on each feature.

- **Starting and Stopping:** Procedures for ignition and engine shutdown.
- **Transmission:** How to use the automatic or manual transmission, including parking and driving modes.
- **Dashboard Indicators:** Explanation of warning lights and gauges.
- **Controls:** Operation of steering wheel controls, power windows, mirrors, and other interior features.

SCHEDULED MAINTENANCE

Regular maintenance is crucial for the longevity and performance of your Ford E-Series. The Scheduled Maintenance Guide outlines recommended service intervals and procedures to keep your vehicle in optimal condition.

- **Oil Changes:** Recommended frequency and type of oil.
- **Fluid Checks:** Brake fluid, coolant, power steering fluid, and windshield washer fluid.
- **Tire Rotation:** Guidelines for extending tire life.
- **Filter Replacement:** Air filter, cabin air filter, and fuel filter.
- **Inspections:** Brake system, suspension, exhaust system, and belts.




Image: Front cover of the 2008 Ford Scheduled Maintenance Guide, a blue booklet detailing recommended service intervals.

TIRE CARE AND WARRANTY

Proper tire maintenance is essential for safety, fuel efficiency, and tire longevity. This section provides information on tire pressure, rotation, and the tire warranty.

- **Tire Pressure:** Check regularly, especially before long trips.
- **Tire Rotation:** Follow recommended schedules to ensure even wear.
- **Tire Inspection:** Look for signs of wear, damage, or punctures.

The Tire Warranty Guide provides specific details regarding coverage for your vehicle's tires. It outlines the terms and conditions for tire defects and wear.




Image: Front cover of the Ford Tire Warranty Guide, a light blue booklet with a stylized tire tread design.

WARRANTY INFORMATION

Your 2008 Ford E-Series comes with a comprehensive warranty. The Warranty Guide provides full details on coverage for various components, including powertrain, bumper-to-bumper, and corrosion. It also specifies the duration and conditions of these warranties.

- **Basic Warranty:** Coverage for most vehicle components.
- **Powertrain Warranty:** Specific coverage for engine, transmission, and drive systems.
- **Corrosion Warranty:** Protection against rust-through.
- **Emissions Warranty:** Coverage for emissions-related components.




Image: Front cover of the 2008 model year Warranty Guide for Ford Cars and Light Trucks, excluding Escape Hybrid Vehicles.

ROADSIDE ASSISTANCE & QUICK TIPS

Ford provides roadside assistance for unexpected situations. This service can help with flat tires, dead batteries, lock-outs, and fuel delivery. Keep your vehicle's information handy when calling for assistance.

- **Flat Tires:** Assistance for tire changes or towing.

- **Dead Batteries:** Jump-start service.
- **Lock-Outs:** Help to regain access to your vehicle.
- **Fuel Delivery:** Emergency fuel supply if you run out.
- **Towing:** If your vehicle is inoperable.

For complimentary help, call **1-800-241-3673** in the U.S. or **1-800-241-3673** in Canada. Have your VIN, vehicle's mileage, and location ready.

ROADSIDE ASSISTANCE FOR COMPLIMENTARY HELP CALL 1-800-241-3673 Quick access to the information below will get help to you faster. Know your vehicle's mileage and specific location.	NAME _____ CAR PHONE # _____ KEY CODE # _____ VIN# _____ LICENSE PLATE # _____	*Free Roadside Assistance is provided throughout the bumper-to-bumper limited warranty period * Service provided by Ford Auto Club. * If traveling in Canada, please call 1-800-348-5250.	ROADSIDE ASSISTANCE FOR COMPLIMENTARY HELP CALL 1-800-241-3673 Quick access to the information below will get help to you faster. Know your vehicle's mileage and specific location.	NAME _____ CAR PHONE # _____ KEY CODE # _____ VIN# _____ LICENSE PLATE # _____	*Free Roadside Assistance is provided throughout the bumper-to-bumper limited warranty period * Service provided by Ford Auto Club. * If traveling in Canada, please call 1-800-348-5250.	Ford Motor Company reserves the right to modify or discontinue Roadside Assistance at any time. Certain restrictions apply to Roadside Assistance benefits. Call 1-800-241-3673 for further details.
						
FLAT TIRES	DEAD BATTERIES	LOCK OUTS	WARRANTY, NON-WARRANTY AND COLLISION TOWS	FUEL DELIVERY	TRAILERS	
It does seem that today nobody gets a flat tire, but what if you did? Not to worry. Roadside Assistance will be there to change your tire for you. Tire change service requires the customer to have a useable spare tire.	Ah, Even a good battery can go dead for one reason or another. Just give us a call. Roadside Assistance will give your vehicle the jump-start it needs.	It's embarrassing, but it happens. Those kids "accidentally" hit the button. That attendant left the key inside. Just call us. We'll get you back in, fast...and it's free. Key replacement cost is customer responsibility.	Your car's not working...and you don't know why. Do you still get a tow for free? Of course you do. This is Roadside Assistance. Just make the call and we'll be there. * Warranty Towing * Non-warranty Towing * Collision Towing	You ran out of gas with no fuel station in sight. No problem. Make the call and we'll bring the gas to you. FREE. Limited to 2 (two) no charge occurrences within a 12 month period.	If your vehicle requires towing while hauling a trailer, Roadside Assistance provides coverage for towing your trailer up to \$200 per event.	

Image: A card detailing Roadside Assistance contact information and quick tips for common issues like flat tires, dead batteries, lock-

outs, fuel delivery, and trailer towing.

SPECIFICATIONS

Key specifications for the 2008 Ford E-Series Owner's Manual document:

Specification	Value
ASIN	B003IQBJUS
Language	English

ADDITIONAL RESOURCES AND SUPPORT

For further assistance or detailed information, please refer to the official Ford website or contact a certified Ford dealership.

- **Official Ford Website:** www.ford.com
- **Locate a Dealer:** Find your nearest authorized Ford service center for professional maintenance and repairs.
- **Customer Service:** Contact Ford customer service for any inquiries regarding your vehicle.

© 2007 Ford Motor Company. All rights reserved. Information subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B003IQBJUS>

More documents and user manuals: <https://manuals.plus/>