

[Manuals.plus](#) /

› [Hasbro](#) /

› Hasbro Star Wars 2010 Saga Legends Action Figure SL No. 02 IG-88 Instruction Manual

Hasbro 21391

Hasbro Star Wars 2010 Saga Legends Action Figure SL No. 02 IG-88 Instruction Manual

Model: 21391

INTRODUCTION

This manual provides essential information for the assembly, operation, and care of your Hasbro Star Wars 2010 Saga Legends IG-88 action figure. Please read these instructions carefully to ensure proper handling and to maximize your enjoyment of this product.

PRODUCT OVERVIEW

The IG-88 action figure is part of the Star Wars 2010 Saga Legends series. This highly detailed figure represents the assassin droid IG-88, known for its role as a bounty hunter. The figure is designed for collectors and enthusiasts aged 4 and up.

- **Figure Scale:** 3 3/4 inches tall.
- **Series Number:** SL02 in the 2010 Saga Legends line.
- **Included Accessories:** Secret weapons, Galactic Battle Game card, die, and base.



Figure 1: IG-88 action figure displayed in its original blister packaging, showcasing the character, accessories, and Galactic Battle Game card.

SETUP AND ASSEMBLY

Your IG-88 action figure comes with several accessories that can be attached to enhance its display and playability.

1. **Unpackaging:** Carefully remove the figure and all accessories from the packaging. Retain the packaging for future reference if desired.
2. **Attaching Weapons:** IG-88 includes multiple "secret weapons." Identify the various blaster rifles and the machete-like accessory. These can be placed into the figure's hands or attached to designated slots on its back or side, depending on the accessory design. Ensure a snug fit without forcing.
3. **Using the Display Base:** The figure includes a display base. Align the pegs on the base with the holes on the figure's feet and gently press down until the figure is securely standing.
4. **Galactic Battle Game Components:** The included Galactic Battle Game card, die, and base are separate components for the game. Refer to the game instructions (not included in this manual) for their use.




Figure 2: The IG-88 figure fully assembled with its various weapons and standing on its gray display base.



Figure 3: A detailed view of the various blaster rifles and other weapon accessories included with the IG-88 figure.

OPERATING AND POSING

The IG-88 action figure features multiple points of articulation, allowing for various poses.

- **Articulation Points:** The figure typically has articulation at the neck, shoulders, elbows, hips, and knees. Gently move these joints to achieve desired poses.

- **Posing with Weapons:** Once weapons are attached, adjust the figure's arms and hands to hold them in dynamic action stances.
- **Stability:** When posing, ensure the figure's weight is balanced, especially if not using the display base, to prevent it from falling.

MAINTENANCE AND CARE

Proper care will help preserve the condition of your action figure.

- **Cleaning:** To clean the figure, gently wipe it with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure away from direct sunlight, extreme temperatures, and high humidity to prevent discoloration or material degradation. Keep it in a dust-free environment.
- **Handling:** Avoid excessive force when posing or attaching accessories, as this may damage the joints or plastic components.

TROUBLESHOOTING

If you encounter any issues with your IG-88 action figure, consider the following:

- **Loose Joints:** Over time, joints may become slightly loose. This is common with articulated figures. Gentle manipulation can sometimes restore some tightness.
- **Difficulty Attaching Accessories:** Ensure accessories are aligned correctly with the designated slots or hands. Do not force them. If a part seems too tight, try gently wiggling it into place.
- **Missing Parts:** If any parts were missing upon purchase, refer to the warranty and support section.

SPECIFICATIONS

Product Dimensions	5.12 x 1.57 x 5.51 inches
Item Weight	2.43 ounces
Item Model Number	21391
Manufacturer Recommended Age	3 years and up
Brand	Hasbro

SAFETY INFORMATION

Please observe the following safety guidelines:

- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years of age.
- **Recommended Age:** This action figure is recommended for ages 4 and up.
- **Adult Supervision:** Adult supervision is recommended for younger children during play.

WARRANTY AND SUPPORT

For information regarding product warranty or customer support, please contact Hasbro customer service directly. Details can typically be found on the product packaging or on the official Hasbro website. Please have your model

number (21391) and purchase information available when contacting support.
You can visit the official Hasbro store for more information: [Hasbro Toyland Store](#)