

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [OXO](#) /
- > [OXO Good Grips Locking Can Opener with Lid Catch Instruction Manual](#)

OXO 1101780

OXO Good Grips Locking Can Opener with Lid Catch Instruction Manual

Model: 1101780

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your OXO Good Grips Locking Can Opener with Lid Catch. Please read these instructions thoroughly before first use and retain for future reference.

PRODUCT OVERVIEW





Figure 1: OXO Good Grips Locking Can Opener with Lid Catch.

The OXO Good Grips Locking Can Opener is designed for effortless can opening. It features a locking mechanism to secure it onto can edges, a comfortable knob and handle, a sharp stainless steel cutting wheel, a viewing window for alignment, and a magnetic lid catch for easy disposal.

**7.0 in/
17.7 cm**



4.0 in/ 10.1 cm

Figure 2: Product dimensions (approximately 7 inches high by 4 inches wide).

The can opener measures approximately 7 inches in height and 4 inches in width, providing a compact yet ergonomic design for comfortable handling.

SETUP

The OXO Good Grips Locking Can Opener requires no assembly. Before first use, wash the can opener with warm, soapy water and rinse thoroughly. Dry completely before storage.

OPERATING INSTRUCTIONS

1. **Positioning the Opener:** Hold the can opener with the cutting wheel positioned on the rim of the can. Ensure the thumb lock is released.



Figure 3: Place the cutting wheel on the can's rim.

The opener features a comfortable, non-slip knob and handle for a secure grip during operation.

2. **Locking Mechanism:** Squeeze the handles together to clamp the opener firmly onto the can's edge. The locking mechanism will engage, holding the opener in place without continuous squeezing.
3. **Cutting the Lid:** Turn the large, comfortable knob clockwise. The sharp, stainless steel wheel will cut cleanly through the can lid. A clear window allows for precise alignment and helps confirm a full rotation.



Figure 4: The cutting window aids in precise positioning and tracking the cut.

4. **Lid Removal:** Once the can is fully opened, release the thumb lock and press the button to disengage the opener from the can. The integrated magnetic catch will hold the cut lid, preventing it from falling into the can's contents.



Figure 5: The magnetic catch secures the lid for safe disposal.

The magnetic lid catch simplifies cleanup by holding the lid securely after cutting.

5. **Disposal:** Carefully remove the lid from the magnetic catch and dispose of it properly.

MAINTENANCE AND CARE

- **Cleaning:** Hand wash the can opener with warm, soapy water immediately after each use.
- **Drying:** Rinse thoroughly and dry completely to prevent rust on the stainless steel components.
- **Storage:** Store in a dry place.
- **Do Not Dishwash:** This product is not suitable for dishwasher cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Can opener does not lock onto the can.	The can opener may not be properly aligned with the can's rim, or the handles are not squeezed sufficiently.	Ensure the cutting wheel is directly on the can's rim. Squeeze the handles firmly until the locking mechanism engages.
Can opener skips or does not cut smoothly.	Improper alignment, dull cutting wheel, or debris on the wheel.	Re-align the opener. Clean the cutting wheel thoroughly. If the wheel is dull after extended use, consider replacing the unit.
Lid falls into the can after opening.	The magnetic lid catch may be obstructed or not properly engaging.	Ensure the magnetic catch area is clean. Verify the lid is fully cut before releasing the opener.

SPECIFICATIONS

- **Model Number:** 1101780
- **Brand:** OXO
- **Material:** Stainless Steel (blade), Plastic/Rubber (handle)
- **Color:** Black
- **Product Dimensions:** Approximately 4"W x 7"H
- **Item Weight:** 6.4 ounces
- **Operation Mode:** Manual
- **UPC:** 719812030173

WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to view additional product videos, please visit the official OXO website or contact their customer service department.

[Visit the OXO Store on Amazon](#)



© 2023 OXO. All rights reserved.

Related Documents - 1101780

	<p>OXO Good Grips Mandoline Slicer: User Manual & Slicing Instructions</p> <p>Comprehensive user manual for the OXO Good Grips Mandoline Slicer, covering components, disassembly, cleaning, reassembly, storage, and detailed slicing instructions for various cuts like straight, crinkle, waffle, and julienne.</p>
---	--



[OXO Good Grips Vegetable Chopper: Preparation, Use, and Cleaning Guide](#)

Learn how to prepare, use, and clean your OXO Good Grips Vegetable Chopper. Includes safety warnings and care instructions for this kitchen tool.


[OXO Good Grips Triple Timer - Better Guarantee](#)

Information about the OXO Good Grips Triple Timer, including its Better Guarantee and contact details for OXO.



[OXO Good Grips Chef's Digital Leave-In Thermometer User Manual & Guide](#)

Comprehensive user manual and product guide for the OXO Good Grips Chef's Digital Leave-In Thermometer. Learn about cleaning, storage, activation, programming temperature settings, using the timer, and product specifications.



[OXO Good Grips Stainless Steel Scale Instruction Manual](#)

This document provides instructions for using the OXO Good Grips Stainless Steel Scale, including zeroing, adding and weighing operations, interface features, and care instructions.



[OXO Good Grips Cold Brew Coffee Maker: User Guide and Tips](#)

Learn how to make smooth, low-acid cold brew coffee and tea with the OXO Good Grips Cold Brew Coffee Maker. This guide covers setup, brewing, dilution, care, and tips.