



[Manuals.plus](#) /

> [VIZIO](#) /

> VIZIO M260VA 26-Inch Class RazorLED 720p LCD HDTV User Manual

VIZIO M260VA

VIZIO M260VA 26-Inch Class RazorLED 720p LCD HDTV User Manual

Model: M260VA

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your VIZIO M260VA 26-Inch Class RazorLED 720p LCD HDTV. Please read this manual thoroughly before using your television to ensure proper and safe operation. Keep this manual for future reference.



Image: Front view of the VIZIO M260VA 26-Inch Class RazorLED 720p LCD HDTV. The television features a slim black bezel and a stand, displaying a vibrant image on its screen.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electronic devices to reduce the risk of fire, electric shock, and injury. This includes:

- Do not expose the television to rain or moisture.
- Do not block ventilation openings.
- Do not place the television near heat sources.
- Use only attachments/accessories specified by the manufacturer.
- Unplug the television during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

PACKAGE CONTENTS

Verify that your package contains the following items:

- VIZIO M260VA 26-Inch Class RazorLED 720p LCD HDTV
- Remote Control
- Power Cord
- TV Stand (and screws for assembly)
- Quick Start Guide (not included in this digital manual)

SETUP

1. Unpacking

Carefully remove the television and all accessories from the packaging. Retain the packaging for future transport or if servicing is required.

2. Attaching the Stand

If you are placing the TV on a table or entertainment center, you will need to attach the included stand. Follow the instructions provided with the stand for secure attachment. Ensure all screws are tightened properly.

3. Wall Mounting (Optional)

The VIZIO M260VA supports VESA standard wall mounts with a 200 x 100 mm pattern. If wall mounting, ensure you use a compatible wall mount kit (sold separately) and follow the mounting kit's instructions carefully. Professional installation is recommended for wall mounting.

4. Connecting Devices

Connect your external devices to the television using the available ports. Ensure the TV is unplugged before making any connections.

- **HDMI:** For high-definition video and audio from devices like Blu-ray players, cable/satellite boxes, or gaming consoles. The TV has 1 HDMI port.
- **USB:** For connecting USB storage devices to view photos or play compatible media files. The TV has 1 USB port.
- **Antenna/Cable (Coaxial):** For connecting an antenna for over-the-air broadcasts or a cable TV connection.
- **Component Video:** For high-quality analog video connections.
- **Composite Video:** For standard definition analog video connections.
- **Audio Out:** For connecting to external audio systems.

5. Initial Power On

After connecting all devices, plug the power cord into the TV and then into a wall outlet. Press the power button on the TV or the remote control. The TV will guide you through the initial setup process, including language selection and channel scanning.

OPERATING INSTRUCTIONS

1. Remote Control Overview

The included remote control allows you to access all TV functions. Familiarize yourself with the button layout for easy navigation.

- **Power:** Turns the TV on or off.
- **Input:** Cycles through available input sources (HDMI, USB, TV, etc.).
- **Volume Up/Down:** Adjusts the audio level.
- **Channel Up/Down:** Changes TV channels.
- **Menu:** Opens the on-screen display (OSD) menu for settings adjustments.

- **Navigation Buttons (Arrows/OK):** Used to navigate menus and confirm selections.
- **Exit:** Closes the current menu or on-screen display.

2. Input Selection

To switch between connected devices, press the **Input** button on your remote control. A list of available inputs will appear on the screen. Use the navigation buttons to select your desired source and press **OK**.

3. Picture Settings

Access the Picture menu to adjust settings for optimal viewing. Your VIZIO M260VA features Razor LED lighting for brilliant color and contrast, and a 720p HD resolution display.

- **Picture Mode:** Select from preset modes like Standard, Vivid, Movie, or Game.
- **Brightness:** Adjusts the overall lightness or darkness of the image.
- **Contrast:** Controls the difference between the brightest and darkest parts of the image.
- **Color:** Adjusts the intensity of colors.
- **Tint:** Fine-tunes the color balance (red-green).
- **Sharpness:** Enhances the edge definition of objects in the picture.
- **Advanced Picture Settings:** Includes options like Color Temperature, Noise Reduction, and the Ambient Light Sensing technology, which automatically adjusts picture settings based on room lighting conditions to optimize viewing and save energy.

4. Sound Settings

Access the Audio menu to customize sound output. The TV features SRS TruVolume and SRS TruSurround HD audio for advanced virtual surround sound.

- **Sound Mode:** Choose from presets like Standard, Music, Movie, or Speech.
- **Bass/Treble:** Adjust low and high-frequency audio levels.
- **Balance:** Adjusts the volume between left and right speakers.
- **SRS TruVolume:** Maintains consistent volume levels, preventing sudden increases during commercials.
- **SRS TruSurround HD:** Enhances the audio experience by creating a virtual surround sound effect from the built-in speakers.

5. Internet Applications (Via External Devices)

While the VIZIO M260VA supports internet services like Amazon Instant Video, Netflix, and YouTube, these are typically accessed through external streaming devices (e.g., a smart Blu-ray player, streaming stick, or game console) connected to the TV's HDMI ports. The TV itself does not have built-in smart TV functionality for these applications.

MAINTENANCE

1. Cleaning the Screen

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner. Never spray liquid directly onto the screen.

2. General Care

Wipe the cabinet and stand with a soft, dry cloth. Avoid using abrasive cleaners or solvents. Ensure the TV's ventilation openings are clear of dust and obstructions to prevent overheating.

3. Energy Saving

Your VIZIO M260VA is designed to be energy efficient, exceeding Energy Star 4.0 guidelines. Utilize the Ambient Light Sensing

technology to automatically adjust brightness based on room conditions. The TV also features a High Efficiency Standby Power Shutoff to minimize power consumption when not in use.

TROUBLESHOOTING

If you encounter issues with your television, refer to the following common problems and solutions:

Problem	Possible Solution
No Power	Ensure the power cord is securely plugged into both the TV and a working electrical outlet. Check if the outlet has power. Try pressing the power button on the TV itself, not just the remote.
No Picture, But Sound is Present	Verify the correct input source is selected. Check all video cable connections (HDMI, component, etc.) between the TV and the source device. Try a different input port or cable.
No Sound, But Picture is Present	Check the volume level and ensure the TV is not muted. Verify audio cable connections. If using an external audio system, ensure it is powered on and correctly configured. Check sound settings in the TV menu.
Remote Control Not Working	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor. Point the remote directly at the TV.
Poor Picture Quality	Check the source device's output resolution. Adjust picture settings (brightness, contrast, sharpness) in the TV menu. Ensure antenna or cable connections are secure and free from interference.

If the problem persists after trying these solutions, please contact VIZIO customer support.

SPECIFICATIONS

Feature	Detail
Model Name	VIZIO M260VA
Screen Size	26 Inches
Display Technology	LED (Razor LED lighting)
Resolution	720p
Refresh Rate	60 Hz
Aspect Ratio	16:9
Response Time	8 Milliseconds
Connectivity Technology	HDMI, USB
Total Number of HDMI Ports	1
Total USB Ports	1
Audio Output Mode	Surround (SRS TruSurround HD)
Speaker Description	Built-in speakers with virtual surround sound
Special Features	Flat, Ambient Light Sensing technology, High Efficiency Standby Power Shutoff

Feature	Detail
Mounting Type	Table Mount
VESA Mount Standard	200 x 100 mm
Color	Black
Model Year	2010
Energy Efficiency	Exceeds Energy Star 4.0 guidelines
Line Voltage	220 VAC 50 Hz

WARRANTY AND SUPPORT

Limited Warranty

Your VIZIO M260VA television comes with a limited warranty. Please refer to the warranty card included with your product or visit the official VIZIO website for detailed terms and conditions regarding coverage, duration, and limitations.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact VIZIO customer support. You can typically find contact information (phone numbers, email, or support website) on the VIZIO official website or in your product's original documentation.

When contacting support, please have your TV's model number (M260VA) and serial number ready. The serial number is usually located on a sticker on the back of the television.