Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Invicta 6986

Invicta Men's Pro Diver Watch - Instruction Manual

Model: 6986

1. Introduction and Overview

This manual provides essential information for the proper use, care, and maintenance of your Invicta Men's Pro Diver Stainless Steel Quartz Watch, Model 6986. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.



Front view of the Invicta Men's Pro Diver Stainless Steel Quartz Watch, Model 6986, featuring a black dial and black stainless steel case.

2. Safety Precautions

Please observe the following safety guidelines to prevent injury or damage to the watch:

- **Battery Ingestion Hazard:** This product contains a button cell or coin battery. Ingestion can cause severe internal chemical burns in as little as two hours, leading to serious injury or death. Keep new and used batteries out of reach of children. If a battery is suspected to be swallowed or inserted into any part of the body, seek immediate medical attention.
- **Battery Disposal:** Do not dispose of batteries in household trash or incinerate them. Remove and immediately recycle or dispose of used batteries according to local regulations.
- **Professional Service:** This product is intended to be opened only by qualified professionals for service or battery replacement.
- **Magnetic Fields:** Avoid storing the watch near strong magnetic fields, as this can affect the accuracy of the quartz movement.
- **Temperature Extremes:** Do not expose the watch to extreme temperatures (very hot or very cold) or rapid temperature changes, as this can damage internal components and seals.



The Invicta watch is typically packaged in a yellow box, which may contain important safety information.

3. Product Features and Components

The Invicta Pro Diver Model 6986 is designed for durability and precision. Key features include:

- **Case:** Black stainless steel case with a 48mm diameter and 16.5mm thickness.
- **Dial:** Black dial with luminous hands and hour markers for visibility in low light conditions.
- **Movement:** Reliable Japanese quartz movement (VD53 Caliber), assembled in Japan. Includes an SR920SW battery.
- **Band:** Black stainless steel and black silicone band, 220mm in length and 26mm in width, secured with a buckle clasp.
- **Crystal:** Flame Fusion crystal, offering extra scratch resistance for enhanced protection and durability.
- **Crown:** Push/pull crown for setting time and date, designed for a water-tight seal.
- **Bezel:** Uni-directional rotating stainless steel bezel with a black top ring, useful for tracking elapsed time.
- **Subdials:** Functional subdials for 60-minute, 60-second, and 24-hour measurements, providing precise timekeeping and chronograph capabilities.
- **Water Resistance:** Rated for 100 meters (330 feet), suitable for recreational surfing, swimming, snorkeling, sailing, and water sports. *Not suitable for diving.*

Visual breakdown of key components and features of the Invicta 6986 watch, including the crown, bezel, case size, and crystal type.

Details of the watch bracelet, highlighting the buckle clasp for easy adjustment and the premium silicone band for comfort.

Explanation of the watch's movement, including timekeeping subdials and the date display feature.

4. Setup and Initial Use

4.1 Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to the outermost position.
2. **Set the time:** Rotate the crown to move the hour and minute hands to the correct time. Ensure to account for AM/PM if your watch has a 24-hour subdial or date change mechanism.
3. **Set the date:** If your watch has a date display, push the crown in one click from the outermost position (to the middle position). Rotate the crown to adjust the date. If the date changes at noon, you may need to advance the time by 12 hours.
4. **Push in the crown:** Once the time and date are set, push the crown back into its original position to secure the settings and maintain water resistance.

4.2 Adjusting the Band

The black stainless steel and silicone band can be adjusted for a comfortable fit. For significant adjustments, such as removing links from the stainless steel section, professional assistance is recommended to avoid damaging the band or watch.




55
05
15
25
35
45
invicta

The Invicta Pro Diver watch worn on a wrist, showcasing its size and fit.

5. Operating Instructions

5.1 Chronograph Function

Your watch features a chronograph for measuring elapsed time. The subdials typically indicate 60 seconds, 60 minutes, and 24 hours. Refer to the specific markings on your watch's dial for precise subdial functions.

1. **Start:** Press the top pusher button to start the chronograph.
2. **Stop/Pause:** Press the top pusher button again to stop or pause the chronograph.
3. **Reset:** While the chronograph is stopped, press the bottom pusher button to reset all chronograph hands to zero.

5.2 Water Resistance Guidelines

The Invicta Pro Diver 6986 is water resistant to 100 meters (330 feet). This rating indicates suitability for:

- Recreational surfing
- Swimming
- Snorkeling
- Sailing
- Water sports

Important: This watch is NOT suitable for diving. Do not operate the crown or pushers while the watch is wet or submerged, as this can compromise the water resistance.



A visual guide to water resistance ratings, indicating suitable activities for different depths. The Invicta Pro Diver 6986 is rated for 100M.

6. Maintenance and Care

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth to remove dust and smudges. For the silicone band, a damp cloth with mild soap can be used, followed by thorough drying.
- **Avoid Chemicals:** Do not expose the watch to harsh chemicals, solvents, or detergents, as these can damage the case, band, or seals.
- **Impact Protection:** Avoid dropping the watch or subjecting it to strong impacts, which can damage the internal movement or crystal.
- **Battery Replacement:** When the battery needs replacement, it is recommended to have it done by a qualified watch technician to ensure proper sealing and water resistance.

7. Troubleshooting

Problem	Possible Cause	Solution
Watch not running	Depleted battery	Replace battery (professional service recommended).
Time is inaccurate	Exposure to strong magnetic fields	Demagnetize the watch (professional service recommended).
Condensation under crystal	Compromised water resistance seal	Seek immediate professional service to prevent further damage.

8. Specifications

- **Model Number:** 6986
- **Case Diameter:** 48mm
- **Case Thickness:** 16.5mm
- **Movement:** Japanese Quartz, VD53 Caliber
- **Crystal Type:** Flame Fusion
- **Band Material:** Stainless Steel and Silicone
- **Band Length:** 220mm
- **Band Width:** 26mm
- **Watch Weight:** 190 grams
- **Water Resistance:** 100 meters (330 feet)
- **Manufacturer:** Invicta
- **Country of Origin:** Switzerland

9. Warranty and Support

Invicta watches typically come with a manufacturer's warranty. For detailed warranty information and to register your watch for an extended warranty, please visit the official Invicta service website:

Register Your Watch for Extended Warranty

A comprehensive user guide in PDF format is also available for download:

Download User Guide (PDF)

9.1 Official Product Video

Your browser does not support the video tag.

This video provides a 360-degree view of the Invicta Men's Pro Diver watch, showcasing its design and features from all angles.

© 2025 Invicta. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B003MYR658

More documents and user manuals: **https://manuals.plus/**