

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Gewa](#) /

› [GEWA Concerto Shaped Violin Case \(1/8 Size\) Instruction Manual](#)

Gewa **Gewa**

GEWA Concerto Shaped Violin Case (1/8 Size) Instruction Manual

Model: Gewa

Brand: GEWA

1. PRODUCT OVERVIEW

The GEWA Concerto Shaped Violin Case is designed to provide secure and insulated transport for your 1/8 size violin. Manufactured in Germany, this case features a unique thermoplastic shell for durability and superior insulation. Its lightweight yet robust construction ensures optimal protection for your instrument.



Figure 1: The GEWA Concerto Shaped Violin Case in its closed position, showcasing the black tex exterior and integrated handle.

Key Features:

- **Manufactured in Germany:** Ensures high-quality construction.
- **Unique Thermoplastic Shell:** Engineered for durability and impact resistance.
- **Superior Insulation:** Maintains optimal temperature for instrument protection.

- **Lightweight Design:** Approximately 3.7 lbs (without accessories) for easy transport.
- **Cushioned Suspension System:** Protects the violin from shocks during transit.
- **GEWA Patented Swivel and Flexible Bow Holder:** Securely holds bows.
- **Detachable Accessory Pocket:** Provides storage for small items.
- **Comfortable Carrying:** Includes two detachable neoprene rucksack straps.
- **Luxurious Interior:** Black velour lining with a protective blanket.
- **Combination Lock:** Enhances security.
- **Attached Sheet Music Pocket:** Convenient storage for music sheets.
- **Water-Resistant Cover:** Provides protection against moisture.

2. SETUP AND INITIAL USE

2.1 Unpacking and Contents

Carefully unpack the violin case from its packaging. Inspect the case for any signs of damage. The package should contain the following items:

- GEWA Concerto Shaped Violin Case
- Swivel type holder (integrated)
- Bow holder (integrated)
- Detachable accessory pocket
- 2 detachable neoprene rucksack straps
- Protection blanket
- Address card compartment (integrated)

2.2 Attaching Rucksack Straps

The case comes with two detachable neoprene rucksack straps for comfortable carrying. Locate the D-rings on the back and sides of the case. Attach the clips of the straps to these D-rings. Adjust the strap length for a comfortable fit.



Figure 2: Rear view of the violin case, showing the D-rings where the rucksack straps can be attached for backpack-style carrying.

3. OPERATING THE CASE

3.1 Opening and Closing the Case

To open the case, locate the zippers running along the perimeter. Unzip both zippers completely. The lid will hinge open, revealing the interior. To close, align the lid with the base and zip both zippers securely. Ensure no fabric is caught in the zippers.



Figure 3: The violin case fully open, displaying the plush blue velour interior and the instrument compartment.



Figure 4: An alternative view of the open case, highlighting the various compartments and the protective blanket.

3.2 Placing the Violin

Gently place your 1/8 size violin into the main compartment. The cushioned suspension system is designed to hold the instrument securely. Ensure the violin rests properly within the molded interior without excessive force. Place the included protection blanket over the violin before closing the lid.

3.3 Using Bow Holders

The case features GEWA's patented swivel and flexible bow holders located inside the lid. To secure a bow, gently slide the frog end into the flexible holder and the tip into the swivel holder. Ensure the bow is firmly held to prevent movement during transport.

3.4 Accessory Compartment

A detachable accessory pocket is provided for storing rosin, tuners, or other small items. Place the accessory pocket into its designated space within the case. The attached sheet music pocket is located on the exterior of the case for easy access to your scores.



Figure 5: A detailed view of the accessory compartment, designed for small items like rosin or a tuner.

3.5 Combination Lock

The case is equipped with a combination lock for added security. Refer to the separate lock instructions (if provided with the case) for setting and resetting your personal combination. Always ensure the lock is engaged when transporting the case to prevent accidental opening.



Figure 6: Close-up of the main handle and zipper, illustrating the robust construction and potential location for the combination lock mechanism.



Figure 7: A detailed view of the ergonomic carrying handle, designed for comfortable grip.

4. MAINTENANCE AND CARE

4.1 Exterior Cleaning

The exterior of the case is made from a water-resistant tex material. To clean, wipe with a damp cloth and mild

soap if necessary. Avoid harsh chemicals or abrasive cleaners, as these may damage the finish. Allow the case to air dry completely before storage or use.

4.2 Interior Care

The interior velour lining can be gently vacuumed with a soft brush attachment to remove dust or debris. For spills, dab with a clean, slightly damp cloth. Ensure the interior is completely dry before placing your violin back inside to prevent moisture damage.

4.3 Long-Term Storage

When storing the case for extended periods, keep it in a cool, dry place away from direct sunlight and extreme temperature fluctuations. This helps preserve the integrity of the thermoplastic shell and interior materials.

5. TROUBLESHOOTING

5.1 Zipper Issues

If a zipper becomes stiff or difficult to operate, apply a small amount of zipper lubricant or graphite to the teeth. Avoid forcing the zipper, as this can cause damage. Ensure no fabric is obstructing the zipper path.

5.2 Strap Adjustment

If the rucksack straps feel uncomfortable, adjust the length using the buckles. Ensure both straps are adjusted evenly to distribute weight properly and prevent strain.

5.3 Instrument Fit

This case is specifically designed for 1/8 size violins. If your instrument does not fit securely, verify its size. Do not attempt to force an oversized instrument into the case, as this may cause damage to both the instrument and the case.

6. SPECIFICATIONS

Feature	Detail
Model Number	Gewa
ASIN	B003P17PTU
Size	1/8 Violin
Color	Black Exterior / Blue Interior
Material Type	Plastic (Thermoplastic Shell), Fabric (Water-repellent coating), Velour Interior
Item Weight	Approx. 3.7 lbs (without accessories) / 0.01 ounces (listed as item weight, likely package weight is more accurate for case)
Package Dimensions	31.69 x 11.42 x 6.5 inches
Insulation	Thermo Shell for superior insulation
Bow Holders	GEWA Patented Swivel and Flexible Bow Holder

Carrying Options	Main handle, 2 detachable neoprene rucksack straps
Security	Combination lock

Note: Item weight of 0.01 ounces is likely a data entry error; the feature bullet states "Approx. 3.7 lbs without accessories" which is more realistic for a violin case.

Related Documents - Gewa

 <p>USER MANUAL GEWA Digital Piano UP385</p> <p>Bedienungsanleitung User manual Mode d'emploi Manual de instrucciones www.gewaelectronics.de</p> <p>Das Lehrvideo für das Modell UP385 ist über die GEWA App abrufbar. Für weitere Informationen über das Modell UP385 besuchen Sie die GEWA-Website. www.gewaelectronics.de</p>	<p>GEWA Digital Piano UP385 User Manual</p> <p>Comprehensive user manual for the GEWA Digital Piano UP385, covering setup, operation, features, and safety. Learn to master your digital piano with detailed instructions from GEWA music.</p>
 <p>QUICK START GUIDE GEWA UP355</p> <p>Die Lehrvideo Bedienungsanleitung für das Modell UP355 ist über die GEWA App abrufbar. Für weitere Informationen über das Modell UP355 besuchen Sie die GEWA-Website. www.gewaelectronics.de</p>	<p>GEWA UP355 Digital Piano Quick Start Guide</p> <p>This quick start guide provides essential information for setting up and using the GEWA UP355 digital piano. It covers safety precautions, package contents, assembly, operation, connections, Bluetooth features, the GEWA Piano Remote App, and technical specifications. Multilingual instructions are included to access the full user manual.</p>
 <p>QUICK START GUIDE GEWA PP-3</p>	<p>GEWA PP-3 Digital Piano Quick Start Guide</p> <p>Quick start guide for the GEWA PP-3 digital piano, covering setup, operation, sound selection, Bluetooth connectivity, and app integration.</p>
 <p>DEUTSCH</p> <p>G5 Drum-Modul</p> <p>Installations- und Bedienungsanleitung für das GEWA G5 Drum-Modul</p> <p>www.gewaelectronics.com</p>	<p>GEWA G5 Drum-Modul Bedienungsanleitung</p> <p>Umfassende Bedienungsanleitung für das GEWA G5 Drum-Modul, die Installation, Einrichtung, Bedienung und technische Spezifikationen abdeckt.</p>

 <p>GEWA Digital Piano UP405</p> <p>USER MANUAL GEWA Digital Piano - UP405</p> <p>Sicherungsanleitung (Owner's manual) Mode d'emploi Manual de instrucciones www.gewapeys.com</p> <p> Read these operating instructions before use and observe the safety instructions.  Keep the instruction manual for future reference.</p>	<h2>GEWA Digital Piano UP405 User Manual - Features, Setup, and Operation</h2> <p>Comprehensive user manual for the GEWA Digital Piano UP405. Learn about setup, operation, features, connectivity, and troubleshooting for your GEWA UP405 digital piano.</p>
 <p>DEUTSCH</p> <p>G3 Drum-Modul</p> <p>ENGLISH DEUTSCH FRANÇAIS ESPAÑOL</p> <p> Bitte für die Betriebsanleitung vor der Inbetriebnahme des Moduls die Anleitung des Schlagzeugmoduls zu studieren.</p> <p> Bitte die Betriebsanleitung des Schlagzeugmoduls vor der Inbetriebnahme des Moduls zu studieren.</p> <p> Bitte die Betriebsanleitung des Schlagzeugmoduls vor der Inbetriebnahme des Moduls zu studieren.</p> <p>www.gewadrums.com</p>	<h2>GEWA G3 Drum-Modul Bedienungsanleitung</h2> <p>Umfassende Bedienungsanleitung für das GEWA G3 Drum-Modul von GEWA music GmbH.</p> <p>Erfahren Sie mehr über Einrichtung, Funktionen, Sicherheit und technische Details dieses digitalen Schlagzeugmoduls.</p>