

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Fossil](#) /

> [Fossil Machine Quartz Chronograph Watch \(Model FS4552IE\) Instruction Manual](#)

Fossil FS4552IE

Fossil Machine Quartz Chronograph Watch (Model FS4552IE)

INSTRUCTION MANUAL

1. Introduction

Welcome to your new Fossil Machine Quartz Chronograph Watch. This manual provides essential information for setting up, operating, and maintaining your timepiece. Please read it thoroughly to ensure proper use and longevity of your watch.

2. Components Overview

Your Fossil Machine watch features a robust design with several key components:

- **Dial:** The watch face displaying time and chronograph functions.
- **Hands:** Hour, Minute, and Second hands for timekeeping.
- **Sub-dials:** Smaller dials for chronograph minutes, chronograph seconds, and a 24-hour indicator.
- **Date Window:** Displays the current date.
- **Crown:** Used for setting time and date.
- **Pushers:** Buttons used to operate the chronograph functions.
- **Case:** The main body of the watch, made from stainless steel.
- **Bezel:** The textured ring surrounding the watch crystal.
- **Bracelet:** Black stainless steel metal bracelet with a push-button fold-over clasp.



Figure 2.1: Front view of the Fossil Machine Quartz Chronograph Watch, highlighting the dial, hands, sub-dials, and textured bezel.

3. Setup

3.1 Setting the Time

1. Pull the crown out to position 2 (the outermost position).
2. Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time. Ensure you set the correct AM/PM by observing if the date changes when passing midnight.
3. Push the crown back into position 0 (the innermost position) to start the watch.

3.2 Setting the Date

1. Pull the crown out to position 1 (the middle position).
2. Turn the crown to adjust the date. Turn it until the correct date is displayed in the date window.
3. Push the crown back into position 0 (the innermost position).



Figure 3.1: Side view of the Fossil Machine Watch, illustrating the crown and pushers for time and date adjustments.

3.3 Adjusting the Bracelet

The watch comes with a stainless steel metal bracelet. For optimal comfort and fit, the bracelet may need adjustment. This typically involves adding or removing links. It is recommended to have this procedure performed by a professional jeweler or watch technician to prevent damage to the bracelet or clasp.





Figure 3.2: Back view of the Fossil Machine Watch, displaying the stainless steel caseback and the push-button fold-over clasp on the bracelet.

4. Operating

4.1 Chronograph Function

Your watch is equipped with a chronograph function for measuring elapsed time.

1. **Start/Stop:** Press the top pusher (located at 2 o'clock) to start the chronograph. Press it again to stop the measurement.
2. **Reset:** With the chronograph stopped, press the bottom pusher (located at 4 o'clock) to reset all chronograph hands to their zero positions.

Video 4.1: Demonstration of the Fossil Men's Machine Quartz Stainless Steel Chronograph Watch (Model: FS4552), showcasing its features and chronograph operation.

Video 4.2: Overview of the Fossil Men's Machine Stainless Steel Case Quartz Chronograph Watch, highlighting its design and functionality.

4.2 Water Resistance

This watch is water resistant up to 5 ATM (50 meters / 165 feet). This rating means the watch is suitable for short periods of recreational swimming and showering. It is not recommended for diving, snorkeling, or high-impact water sports. Always ensure the crown is fully pushed in before exposing the watch to water.

5. Maintenance

5.1 Cleaning

Regular cleaning will help maintain the appearance of your watch. Wipe the watch case and bracelet with a soft, dry cloth. For water-resistant models, a slightly damp cloth can be used, followed by thorough drying with a soft, dry cloth.

5.2 Battery Replacement

Your watch is powered by a Lithium Metal battery. When the battery runs low, the watch hands may stop or operate erratically. It is recommended that battery replacement be performed by a qualified watch technician to ensure proper sealing and maintain the watch's water resistance and warranty.

5.3 Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. This helps preserve the watch's movement and materials.

6. Troubleshooting

- **Watch Not Running:** Ensure the crown is fully pushed into position 0. If the watch still does not run, the battery may

need to be replaced.

- **Date Not Changing Correctly:** If the date changes at noon instead of midnight, pull the crown out to position 2 and advance the time by 12 hours. Then, reset the time and date as described in the Setup section.
- **Condensation/Water Inside Watch:** If you notice condensation or water droplets inside the watch, immediately take it to a qualified service center. Do not attempt to open the watch yourself, as this can void the warranty and cause further damage.
- **Chronograph Hands Not Resetting to Zero:** If the chronograph hands do not reset to the 12 o'clock position, consult a professional watch technician for adjustment.

7. Specifications

Model Number	FS4552IE
Movement Type	Quartz
Case Material	Stainless Steel
Case Diameter	45 Millimeters
Case Thickness	12 Millimeters
Band Material Type	Stainless Steel
Band Width	24 Millimeters
Water Resistance Depth	50 Meters (165 Feet)
Crystal Type	Mineral
Closure Type	Push-Button Clasp
Battery	1 Lithium Metal battery (included)



Figure 7.1: Fossil Men's Watch Case Size Guide, illustrating various watch diameters and case thicknesses for reference.

8. Warranty and Support

Your Fossil Machine Quartz Chronograph Watch is covered by a manufacturer's warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the warranty card included with your purchase or visit the official Fossil website. For customer support, service inquiries, or to locate an authorized service center, please visit [Fossil Customer Care](#).