

[Manuals.plus](#) /

> [WENKO](#) /

> WENKO Prea Telescopic Shower Caddy Instruction Manual

WENKO 18596100

WENKO Prea Telescopic Shower Caddy Instruction Manual

Brand: WENKO

Model: 18596100

1. INTRODUCTION

The WENKO Prea Telescopic Shower Caddy is a high-quality stainless steel storage solution designed for universal use in shower cabins and bathtub corners. It provides ample storage space for shampoo, shower gel, soap, sponges, and other bathroom accessories. This manual provides detailed instructions for assembly, installation, operation, and maintenance to ensure safe and effective use of your new shower caddy.






Figure 1: WENKO Prea Telescopic Shower Caddy, fully assembled.

2. SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly.
- Do not overload the baskets. Distribute weight evenly.
- Regularly check the stability of the caddy, especially after initial installation and during use.
- Keep small parts away from children during assembly.
- Avoid using abrasive cleaners or scouring pads, as these can damage the stainless steel finish.

3. PARTS LIST

Before beginning assembly, verify that all the following parts are included in your package:

1. Telescopic Rod (main pole)
2. 4 x Storage Baskets (corner design)
3. Rubber Rings/Conical Gaskets (for basket height adjustment)
4. End Caps (top and bottom)




Figure 2: Illustration of the telescopic rod and four storage baskets.

4. SETUP AND INSTALLATION

The WENKO Prea Telescopic Shower Caddy features a drill-free installation process, making it quick and easy to set up.

1. **Assemble the Telescopic Rod:**

Connect the sections of the telescopic rod to achieve the desired height. The rod is adjustable from 65 cm to 275 cm (25.6 inches to 108.3 inches).

65 - 275 cm

25.60 - 108.27 inch



20 cm

7.87 inch

28 cm

11.02 inch

Figure 3: Product dimensions, including adjustable height range.

2. Attach the Storage Baskets:

Slide the rubber rings (conical gaskets) onto the telescopic rod at your desired basket heights. Then, place the storage baskets onto these rings. The conical design ensures that the baskets become more secure with added weight.

3. Position and Secure the Caddy:

Place the assembled caddy in your desired location, typically a shower cabin corner or bathtub corner. Extend the telescopic rod by twisting it until it firmly clamps between the floor and the ceiling. No drilling or tools are required for this step.




Figure 4: Visual representation of drill-free installation and height adjustability.



- ✓ **Teleskopierbar: Einfach zwischen Boden und Decke klemmen**
- ✓ **Universell einsetzbar in Duschkabine, Badewannenecke oder im Badezimmer**

- ✓ *Telescopic: Simply clamp between floor and ceiling*
- ✓ *Universally applicable in shower cubicle, bath corner or in the bathroom*

Figure 5: The shower caddy clamped between floor and ceiling, suitable for various bathroom settings.

5. OPERATION

Once installed, the WENKO Prea Telescopic Shower Caddy is ready for use.

- **Adjusting Basket Height:**

To reposition a basket, simply lift it off its rubber ring, slide the ring to the new desired height, and then place the basket back onto the ring. Ensure the basket is level and stable.

- **Loading the Baskets:**

Place your shower essentials such as shampoo bottles, shower gel, soap, and sponges into the baskets. Distribute the weight as evenly as possible across the baskets to maintain stability.



Figure 6: The shower caddy in a typical shower corner, holding various items.

6. MAINTENANCE

To ensure the longevity and appearance of your stainless steel shower caddy, follow these maintenance guidelines:

- **Cleaning:**

Clean the stainless steel surfaces regularly with a soft cloth and mild soap or a non-abrasive stainless steel cleaner. Rinse thoroughly with water and dry immediately to prevent water spots and maintain its brilliant finish. Avoid harsh chemicals, abrasive cleaners, or steel wool, as these can scratch the surface or cause corrosion.

- **Inspection:**

Periodically check the telescopic rod and basket connections for any signs of loosening or wear. Re-tighten the telescopic rod if necessary by twisting it firmly between the floor and ceiling.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Caddy feels unstable or wobbly.	Telescopic rod not fully extended or tightened. Uneven weight distribution.	Ensure the telescopic rod is twisted firmly between the floor and ceiling. Redistribute items in baskets evenly.
Baskets slide down the pole.	Rubber rings (conical gaskets) are not properly positioned or are worn.	Ensure the rubber rings are securely placed under each basket. If worn, contact customer support for replacements.
Rust spots appear on stainless steel.	Exposure to harsh chemicals, abrasive cleaning, or prolonged water exposure without drying.	Clean with a mild stainless steel cleaner and soft cloth. Dry thoroughly after each use. Avoid abrasive materials.

8. SPECIFICATIONS

Material: High-quality Stainless Steel

Color: Brilliant Silver

Adjustable Height: 65 cm to 275 cm (25.6 inches to 108.3 inches)

Dimensions (L x W x H): Approximately 28 cm x 20 cm x 65-275 cm (11.02 in x 7.87 in x 25.6-108.3 in)

Telescopic Rod Diameter: 2.2 cm (0.87 inches)

Weight (unpacked): 1.68 kg (3.7 lbs)

Number of Baskets: 4

Installation Type: Tension Rod (Floor-to-Ceiling)

9. WARRANTY AND SUPPORT

Your WENKO Prea Telescopic Shower Caddy comes with a **3-year warranty** from the date of purchase. This warranty covers all material and manufacturing defects that impair proper functionality. It excludes damages resulting from incorrect handling or natural wear and tear. Your statutory warranty rights remain unaffected.

Sehr geehrter Kunde,
auf dieses Produkt haben Sie 3 Jahre Garantie ab Kaufdatum. Die Garantie umfasst alle Material- und Herstellungsfehler, welche die Funktion beeinträchtigen. Ausgenommen sind Schäden, die durch unsachgemäße Handhabung oder natürlichen Verschleiß entstehen. Diese Garantie schränkt Ihre gesetzlichen Gewährleistungsrechte nicht ein. Im Garantiefall schicken Sie den Artikel zusammen mit dem dazugehörigen Kassenbonno kostenfrei und transportsticher verpackt an die folgende Anschrift:
Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“
Im Hülsfeld 10 · 40721 Hilden
service@wenko.de · www.wenko.de

Dear customer,
You have a 3-year guarantee on this product, beginning on the date of purchase. The guarantee comprises all material and manufacturing errors that impair the function. Any damage caused by improper handling or normal wear and tear is excluded. Thus guarantee does not restrict your statutory guarantee rights. In case of a guarantee claim, please send the article free of charge and properly packaged to the following address together with the corresponding receipt:
Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“
Im Hülsfeld 10 · 40721 Hilden, Germany
service@wenko.de · www.wenko.de

Chère cliente, cher client,
Pour ce produit, vous bénéficiez d'une garantie de 3 ans à compter de la date d'achat. La garantie porte sur tous les vices de matériau et de fabrication qui altèrent le bon fonctionnement. Sont exclus les dommages résultant d'un maniement incorrect ou de l'usure naturelle. La garantie ne restreint aucune vos droits à la garantie légaux. En cas de garantie, veuillez renvoyer gratuitement l'article accompagné du ticket de caisse et convenablement emballé pour le transport à l'adresse suivante :
Wenko-Wenselaar GmbH & Co. KG - Abteilung « Retouren »
Im Hülsfeld 10 · 40721 Hilden, Allemagne
service@wenko.de · www.wenko.de

Estimado cliente:
Para este producto usted dispone de 3 años de garantía a partir de la fecha de compra. La garantía cubre todos los defectos de material y fabricación, que perturben el funcionamiento. A excepción de los daños que sean causados por el uso indebido o el desgaste normal. Esta garantía no limitará sus derechos legales de garantía. En caso de hacer uso de la garantía, envíe gratuitamente el producto junto con el recibo de pago correspondiente y empaquetado de forma segura para el transporte a la siguiente dirección:
Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“
Im Hülsfeld 10 · 40721 Hilden, Alemania
service@wenko.de · www.wenko.de

Gentile cliente,
questo prodotto ha una garanzia di 3 anni a partire dalla data di acquisto. La garanzia copre tutti i difetti di materiali e fabbricazione che pregiudicano la funzione. Sono esclusi dalla garanzia i danni causati da un uso improprio o dovuti a usura naturale. Questa garanzia non limita i Suoi diritti legali. In caso di garanzia l'articolo, opportunamente imballato, va spedito gratuitamente insieme al relativo scontrino al seguente indirizzo:
Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“ (Reperto "Resi")
Im Hülsfeld 10 · 40721 Hilden, Germania
service@wenko.de · www.wenko.de

Geachte klant,
Op dit product heeft u 3 jaar garantie vanaf de datum van aankoop. Deze garantie omvat alle materiaal- en productiefouten die van invloed zijn op de werking van het product. Schade als gevolg van verkeerd gebruik of natuurlijke slijtage valt niet onder de garantie. Deze garantie laat uw wettelijke garantierechten onverlet. Bij garantie kunt u het product gratis retourneren. Stuur het product in dat geval veilig verpakt naar het volgende adres:
Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“
Im Hülsfeld 10 · D-40721 Hilden, Duitsland
service@wenko.de · www.wenko.de



Garantie-Zertifikat Guarantee Certificate Certificat de garantie Certificado de garantía Certificato di garanzia



Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“ · Im Hülsfeld 10 · 40721 Hilden
service@wenko.de · www.wenko.de

Figure 7: WENKO 3-Year Warranty Certificate.

Warranty Claims and Support:

In case of a warranty claim, please return the item, along with your proof of purchase (receipt), properly packaged for transport, to the following address:

Wenko-Wenselaar GmbH & Co. KG
Abteilung "Retouren"
Im Hülsfeld 17
40721 Hilden, Germany

For further inquiries or support, you may also contact us via email service@wenko.de

Visit our official website for more information www.wenko.de