

LIFETIME 081483004709

# Lifetime Pro Court Height Adjustable Portable Basketball System User Manual

Model: 081483004709

## INTRODUCTION

This manual provides essential information for the safe and effective assembly, operation, and maintenance of your Lifetime Pro Court Height Adjustable Portable Basketball System. Please read all instructions carefully before assembly and use. Retain this manual for future reference.

## PRODUCT OVERVIEW

The Lifetime Pro Court Portable Basketball System is designed for outdoor recreational use, offering a durable and adjustable solution for basketball enthusiasts of all ages. Its robust construction ensures longevity and stability.

### Key Features:

- **44-inch Shatterproof Fusion Backboard:** Constructed with a durable polycarbonate playing surface for enhanced performance and resilience.
- **Telescoping Height Adjustment:** Easily adjusts the rim height from 7.5 feet to 10 feet, accommodating various player skill levels and ages.
- **Portable Base:** Equipped with wheels for convenient relocation and a 27-gallon capacity for water or sand to ensure stability.
- **All-Weather Resistant:** Features fade-resistant graphics and a 3-piece steel pole with a powder-coated finish for durability against various weather conditions.
- **Classic Rim:** A 5/8-inch solid-steel ring supported by 1/2-inch braces, complete with an all-weather nylon net.



Figure 1: The Lifetime Pro Court Portable Basketball System, showcasing its design and outdoor suitability.

## SETUP INSTRUCTIONS

---


Assembly of the Lifetime Pro Court Basketball System typically requires two adults and can take approximately 1-2 hours. Follow the detailed instructions provided in the separate assembly guide included with your product. Ensure all components are present before beginning assembly.

### Key Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list.
2. **Assemble Pole Sections:** Connect the 3-piece steel pole sections as per the assembly guide.
3. **Attach Backboard and Rim:** Secure the 44-inch backboard and classic rim to the pole assembly.
4. **Fill the Base:** The base must be filled with a stabilizing agent to prevent tipping. It has a 27-gallon capacity.
  - **Water:** Provides adequate stability for general play.
  - **Sand:** Offers superior stability and is recommended for high-impact play or windy conditions.
5. **Adjust Height:** Once assembled and the base is filled, adjust the height to your desired level using the telescoping mechanism.

# 90782

Courtside, 46" Shtpf Fsn,  
Quick Adjust® II



©2016 Lifetime Products, Inc, Clearfield, UT 84016-0010 USA

Figure 2: Technical diagram illustrating the system's dimensions and height adjustment capabilities.

## OPERATING INSTRUCTIONS

### Height Adjustment:

The system features a telescoping height adjustment mechanism, allowing the rim to be set anywhere from 7.5 feet to 10 feet. To adjust the height:

1. Locate the adjustment screws on the back of the pole.
2. Loosen the screws sufficiently to allow the pole sections to slide.
3. Carefully raise or lower the backboard to the desired height. Ensure the pole sections are aligned with the pre-drilled holes for secure positioning.
4. Tighten the adjustment screws firmly to lock the height in place. Verify stability before use.




Figure 3: Visual guide for adjusting the system's height.

### Portability:

The base is equipped with wheels for easy movement. To move the system:

1. Ensure the base is securely filled to maintain stability during movement.
2. Carefully tilt the system backward onto its wheels.
3. Roll the system to the desired location.
4. Gently lower the system back onto its base, ensuring it is level and stable before use.

## MAINTENANCE

Regular maintenance will extend the life of your basketball system.

- **Base Fluid Level:** Periodically check the fluid level in the base. Refill with water or sand as needed to maintain stability.
- **Hardware Inspection:** Regularly inspect all nuts, bolts, and screws for tightness. Tighten any loose hardware to ensure structural integrity.
- **Cleaning:** Clean the backboard and pole with mild soap and water. Avoid abrasive cleaners that could damage the finish or playing surface.
- **Net Replacement:** The all-weather nylon net is designed for durability, but may require replacement over time due to wear and tear. Replacement nets are widely available.
- **Winterization:** If storing the system for winter, ensure the base is completely drained of water to prevent freezing and cracking. Sand-filled bases do not require draining.




Figure 4: Illustration of the system's weather-resistant features.

## TROUBLESHOOTING

### Common Issues and Solutions:

- **System Instability:**

- Ensure the base is fully filled with water or sand.
- Check that all pole sections are securely connected and adjustment screws are tightened.

- **Backboard Wobbling:**

- Verify all bolts attaching the backboard to the pole and support arms are tight.
- Confirm the pole sections are properly seated and secured.

- **Difficulty Adjusting Height:**

- Loosen adjustment screws completely before attempting to slide the pole.
- Ensure no debris is obstructing the telescoping mechanism.

## SPECIFICATIONS

Brand	LIFETIME
Model Name	Lifetime Pro Court Height Adjustable Portable Basketball System, 44 Inch Backboard
Model Number	081483004709
Backboard Size	44 inches
Backboard Material	Polycarbonate (Shatterproof Fusion)
Height Adjustment Range	7.5 to 10 feet (Telescoping)

Base Capacity	27 gallons (water or sand)
Base Dimensions	43.2 in x 30 in x 6.5 in
Pole Material	3-Piece Steel (Powder-Coated)
Rim Type	Classic Rim (5/8-inch solid-steel ring, 1/2-inch braces)
Net Material	All-weather nylon (50g weight)
Item Weight	50 Pounds
Product Dimensions (Overall)	44"D x 44"W x 120"H
Indoor/Outdoor Usage	Outdoor

## WARRANTY AND SUPPORT

Your Lifetime Pro Court Height Adjustable Portable Basketball System is covered by a **5-Year Limited Manufacturer Warranty**. For warranty claims, technical support, or replacement parts, please contact Lifetime customer service directly. Refer to the contact information provided in your product packaging or visit the official Lifetime website.

For additional information and support, you may visit the [Lifetime Store on Amazon](#).