Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- homestyles /
- > Homestyles Blair Black Dining Chairs (Set of 2) User Manual

homestyles 5178-802

Homestyles Blair Black Dining Chairs (Set of 2) User Manual

Model: 5178-802

Brand: homestyles

INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your Homestyles Blair Black Dining Chairs. Please read these instructions carefully before assembly and use to ensure safe and proper operation.

IMPORTANT SAFETY INFORMATION

- WARNING: Do not exceed the maximum weight limit of 250 pounds per chair.
- Always follow the assembly instructions carefully to ensure safe and proper use.
- Regularly check all bolts and screws to ensure they remain tight. Loose fasteners can lead to instability and potential injury.
- · Do not stand on the chairs.
- Keep chairs away from direct heat sources or excessive moisture to prevent damage to the wood finish.

PACKAGE CONTENTS

Your Homestyles Blair Black Dining Chairs package includes:

- 2 x Blair Black Dining Chairs (unassembled components)
- Hardware pack (screws, bolts, Allen wrench)
- · Assembly instructions sheet



Image: Components of the Homestyles Blair Black Dining Chairs as they appear in the package before assembly.

SETUP AND ASSEMBLY

Assembly is required for the Homestyles Blair Black Dining Chairs. The process is designed to be straightforward with easy-to-understand directions provided in the package. An Allen wrench is included for assembly.

- 1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches. Verify all components and hardware are present against the parts list in your included instructions.
- 2. **Initial Fastening:** Begin by loosely attaching all screws and bolts. The chairs typically involve 11 screws in total, provided in separate bags (short, standard, long).
- 3. **Preventing Wobble:** To ensure stability and prevent wobbling, do not fully tighten screws one-by-one. Instead, screw them in as "groups," moving from one to another. Keep them loose until all connections are made.
- 4. **Seat and Leg Attachment:** When attaching the seat and front legs to the back frame/leg assembly, take your time. Snug the fasteners but do not fully tighten. Test the chair's levelness as you go. Adjust the pitch of the seat to the back to achieve a perfect, stable fit.
- 5. Final Tightening: Once all components are correctly aligned and the chair is level, fully tighten all

Your browser does not support the video tag.

Video: An official Homestyles video demonstrating the assembly and features of the Blair Dining Chair. This video provides a visual guide to the assembly process and highlights key design elements.






Image: Front view of a fully assembled Homestyles Blair Black Dining Chair, showcasing its X-back design and tapered leas.

OPERATING INSTRUCTIONS (USAGE)

The Homestyles Blair Black Dining Chairs are designed for dining purposes and offer comfort and style for everyday use.

- **Seating Comfort:** The seat and back are designed with customized contours to cradle the user, providing enhanced comfort during extended periods of sitting.
- Weight Capacity: Each chair has a maximum weight recommendation of 250 pounds. Do not exceed this limit to ensure safety and product longevity.
- **Placement:** These chairs are suitable for indoor use in dining rooms, kitchens, or other areas where additional seating is needed.



Image: Homestyles Blair Black Dining Chairs in a dining room setting, demonstrating their intended use around a table.

MAINTENANCE

Proper care will help maintain the appearance and longevity of your dining chairs.

- **Cleaning:** For general cleaning, spot clean the chairs as needed. Use a soft, damp cloth with mild soap if necessary, and dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Regular Inspection:** Periodically inspect all connections and tighten any loose screws or bolts to maintain structural integrity.
- **Protecting the Finish:** Avoid placing hot items directly on the chair surface. Use furniture pads under the legs to prevent scratching floors.



Image: Detailed view of the black painted finish, showing the wood grain texture. Regular cleaning helps preserve this finish.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Wobbling Chair:** If a chair feels wobbly, it is likely due to loose screws. Turn the chair upside down and use the provided Allen wrench to tighten all screws evenly. Avoid overtightening.
- Scratches/Chips in Finish: Minor scratches or chips can occur with regular use. Touch-up paint matching the black finish may be used to address these.

SPECIFICATIONS

Feature	Detail
Brand	homestyles
Model Name	Blair

Model Number	5178-802
Color	Black
Product Dimensions	22.25"D x 18.75"W x 38.86"H
Seat Height	18 Inches
Seat Depth	17.25 inches
Chair Backrest Width	19 Inches
Back Style	Cross Back
Material	Hardwood (Frame)
Finish Type	Painted
Maximum Weight Recommendation	250 Pounds
Product Care Instructions	Spot Clean
Assembly Required	Yes
Number of Pieces	2 (chairs)

WARRANTY

The Homestyles Blair Black Dining Chairs come with a 30-day limited warranty. Please refer to the warranty documentation included with your purchase for full details and terms.


SUPPORT

For further assistance, questions, or to report any issues, please contact Homestyles customer support through their official website or the contact information provided in your product packaging.

You can also visit the homestyles Store on Amazon for more product information and support resources.


© 2025 homestyles. All rights reserved.

Related Documents - 5178-802



Homestyles 6801-21 Coffee Table Assembly and Care Instructions

Comprehensive assembly and care guide for the Homestyles 6801-21 Coffee Table. Includes detailed steps, parts list, hardware list, and maintenance tips for optimal use and longevity.




homestyles 88 5053 49 Hall Tree Assembly Instructions and Care Guide

Detailed assembly instructions and care guide for the homestyles 88 5053 49 Hall Tree. Includes part lists, hardware lists, step-by-step assembly, and important safety information for setting up your entryway furniture.



Homestyles 5903-44 2 Drawer Night Stand Assembly Instructions

Assembly and care instructions for the Homestyles 5903-44 2 Drawer Night Stand. Includes part list, assembly steps, and maintenance tips to ensure proper use and longevity.



Homestyles Kitchen Cart Assembly Instructions & Care Guide

Detailed assembly instructions and care guide for the Homestyles 20 04516 0095 Kitchen Cart. Includes part lists, hardware lists, step-by-step assembly, and maintenance tips.



Homestyles 5906-44 2 Drawer Night Stand Assembly and Care Instructions

Assembly and care instructions for the Homestyles 5906-44 2 Drawer Night Stand. Includes part list, step-by-step assembly, and maintenance guidelines.



Homestyles 6801-23 Storage Bench Assembly Instructions

Assembly instructions and care guide for the Homestyles 6801-23 Storage Bench. Includes parts list, hardware list, step-by-step assembly, and cleaning recommendations.