

[Manuals.plus](#) /

› [Falk](#) /

› FALK Claas Pedal Tractor with Excavator and Tilting Trailer User Manual

Falk KAYL1010W

FALK Claas Pedal Tractor with Excavator and Tilting Trailer User Manual

Model: KAYL1010W

INTRODUCTION

Thank you for choosing the FALK Claas Pedal Tractor with Excavator and Tilting Trailer. This replica of the Claas Axos 330 model is designed to provide hours of imaginative and active play for children aged 3 to 7 years. Manufactured in France, this robust toy features a pedal-driven tractor, an articulated front loader, a 360-degree rotating rear excavator, and a large tilting trailer.

This manual provides essential information for assembly, operation, maintenance, and safety to ensure a safe and enjoyable experience.

Important Safety Information

WARNING! Not suitable for children under 36 months due to the danger of ingesting small parts. Adult supervision is required at all times during assembly and play.

PARTS LIST

Before beginning assembly, please ensure all components listed below are present in the packaging.

- 1 x Pedal Tractor chassis
- 1 x Front Loader attachment
- 1 x Rear Excavator attachment
- 1 x Double-Axle Tilting Trailer
- Assembly hardware (screws, nuts, pins, etc.)
- Sticker sheet

If any parts are missing or damaged, please contact FALK customer support.

SETUP AND ASSEMBLY

Assembly of the FALK Claas Pedal Tractor requires adult supervision and can take approximately 2-3 hours. Follow the detailed instructions provided in the separate assembly guide (not included in this manual) for step-by-step procedures. Ensure you have adequate space and the necessary tools (e.g., screwdriver, hammer) before starting.

Key Assembly Points:

- Attach the wheels securely to the tractor chassis.
- Mount the pedal mechanism and steering column.
- Install the front loader and rear excavator attachments, ensuring they are fully articulated and move freely.
- Assemble the tilting trailer and connect it to the tractor hitch.
- Apply all decorative stickers as per the assembly guide for a complete look.



Image: The fully assembled FALK Claas Pedal Tractor with its front loader, rear excavator, and double-axle tilting trailer.



Image: A child seated on the FALK Claas Pedal Tractor, demonstrating its size and the attached trailer. The "Fabriqué en France" logo is visible in the top left corner.

OPERATING INSTRUCTIONS

The FALK Claas Pedal Tractor is designed for intuitive operation, allowing children to engage in various play scenarios.

Pedal Operation

- To move the tractor forward, pedal in a circular motion.
- To steer, turn the steering wheel left or right. The steering wheel is equipped with a horn for added play realism.

Front Loader Operation

- The front loader is fully articulated. Use the designated handle and lever (as shown in the assembly guide) to raise, lower, and tilt the bucket.
- Ideal for scooping and transporting light materials like sand or leaves.



Image: A child demonstrating the operation of the articulated front loader on the FALK Claas Pedal Tractor.

Rear Excavator Operation

- The rear excavator is also fully articulated for precise digging.
- The tractor seat can rotate 360 degrees, allowing the child to easily switch between driving and operating the excavator.
- Use the handle and lever to control the excavator arm and bucket.



Image: A child operating the articulated rear excavator, showcasing the 360-degree rotating seat feature.

Tilting Trailer Use

- The double-axle trailer can be easily attached and detached from the tractor.

- To empty the trailer, unlatch and tilt the bed. This allows for easy dumping of transported materials.



Image: A child enjoying riding the FALK Claas Pedal Tractor with the attached tilting trailer, demonstrating the overall play experience.

MAINTENANCE

Regular maintenance will extend the life of your FALK Claas Pedal Tractor.

- **Cleaning:** Wipe down all plastic surfaces with a damp cloth and mild soap as needed. Avoid abrasive cleaners.
- **Lubrication:** Periodically check moving parts (pedals, steering, excavator joints) and apply a small amount of silicone-based lubricant if movement becomes stiff.
- **Storage:** Store the tractor in a dry, covered area away from direct sunlight and extreme temperatures to prevent material degradation.
- **Inspection:** Regularly inspect all screws, nuts, and connections to ensure they are tight. Retighten as necessary. Check for any cracks or damage to plastic parts and discontinue use if significant damage is found.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Difficulty with assembly.	Missing parts, incorrect orientation, or tight fittings.	Verify all parts against the parts list. Refer to the detailed assembly guide. Ensure components are aligned correctly. For tight fittings, gentle force or a rubber mallet may be needed. If parts are missing, contact customer support.
Pedals or steering are stiff.	Lack of lubrication or debris in moving parts.	Clean any visible debris. Apply a small amount of silicone-based lubricant to the pedal axle and steering column joints.

Problem	Possible Cause	Solution
Excavator or front loader not moving smoothly.	Joints are stiff or debris is present.	Clean the joints and apply silicone lubricant. Check for any obstructions.
Trailer detaches easily.	Hitch connection is loose or damaged.	Ensure the trailer hitch is securely fastened to the tractor. Inspect the hitch mechanism for wear or damage.

SPECIFICATIONS

Model Name: Tractopelle à pédales Claas avec excavatrice arrière et remorque basculante double essieu

Model Number: KAYL1010W

Brand: Falk

Dimensions (L x W x H): 225 x 60 x 79 cm (88.6 x 23.6 x 31.1 inches)

Weight: 23 kg (50.7 lbs)

Recommended Age: 3 to 7 years

Material: High-quality Plastic

Educational Value: Develops imagination, role-playing skills, and physical development through active play.

Color: Green

Power Source: Manual (pedal-driven)

WARRANTY AND SUPPORT

FALK products are manufactured with quality and durability in mind.

- Spare Parts:** Spare parts for this product are available for a period of 2 years from the date of purchase.
- Customer Support:** For any questions regarding assembly, missing parts, or product issues, please contact FALK customer service. Refer to the contact information provided on the product packaging or the official FALK website.

Please retain your proof of purchase for warranty claims and support inquiries.

© 2024 Falk. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B003U5MZB4>

More documents and user manuals: <https://manuals.plus/>