

Aurora 21074

Aurora Dreamy Eyes Lea Lamb Stuffed Animal User Manual

Model: 21074

INTRODUCTION

This manual provides essential information for the proper care and handling of your Aurora Dreamy Eyes Lea Lamb stuffed animal. Please read through these instructions to ensure the longevity and enjoyment of your plush toy.

SAFETY INFORMATION

WARNING: Choking Hazard - Small Parts.

This product is recommended for ages 0-15 years. Always supervise young children during play. Regularly inspect the toy for any loose parts or damage that could pose a hazard.

SETUP AND INITIAL INSPECTION

1. **Unpacking:** Carefully remove the Lea Lamb stuffed animal from its packaging. Retain packaging for future reference if needed.
2. **Initial Inspection:** Before first use, thoroughly inspect the plush toy for any signs of damage, loose stitching, or detached components. Ensure all parts are securely attached.
3. **Fluffing:** Gently fluff the plush toy to restore its shape after being compressed in packaging.



Image 1: Aurora Dreamy Eyes Lea Lamb in a relaxed, lying position. This shows the full body and the characteristic large, dreamy eyes.

OPERATING (USAGE GUIDELINES)

The Aurora Dreamy Eyes Lea Lamb is designed for cuddling, imaginative play, and display. Its soft plush fabric and bean-filled body make it suitable for various gentle interactions.

- **Cuddling:** The soft texture is ideal for comforting cuddles.
- **Play:** Engage in gentle imaginative play. Avoid rough handling that could damage the toy.
- **Display:** The toy can be placed on shelves, beds, or other surfaces as a decorative item.



Image 2a: Aurora Dreamy Eyes Lea Lamb sitting upright, showcasing its front view and large, expressive eyes.



Image 2b: Aurora Dreamy Eyes Lea Lamb sitting upright, showing its back view and tail detail.

MAINTENANCE AND CLEANING

To maintain the quality and appearance of your Lea Lamb, follow these cleaning instructions:

- **Spot Cleaning:** For minor stains, use a soft cloth dampened with mild soap and cold water. Gently blot the affected area. Do not rub vigorously.
- **Drying:** Allow the toy to air dry completely. Do not use a machine dryer, as high heat can damage the plush fabric and internal components.
- **Avoid Submerging:** Do not submerge the entire toy in water, especially due to its bean pellet filling, which can be difficult to dry thoroughly and may lead to mildew.
- **Regular Dusting:** Gently dust the toy regularly with a soft brush or cloth to prevent dirt buildup.

TROUBLESHOOTING

Issue	Possible Cause	Solution
-------	----------------	----------

Issue	Possible Cause	Solution
Plush appears flattened or matted.	Compression during storage or prolonged use.	Gently fluff and reshape the plush by hand. A soft brush can help restore the texture.
Minor stain on fabric.	Accidental spill or dirt.	Perform spot cleaning as described in the Maintenance section.
Loose thread or minor seam opening.	Normal wear and tear.	Carefully trim loose threads. For minor seam openings, hand-stitch with matching thread. If significant, discontinue use and contact support.

SPECIFICATIONS

- **Model Name:** Lea Lamb
- **Model Number:** 21074
- **Brand:** Aurora
- **Dimensions:** Approximately 8 x 8 x 8 inches (L x W x H)
- **Item Weight:** Approximately 1 ounce
- **Materials:** Soft plush fabric, bean pellets
- **Recommended Age:** 0 - 15 years
- **Manufacturer:** Aurora World Inc
- **Release Date:** August 15, 2010




Image 3: The Lea Lamb plush toy held in an adult's hand, illustrating its approximate size and portability.

WARRANTY INFORMATION

Specific warranty details for the Aurora Dreamy Eyes Lea Lamb are not provided in this manual. For information regarding product warranty, please refer to the original product packaging or contact Aurora World Inc. directly.

SUPPORT AND CONTACT

For further assistance, questions, or concerns regarding your Aurora Dreamy Eyes Lea Lamb, please visit the official Aurora World Inc. website or contact their customer service department.

Manufacturer: Aurora World Inc.

Website: www.auroraworld.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question