

manuals.plus /

› [PHILIPS](#) /

› [Philips Norelco BeardTrimmer 7300 Instruction Manual \(Model QT4070/41\)](#)

PHILIPS QT4070/41

Philips Norelco BeardTrimmer 7300 Instruction Manual

Model: QT4070/41 | Brand: PHILIPS

INTRODUCTION

The Philips Norelco BeardTrimmer 7300 (Model QT4070/41) is designed for precise beard and stubble trimming with an integrated vacuum system for mess-free grooming. This high-performance trimmer offers 18 secured length settings and a turbo power boost for efficient trimming.

PHILIPS
NORELCO

FACE | STYLE



with
**TURBO
BOOST**

VACUUM SYSTEM LESS MESS

SERIES 7000
BEARD TRIMMER 7300



Vacuum
system
captures hairs

18
LENGTHS

Built-in length
settings
for a short to full
beard

10
mm

Digital
display

1000000
power

75 min
cordless
power

1 hr
charge
time

45 day run time

Image: Philips Norelco BeardTrimmer 7300 in its retail packaging, highlighting key features like the vacuum system and adjustable length settings.

KEY FEATURES

- **Integrated Vacuum System:** Captures cut hairs for a clean trimming experience.
- **18 Secured Length Settings:** Adjustable from 1/32 inch (1mm) up to 23/32 inch (18mm) for versatile styling.
- **0.5mm Stubble Setting:** For achieving a precise stubble look.
- **Turbo Power Boost Button:** Increases cutting and fan speed for thicker hair.
- **Multifunctional Display:** Shows battery status and selected hair length.
- **Maintenance-Free Blades:** Self-sharpening blades require no oiling.
- **Corded and Cordless Use:** Provides flexibility and convenience.
- **Travel Lock:** Prevents accidental activation during transport.

PHILIPS

NORELCO

INTEGRATED VACUUM

Vacuum system captures cut hairs for mess-free trimming.

Aspiradora integrada, el sistema de aspiradora captura los vellos recortados para un recorte más prolijo.



18 BUILT-IN LENGTH SETTINGS

The adjustable wheel "locks in" your chosen length setting, from 1/32" to 23/32" (1-18 mm). No separate attachments needed for a hassle-free trim.

18 ajustes de largo integrados, el exclusivo control de largo 'bloquea' el ajuste del largo elegido, desde 1 - 18 mm (1/32" a 23/32"). No se requieren accesorios para un recorte sin inconvenientes.



1/32 inch*
0.5 mm*

*Without stubble comb attached *Sin el peine guía acoplado

STUBBLE & CONTOUR-FOLLOWING COMBS

The stubble comb delivers a close and precise trim. The contour-following beard comb provides a skin-friendly, even trim.

Peine que sigue las curvas y peine para barba de pocos días, el peine para barba de pocos días ofrece un recorte al ras y preciso. El peine para la barba que sigue las curvas del rostro ofrece un recorte parejo y cuida la piel.



VACUUM SYSTEM LESS MESS

SERIES 7000
BEARD TRIMMER 7300

DIGITAL DISPLAY

Indicates battery status and selected hair length setting.

Pantalla digital, indica el estado de la batería y la configuración del largo de vello seleccionada.



Image: Detailed view of the Philips Norelco BeardTrimmer 7300, illustrating the integrated vacuum system, 18 built-in length settings, and digital display.

WHAT'S IN THE BOX

Your Philips Norelco BeardTrimmer 7300 package includes:

- Philips Norelco Vacuum Stubble and Beard Trimmer Pro (Model QT4070/41)
- Charging Adaptor
- USB-C Cable
- Cleaning Brush
- Stubble Comb
- Contour-Following Comb
- Beard Comb
- Blade Oil
- Travel Case





Image: Side view of the product packaging, detailing the secured length settings, maintenance-free feature, and listing the items included in the box.

SETUP

Charging the Trimmer

1. Connect the USB-C cable to the trimmer and the charging adaptor.
2. Plug the charging adaptor into a power outlet.
3. The multifunctional display will indicate the battery level during charging. A full charge provides up to 50 minutes of cordless use.

Attaching and Removing Combs

- To attach a comb: Align the comb with the trimmer head and gently push until it clicks into place.
- To remove a comb: Gently pull the comb away from the trimmer head.



Image: Close-up of the trimmer's digital display, showing the battery level and selected length setting in millimeters.

OPERATING INSTRUCTIONS

Powering On/Off and Travel Lock

- To power on: Slide the power button upwards.
- To power off: Slide the power button downwards.
- To activate travel lock: Press and hold the power button for 3 seconds until the lock icon appears on the display. Repeat to unlock.

Adjusting Length Settings

- Turn the zoom lock wheel on the back of the trimmer to select your desired length setting (1mm to 18mm). The selected length will be shown on the multifunctional display.
- For a 0.5mm stubble setting, remove the comb.

Trimming Techniques

1. Ensure your beard is clean and dry before trimming.
2. Select the desired length setting using the zoom wheel.
3. Move the trimmer against the direction of hair growth, ensuring the comb is flat against your skin.
4. Use the Turbo power boost button for thicker hair by pressing the 'Turbo' button.
5. For precise edging, remove the comb and use the trimmer blade directly.



Image: A man using the Philips Norelco BeardTrimmer 7300 to trim his beard, demonstrating typical usage.



Image: A man using the Philips Norelco BeardTrimmer 7300 to refine his beard, with a woman observing in the background, illustrating the product's ease of use.

Vacuum System

The integrated vacuum system automatically captures most cut hairs into a chamber within the trimmer handle, reducing mess. Empty the hair chamber after each use for optimal performance.

MAINTENANCE

Cleaning the Trimmer

1. Ensure the trimmer is powered off and unplugged before cleaning.
2. Remove the trimming comb.
3. Open the hair chamber and empty collected hairs.
4. Rinse the trimmer head and hair chamber under running water. The trimmer is waterproof.
5. Use the provided cleaning brush to remove any stubborn hairs from the blades or internal components.
6. Allow all parts to air dry completely before reassembling or storing.

Oiling Blades

The self-sharpening blades of the Philips Norelco BeardTrimmer 7300 are designed to be maintenance-free and do not require oiling under normal use. If you notice reduced performance, apply a small drop of the provided blade oil to the blades.

TROUBLESHOOTING

- **Trimmer not turning on:** Ensure the trimmer is charged. Check if the travel lock is activated.

- **Reduced trimming performance:** Clean the trimmer head and hair chamber thoroughly. Ensure blades are free of debris.
- **Vacuum not collecting hair effectively:** Empty the hair chamber. Ensure the vacuum intake is not blocked.
- **Battery not holding charge:** Ensure the charging adaptor and cable are properly connected. Contact customer support if the issue persists.

SPECIFICATIONS

Model Number	QT4070/41
Product Dimensions	7.28 x 7.67 x 10.83 inches
Item Weight	1 Pound
Color	Black/Silver
Power Source	Battery Powered (1 AA battery required)
Recommended Uses	Trimming (Beard, Stubble, Mustache)
Manufacturer	Norelco

SAFETY INFORMATION

Please read and understand all safety instructions before using the Philips Norelco BeardTrimmer 7300.

- Avoid contact with eyes, skin, and water (other than for cleaning as instructed).
- Unplug the device when not in use and before cleaning.
- Do not use on infants or children without adult supervision.
- Keep the device away from heat sources and direct sunlight.
- Do not use if the device or any part is damaged.

WARRANTY AND SUPPORT

The Philips Norelco Vacuum Stubble and Beard Trimmer Pro is backed by a two-year manufacturer's warranty. For warranty services or product support, please contact Norelco customer service directly. All sales are final.

PRODUCT VIDEOS

Shavers 101: The Types

Video: This video provides a general overview of different shaver types, including a brief demonstration of the Philips Norelco Vacuum Trimmer (QT4070/41) at the 0:27 mark, showcasing its use for beard and stubble trimming.