

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Sony](#) /

› [The Shoot PS Move Game Instruction Manual](#)

Sony 9159872

The Shoot PS Move Game Instruction Manual

INTRODUCTION

Welcome to The Shoot, an action-packed light-gun shooter game developed exclusively for the PlayStation 3 system, utilizing the PlayStation Move motion controller. This manual provides essential information to help you set up, play, and enjoy your game.

PRODUCT OVERVIEW



The game cover for *The Shoot* features a dynamic scene with various characters, including a cowboy, a zombie-like figure, a police officer, and a robot, set against a backdrop of a saloon. The PlayStation Move controller is prominently displayed, indicating its necessity for gameplay. The PEGI 12 rating is visible, signifying content suitable for ages 12 and over.

SETUP GUIDE

To begin playing *The Shoot*, ensure you have the following:

- A PlayStation 3 console.
- A PlayStation Move motion controller.
- A PlayStation Eye camera (required for PlayStation Move functionality).
- *The Shoot* game disc.

Connecting Your PlayStation Move System:

1. Connect the PlayStation Eye camera to a USB port on your PlayStation 3 console.
2. Ensure your PlayStation Move motion controller is charged and paired with your PS3. Refer to your PlayStation Move controller manual for pairing instructions if needed.
3. Insert The Shoot game disc into your PS3 console.
4. Follow any on-screen prompts for initial setup or calibration.

OPERATING INSTRUCTIONS

Gameplay Basics:

The Shoot is a rail shooter where you use the PlayStation Move controller to aim and fire at targets on screen. The game features various movie-themed sets and scenarios.

- **Aiming:** Point the PlayStation Move controller at the screen to control your on-screen reticle.
- **Firing:** Press the T button on the Move controller to shoot.
- **Reloading:** Perform a quick flick of the Move controller downwards or away from the screen to reload your weapon.
- **Special Moves:** The game may introduce special abilities or power-ups that can be activated through specific gestures or button presses.

Game Modes:

Explore different game modes, including a campaign mode with various levels and challenges. The game supports single-player and co-operative multiplayer modes.

Note: Some levels or features may need to be unlocked by playing through the single-player campaign before they become available in multiplayer or other modes.

GAME CARE AND HANDLING

To ensure the longevity of your game disc and console, please follow these guidelines:

- Handle the game disc by its edges to avoid fingerprints and scratches.
- Store the disc in its original case when not in use.
- Keep the disc away from direct sunlight, extreme temperatures, and high humidity.
- Clean the disc with a soft, lint-free cloth, wiping from the center outwards if necessary. Do not use abrasive cleaners.

TROUBLESHOOTING

Problem	Possible Cause	Solution
PlayStation Move calibration issues.	Improper lighting, camera placement, or controller interference.	Ensure adequate lighting in the play area. Position the PlayStation Eye camera correctly (refer to its manual). Recalibrate the Move controller through the PS3 system settings or within the game's options. Avoid reflective surfaces.

Problem	Possible Cause	Solution
Game disc not reading.	Dirty or scratched disc, console disc drive issue.	Clean the disc gently with a soft cloth. Try another game disc to check if the console's drive is functioning correctly.
Game freezes or crashes.	Software glitch, console overheating, corrupted game data.	Restart the PS3 console. Ensure the console has proper ventilation. If issues persist, try deleting and reinstalling game data (not save data).

SPECIFICATIONS

- **Platform:** PlayStation 3
- **Required Peripherals:** PlayStation Move Motion Controller, PlayStation Eye Camera
- **Rated:** Ages 12 & Over (PEGI)
- **Language:** English
- **Item Model Number:** 9159872
- **ASIN:** B003UESJTC
- **Package Dimensions:** 17.2 x 13.6 x 1.6 cm
- **Item Weight:** 120 g

SUPPORT AND WARRANTY

For technical support, game updates, or warranty information, please visit the official PlayStation support website or contact Sony customer service. Keep your proof of purchase for any warranty claims.

Official PlayStation Support: www.playstation.com/support/