

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [CubicFun](#) /

› [CubicFun 3D Puzzle Sydney Opera House C067H Instruction Manual](#)

CubicFun C067H

CubicFun 3D Puzzle Sydney Opera House C067H Instruction Manual

Brand: CubicFun | Model: C067H

1. INTRODUCTION AND OVERVIEW

The CubicFun 3D Puzzle Sydney Opera House (Model C067H) offers an engaging and challenging building experience. This 58-piece puzzle allows you to construct a detailed replica of the iconic Sydney Opera House, providing hours of fun and a beautiful model for display. It is designed to enhance logical thinking and spatial awareness skills.

The puzzle is made from high-quality paper and expanded polystyrene (EPS) foam board, ensuring durability and a satisfying assembly process without the need for additional tools or glue.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

This product contains small components that may pose a choking hazard. Adult supervision is recommended for younger users. The manufacturer recommended age for this puzzle is 8 years and up.

3. PACKAGE CONTENTS

Your CubicFun 3D Puzzle Sydney Opera House package should contain the following:

- 58 pre-cut puzzle pieces made from paper and EPS foam board.
- Detailed instruction sheet with visual guides.

Please check all contents upon opening the package. If any pieces are missing or damaged, please contact customer support.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the CubicFun 3D Puzzle Sydney Opera House typically takes between 120 to 150 minutes. No tools or glue are required for assembly.

1. **Unpack and Organize:** Carefully remove all puzzle sheets from the box. Identify the instruction sheet and familiarize yourself with the overall structure.
2. **Identify Pieces:** Each puzzle piece is numbered or uniquely shaped. Refer to the instruction sheet for a diagram of all pieces.
3. **Remove Pieces:** Gently push out the pre-cut foam puzzle pieces from their sheets. Be careful not to tear or bend them.
4. **Follow Step-by-Step Guide:** The instruction sheet provides a sequential guide for assembly. Match the piece numbers and shapes as indicated.
5. **Interlock Pieces:** Connect the pieces by interlocking the tabs and slots. Ensure a snug fit for stability.
6. **Build Sections:** Assemble smaller sections first, then combine them to form larger parts of the Sydney Opera House model.
7. **Final Assembly:** Once all sections are complete, carefully join them to form the final 3D model.





Image: Visual guide showing the step-by-step assembly process of the CubicFun Sydney Opera House 3D puzzle.




Image: The instruction sheet included with the CubicFun Sydney Opera House 3D puzzle, detailing piece layouts and historical information.

5. OPERATING AND DISPLAY

Once assembled, your CubicFun 3D Puzzle Sydney Opera House is ready for display. Place it on a flat, stable surface in your home or office. The model is designed to be a decorative piece and a testament to your building skills.



Image: The complete CubicFun 3D Puzzle Sydney Opera House model displayed next to its packaging, showing the final product and its dimensions.



Image: A close-up view of the fully assembled CubicFun 3D Puzzle Sydney Opera House, highlighting its intricate details and the 58 pieces.

6. MAINTENANCE

To maintain the appearance and integrity of your 3D puzzle model:

- Keep the model in a dry environment, away from direct sunlight and excessive humidity, to prevent material degradation.
- Dust the model gently with a soft, dry cloth or a soft brush. Avoid using water or cleaning solutions.

- Handle the model with care to prevent bending or breaking delicate pieces.

7. TROUBLESHOOTING

If you encounter difficulties during assembly:

- **Pieces not fitting:** Double-check the piece numbers and orientation against the instruction sheet. Ensure you are not forcing pieces, as this can cause damage.
- **Model instability:** Ensure all interlocking tabs are fully engaged. Sometimes gently pressing down on assembled sections can improve stability.
- **Missing pieces:** Carefully re-check the puzzle sheets and packaging. If a piece is genuinely missing, contact CubicFun customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	C067H
Brand	CubicFun
Number of Pieces	58
Assembled Dimensions (L x W x H)	38.5 x 25.5 x 15 cm (approx. 15.2 x 10.0 x 5.9 inches)
Material	Paper and Expanded Polystyrene (EPS) Foam Board
Assembly Time	120-150 minutes
Recommended Age	8 years and up
Educational Objectives	Logical Thinking, Spatial Awareness
Assembly Required	Yes
Batteries Required	No
UPC	804551072819

9. WARRANTY AND SUPPORT

Specific warranty information for the CubicFun 3D Puzzle Sydney Opera House C067H is not provided in the product details. For any inquiries regarding product defects, missing parts, or assembly assistance, please refer to the contact information provided on the product packaging or visit the official CubicFun website for customer support.

