

Logitech 920-002719

Logitech USB Keyboard K200 Instruction Manual

Model: 920-002719 | Brand: Logitech

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Logitech USB Keyboard K200. Designed for comfortable and quiet typing, this keyboard features a spill-resistant design, durable easy-to-read keys, and sturdy adjustable tilt legs. It offers a plug-and-play experience, compatible with Windows XP, Vista, or 7.



Figure 1: Top-down view of the Logitech USB Keyboard K200, showcasing its full layout and media keys.

SETUP

The Logitech USB Keyboard K200 is designed for simple plug-and-play installation. No additional software or drivers are typically required for basic functionality.

Package Contents

- Logitech USB Keyboard K200
- Quick Start Guide



Figure 2: The retail packaging for the Logitech USB Keyboard K200, indicating included items.

Connecting the Keyboard

1. Locate an available USB port on your computer.
2. Insert the USB connector of the Logitech K200 keyboard into the USB port.
3. Your operating system (Windows XP, Vista, or 7) will automatically detect and install the necessary drivers. This process may take a few moments.
4. Once the installation is complete, the keyboard is ready for use.

For optimal comfort, you can adjust the tilt of the keyboard using the sturdy adjustable tilt legs located on the underside of the keyboard.



Figure 3: Side view of the Logitech K200 keyboard, illustrating the adjustable tilt legs for ergonomic positioning.

OPERATING THE KEYBOARD

The Logitech K200 keyboard features a standard QWERTY layout along with a dedicated numeric keypad and a row of convenient media and hot keys.

Standard Keys

All standard alphanumeric, function (F1-F12), navigation, and numeric keypad keys operate as expected with your computer's operating system and applications.

Media and Hot Keys

Located above the function keys, these dedicated keys provide quick access to common functions:

- **Play/Pause:** Controls media playback.
- **Mute:** Toggles audio mute.
- **Volume Down:** Decreases audio volume.
- **Volume Up:** Increases audio volume.

- **Home:** Opens your default web browser to its home page.
- **Email:** Opens your default email client.
- **PC Sleep:** Puts your computer into sleep mode.
- **Calculator:** Launches the calculator application.



Figure 4: Detailed view of the dedicated media and hot keys located at the top of the Logitech K200 keyboard.

MAINTENANCE

Proper care and maintenance will extend the lifespan of your Logitech K200 keyboard.

Cleaning

- Disconnect the keyboard from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- Do not spray liquid directly onto the keyboard.
- For dust and debris between keys, use compressed air.
- The keyboard features a spill-resistant design, meaning it can withstand minor liquid spills. In case of a spill, immediately disconnect the keyboard, turn it upside down to drain liquid, and allow it to dry completely before reconnecting.

Storage

Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

TROUBLESHOOTING

If you encounter issues with your Logitech K200 keyboard, try the following solutions:

| Problem | Solution |
|---------------------------------------|---|
| Keyboard is not responding. | Ensure the USB connector is securely plugged into a working USB port on your computer. Try plugging the keyboard into a different USB port. Restart your computer. Test the keyboard on another computer to determine if the issue is with the keyboard or the computer. |
| Keys are sticking or not registering. | Clean the keyboard as described in the Maintenance section, paying attention to the affected keys. Ensure no debris is lodged under the keys. |
| Media keys are not working. | Ensure your operating system and media player software are up to date. Check if any other software is conflicting with the keyboard's media key functions. |

SPECIFICATIONS

| Feature | Detail |
|-------------------------|---|
| Brand | Logitech |
| Model Number | 920-002719 |
| Connectivity Technology | USB |
| Keyboard Description | Multimedia |
| Compatible Devices | Laptop (and Desktop PCs) |
| Product Dimensions | 7.25 x 18 x 1.25 inches |
| Item Weight | 1.08 pounds |
| Special Feature | One touch Internet Keys, Spill-resistant design, Adjustable tilt legs |
| Color | One Color (Black) |
| Material | Acrylonitrile Butadiene Styrene |
| Language | English |
| Date First Available | July 9, 2010 |

IMPORTANT INFORMATION

Legal Disclaimer

No refunds.

Please note that this product is subject to the terms and conditions of sale at the time of purchase. For specific return or warranty inquiries, please refer to your purchase receipt or contact the retailer directly.

© 2024 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners.
For further support, visit the [official Logitech support website](#).



[Logitech Product Catalog 2010-11: Mice, Keyboards, Audio, Video, and Gaming Gear](#)

Explore the comprehensive Logitech Product Catalog for 2010-11, featuring a wide range of computer peripherals, audio solutions, webcams, gaming accessories, and home entertainment devices.

lang:en **score:18** filesize: 6.06 M page_count: 64 document date: 2010-11-04