

[Manuals.plus](#) /

› [Household Essentials](#) /

› Household Essentials 6028-1 Rolling Laundry Cart with Hanging Bar - Chrome Finish Instruction Manual

Household Essentials 6028-1

Household Essentials 6028-1 Rolling Laundry Cart with Hanging Bar

Instruction Manual

INTRODUCTION

Thank you for choosing the Household Essentials 6028-1 Rolling Laundry Cart. This manual provides essential information for the safe assembly, operation, and maintenance of your new laundry cart. Please read all instructions carefully before use and retain this manual for future reference.

SAFETY INFORMATION

- Ensure all parts are securely fastened before use.
- Do not overload the cart or hanging bar beyond its intended capacity.
- Keep hands and fingers clear of moving parts, especially during assembly and when operating the wheels.
- Use the wheel locks to secure the cart in place when loading, unloading, or when stationary.
- This product is designed for indoor use only.

PARTS LIST AND DIMENSIONS

Before assembly, verify that all components are present and undamaged. Refer to the diagram below for part identification and overall dimensions.



Image: Detailed diagram of the Household Essentials 6028-1 Rolling Laundry Cart, showing all major components and their respective measurements, including the basket, lower shelf, main frame, and hanging bar. The overall height is 68.5 inches, width 24.625 inches, and depth 20.685 inches.

The cart includes a main frame, a large wire basket, a lower wire shelf, a vertical support pole, a curved hanging bar, and four swivel wheels with two locking mechanisms. All necessary hardware for assembly is provided.

ASSEMBLY INSTRUCTIONS

Assembly is required. Follow these steps carefully to ensure proper setup.

1. **Attach Wheels:** Insert the four swivel wheels into the designated sockets at the bottom of the main cart frame. Apply firm pressure until each wheel clicks securely into place. Two of the wheels feature locking mechanisms.
2. **Secure Lower Shelf:** Position the lower wire shelf onto the frame's designated supports. Ensure it sits flat and is stable.
3. **Install Main Basket:** Place the large wire basket onto the upper frame of the cart. Ensure it aligns with the frame and is stable.

4. **Attach Vertical Support Pole:** Insert the vertical support pole into the central opening of the main basket and secure it to the cart frame using the provided hardware. Ensure the pole is oriented correctly, with the attachment point for the hanging bar facing the desired direction.
5. **Mount Hanging Bar:** Attach the curved hanging bar to the top of the vertical support pole using the provided screws. Ensure it is firmly secured and can support garments.



Image: A close-up view illustrating how the wire basket attaches to the main frame, showing the secure connection points.



Image: A detailed view of the hanging bar's connection to the vertical support pole, highlighting the secure fastening mechanism.

OPERATING INSTRUCTIONS

The Household Essentials 6028-1 Laundry Cart is designed for ease of use in various laundry tasks.

- **Moving the Cart:** The four swivel wheels allow for smooth movement across different floor surfaces, including carpet and hard floors. Push or pull the cart by the frame or the vertical pole.
- **Locking Wheels:** To prevent the cart from moving, engage the locks on the two designated wheels. Push down the lever on each locking wheel until it clicks into the 'ON' position. To unlock, lift the lever to the 'OFF' position.

- **Using the Basket:** The large wire basket is suitable for holding multiple loads of laundry, either dirty or clean.
- **Utilizing the Hanging Bar:** The sturdy hanging bar is ideal for hanging garments directly from the dryer to prevent wrinkles, or for air-drying delicate items.
- **Lower Shelf Functionality:** The bottom shelf provides additional storage for folded clothes, laundry detergents, fabric softeners, or other laundry accessories.



Image: A close-up view of one of the swivel wheels, clearly showing the 'ON' and 'OFF' positions of the locking mechanism.



Image: The Household Essentials 6028-1 Laundry Cart positioned in a laundry room, demonstrating its use with clothes in the basket and hanging on the bar, next to a washing machine.

MAINTENANCE

To ensure the longevity and optimal performance of your laundry cart, follow these maintenance guidelines:

- **Cleaning:** Wipe down the chrome finish with a soft, damp cloth and a mild detergent. Avoid abrasive cleaners or scouring pads, which can damage the finish. Dry thoroughly after cleaning.
- **Wheel Care:** Periodically check the wheels for any lint or debris that may hinder smooth rolling. Clean as needed.
- **Fasteners:** Occasionally inspect all screws and connections to ensure they remain tight. Tighten any loose fasteners to maintain stability.

TROUBLESHOOTING

If you encounter any issues with your laundry cart, refer to the following common problems and solutions:

- **Cart does not roll smoothly:**
 - Check if the wheel locks are engaged. Disengage them if necessary.
 - Inspect wheels for debris (lint, hair) and remove any obstructions.
 - Ensure wheels are fully inserted into their sockets.
- **Cart feels unstable or wobbly:**
 - Verify that all assembly screws and connections are tightened.
 - Ensure the basket and lower shelf are correctly seated on the frame.
 - Distribute weight evenly in the basket and on the hanging bar.
- **Hanging bar tips when loaded:**
 - Ensure the hanging bar is securely fastened to the vertical pole.
 - Avoid overloading one side of the hanging bar; distribute garments evenly.

SPECIFICATIONS

Feature	Detail
Model Number	6028-1
Product Dimensions (D x W x H)	20.69" x 24.63" x 67.5"
Material	Alloy Steel (Chrome Finish)
Item Weight	15 Pounds
Number of Wheels	4 (Swivel, 2 with locks)
Number of Shelves	1 (Lower Shelf)
Assembly Required	Yes

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your purchase documentation or visit the official Household Essentials website. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question