

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [KitchenAid](#) /

› [KitchenAid BCG111OB Blade Coffee Grinder User Manual](#)

KitchenAid BCG111OB

KitchenAid BCG111OB Blade Coffee Grinder User Manual

MODEL: BCG111OB

1. Introduction

The KitchenAid Blade Coffee Grinder is designed to quickly and easily grind whole coffee beans for an exceptional brew. Its one-touch operation, on-bowl measurement markings, stainless steel blade, and clear cover simplify the grinding process. This manual provides essential information for the safe and efficient use of your grinder.



Image 1: The KitchenAid BCG111OB Blade Coffee Grinder.

2. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the coffee grinder.
- Do not immerse the motor base in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner.
- The use of attachments not recommended or sold by KitchenAid may cause fire, electric shock, or injury.

- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use appliance for other than intended household use.
- This product contains a Proposition 65 warning.

3. Product Features

- **One-Touch Control:** Easy operation by pushing down on the cover to begin and releasing to stop. The clear cover allows you to view beans and stop grinding when your desired consistency is reached.
- **Powerful Stainless Steel Blade:** Performs powerfully, quickly grinding enough whole coffee beans to make up to 12 cups of coffee.
- **4 oz. Stainless Steel Bowl:** Features markings to measure beans needed for 4, 8, 10, or 12 cups of coffee. Removable for easy transfer to your coffee maker.
- **Compact Design:** The grinder's compact size allows for easy storage.



Image 2: One-touch control for easy grinding.



Image 3: Durable stainless steel blade for efficient grinding.

4. Parts and Assembly

Your KitchenAid Blade Coffee Grinder consists of three main parts:

1. **Motor Base:** The main unit containing the motor and power cord.
2. **Grinding Bowl:** A removable 4 oz. stainless steel bowl with a blade for grinding. It features measurement markings for convenience.
3. **Clear Cover:** A transparent lid that activates the grinding mechanism when pressed down and allows you to monitor the grinding process.



Image 4: Removable grinding bowl for easy cleaning and transfer.

5. Operating Instructions

Follow these steps to grind your coffee beans or spices:

1. **Prepare the Grinder:** Ensure the grinding bowl is clean and properly seated in the motor base. Align the indentations on the bowl with the corresponding marks on the base, then rotate clockwise until secure.
2. **Add Beans/Spices:** Fill the grinding bowl with whole coffee beans or spices. Use the internal measurement markings (4, 8, 10, or 12 cups) as a guide. Do not overfill.
3. **Secure the Cover:** Place the clear cover onto the grinding bowl. Ensure it is properly aligned and seated. The grinder will not operate unless the cover is correctly in place.
4. **Begin Grinding:** Plug the grinder into a standard electrical outlet. Press down firmly on the clear cover to activate the grinding mechanism.
5. **Monitor Grinding:** Observe the beans through the clear cover. Continue grinding until your desired consistency is achieved. For a coarser grind, grind for a shorter duration; for a finer grind, continue for a longer period.
6. **Stop Grinding:** Release pressure from the clear cover to stop the grinding action.
7. **Remove Grounds:** Unplug the grinder. Carefully remove the clear cover, then lift out the grinding bowl. Pour the freshly ground coffee or spices into your desired container.



Image 5: The grinder ready for use with whole coffee beans.



Image 6: Internal markings in the grinding bowl indicate quantities for 4, 8, 10, or 12 cups of coffee.

Video 1: Demonstration of the KitchenAid Blade Coffee Grinder in use, showing the grinding process and ease of operation.

6. Cleaning and Maintenance

Proper cleaning ensures the longevity and performance of your grinder:

- **Unplug Before Cleaning:** Always ensure the grinder is unplugged from the electrical outlet before cleaning.
- **Removable Parts:** The grinding bowl and clear cover are dishwasher safe for easy cleaning. Alternatively, wash them with warm, soapy water and rinse thoroughly.
- **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
- **Drying:** Ensure all parts are completely dry before reassembling or storing the grinder.



Image 7: Removable parts are dishwasher safe for convenient cleaning.

7. Troubleshooting

If your KitchenAid Blade Coffee Grinder is not operating as expected, please check the following:

- **Grinder Not Starting:** Ensure the power cord is securely plugged into a working electrical outlet. Verify that the clear cover is correctly placed and pressed down firmly to engage the safety switch.
- **Uneven Grinding:** Ensure you are not overfilling the grinding bowl. For best results, grind in short bursts and shake the grinder gently to redistribute beans if necessary.
- **Overheating:** If the grinder stops during operation, it may have overheated. Unplug the unit and allow it to cool down for at least 10-15 minutes before attempting to use it again.
- **Excessive Noise:** Check for any foreign objects in the grinding bowl. Ensure the grinding bowl is properly seated in the motor base.

If problems persist, please refer to the Warranty and Customer Support section.

8. Specifications

Specification	Detail
Model Number	BCG1110B

Brand	KitchenAid
Color	Onyx Black
Style	Grinder
Product Dimensions	4.2"L x 3.9"W x 8.7"H
Item Weight	2.6 pounds
Voltage	120 Volts
Material	Polycarbonate
Manufacturer	KitchenAid

9. Warranty and Customer Support

Your KitchenAid BCG111OB Blade Coffee Grinder comes with a **1-year hassle-free replacement warranty**.

For warranty claims, technical assistance, or any product-related inquiries, please contact KitchenAid Customer Service. Refer to the contact information provided in your product packaging or visit the official KitchenAid website for support.

Please have your model number (BCG111OB) and proof of purchase ready when contacting customer support.