EMG EMG J Set

EMG J Set Jazz Bass Pickup System User Manual

Model: EMG J Set

1. Product Overview

The EMG J Set is a high-quality active pickup system designed specifically for Jazz Bass guitars. It delivers a full-bodied sound with sweeping harmonic overtones and exceptional clarity, allowing bassists to achieve incredible tone while retaining traditional characteristics. This manual provides essential information for the proper installation, operation, and maintenance of your EMG J Set.



Image showing two black EMG J Set Jazz Bass pickups, designed for clear and full-bodied bass tone.

2. Setup and Installation

Proper installation is crucial for optimal performance of your EMG J Set. It is highly recommended that installation be performed by a qualified guitar technician if you are not experienced with electronics and soldering.

2.1 Tools and Materials

- Soldering iron and solder
- Wire cutters/strippers
- Small Phillips head screwdriver
- 9-volt battery (for active system power)
- Multimeter (optional, for testing connections)

2.2 Installation Steps

1. **Preparation:** Disconnect your bass from any amplifier. Carefully remove the old pickups and control plate, noting the existing wiring connections.
2. **Mounting:** Install the EMG J Set pickups into the pickup cavities. Ensure they are seated correctly and secured with the provided screws.
3. **Wiring:** Follow the wiring diagram provided with your EMG J Set for specific connections. This typically involves connecting the pickup wires to the volume and tone pots, output jack, and the 9-volt battery. Ensure all solder joints are clean and secure.
4. **Battery Connection:** Connect the 9-volt battery to the designated battery clip. The active circuitry of the EMG J Set requires a 9-volt power source to operate.
5. **Testing:** Before reassembling, connect your bass to an amplifier and test all controls (volume, tone) and both pickups to ensure they are functioning correctly and producing sound.
6. **Reassembly:** Once confirmed operational, carefully reassemble the control plate and secure all components.

3. Operation

The EMG J Set is designed to provide a wide range of tonal possibilities for your Jazz Bass. As active pickups, they offer a higher output and a broader frequency response compared to traditional passive pickups.

3.1 Tone Shaping

- **Volume Controls:** Use the individual volume controls for each pickup to blend their output and achieve different tonal characteristics.
- **Tone Control:** The tone control (typically a passive roll-off) allows you to adjust the high-frequency content, from bright and articulate to warm and mellow.
- **Playing Dynamics:** The clarity and dynamic range of the EMG J Set respond well to playing dynamics, allowing for expressive performances.

Experiment with different settings on your bass and amplifier to discover the full sonic potential of your EMG J Set.

4. Maintenance

Regular maintenance will ensure the longevity and consistent performance of your EMG J Set.

4.1 Cleaning

- Wipe the pickup covers with a soft, dry, lint-free cloth to remove dust and fingerprints.
- Avoid using abrasive cleaners or solvents, as these can damage the finish.

4.2 Battery Replacement

Since the EMG J Set is an active system, it requires a 9-volt battery for power. The battery life will vary depending on usage. If you notice a decrease in output, distortion, or no sound, the battery is likely depleted.

- Locate the battery compartment on your bass (often in a separate cavity or under the control plate).
- Disconnect the old 9-volt battery and replace it with a fresh one, ensuring correct polarity.

4.3 Connection Checks

Periodically check all wiring connections for looseness or corrosion, especially if you experience intermittent sound or noise. If necessary, re-solder any loose connections.

5. Troubleshooting

If you encounter issues with your EMG J Set, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from pickups	Dead 9V battery Loose wiring connection Faulty cable or amplifier	Replace 9V battery Check and re-solder all connections Test with different cable/amplifier
Weak or distorted sound	Low 9V battery Incorrect wiring Pickup height too low	Replace 9V battery Verify wiring against diagram Adjust pickup height closer to strings
Excessive hum or noise	Poor grounding Interference from external sources Faulty component	Check all ground connections Move away from electronic devices Consult a qualified technician

6. Specifications

Key specifications for the EMG J Set Jazz Bass Pickup System:

Feature	Detail
Model	EMG J Set
Type	Active Bass Pickups
Configuration	J-style (Neck and Bridge)
Color	Black
Power Requirement	9-volt battery
ASIN	B003Y580W8
UPC	654330400520
Item Weight	1 pound (approximate, for the set)
First Available	May 10, 2011

7. Warranty and Support

EMG products are manufactured to high standards and are typically covered by a manufacturer's warranty against defects in materials and workmanship. For specific warranty terms and conditions, please refer to the documentation included with your product or visit the official EMG website.

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact EMG customer service directly through their official website or authorized dealers. Providing your product model (EMG J Set) and purchase details will help expedite your support request.

Official EMG Website: www.emgpickups.com

© 2024 EMG Pickups. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question