

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Ingersoll](#) /

› [Ingersoll Men's IN2705WH Boonville Automatic Watch User Manual](#)

Ingersoll IN2705WH

Ingersoll Men's IN2705WH Boonville Automatic Watch User Manual

Model: IN2705WH

INTRODUCTION

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Ingersoll Men's IN2705WH Boonville Automatic Watch. This timepiece features a Caliber 416 automatic movement, a white skeleton dial, and a black genuine leather band. Please read this manual carefully to ensure proper use and longevity of your watch.



Figure 1: Ingersoll Men's IN2705WH Boonville Automatic Watch. This image displays the watch's front view, highlighting its white skeleton dial, stainless steel case, and black leather band.

SETUP

Unboxing

Carefully remove your watch from its packaging. Inspect the watch for any visible damage. The watch comes in a protective box.



Figure 2: Ingersoll Watch Packaging. This image shows the black Ingersoll watch box with the watch cushion inside, ready to hold the timepiece.

Initial Winding and Time Setting

1. **Winding:** As an automatic watch, it is powered by the motion of your wrist. For initial setup or if the watch has stopped, manually wind it by rotating the crown clockwise approximately 20-30 times while it is in the normal (pushed-in) position. This will provide enough power reserve to start the movement.
2. **Setting the Time:** Pull the crown out to the outermost position. Rotate the crown to set the hour and minute hands to the correct time. Push the crown back in to start the watch.

3. **Setting Subdials (if applicable):** The watch features chronograph subdials and a moon phase window. Refer to the operating section for detailed instructions on adjusting these functions.

Wearing the Watch

The watch is equipped with a deployment clasp with buckle closure on its genuine leather band.

1. Open the deployment clasp.
2. Place the watch on your wrist and adjust the buckle to a comfortable fit.
3. Close the deployment clasp securely. Ensure the watch is snug but not too tight, allowing for proper blood circulation and comfortable wear.



Figure 3: Ingersoll Watch on a wrist. This image demonstrates how the watch appears when worn, showcasing its size and fit.

OPERATING THE WATCH

Automatic Movement

Your Ingersoll IN2705WH watch is powered by an automatic mechanical movement (Caliber 416). This means it winds itself using the natural motion of your arm. When fully wound, it has a power reserve that allows it to run for a certain period (typically 36-40 hours) even when not worn. If the watch stops, simply wear it for a few hours or manually wind it as described in the Setup section.

Reading the Dial

- **Main Hands:** The central hour, minute, and second hands indicate the current time. The blue-lined luminous hands provide visibility in low light conditions.
- **Skeleton Dial:** The white skeleton dial allows you to view the intricate workings of the mechanical movement.
- **Chronograph Subdials:** The watch features a trio of chronograph subdials. These typically measure elapsed time (e.g., seconds, minutes, hours). Specific operation details for these subdials may vary; generally, pushers on the side of the case activate, stop, and reset the chronograph functions.
- **Moon Phase Window:** Located at 12 o'clock, this window displays the current phase of the moon. This is usually set by a dedicated pusher or by rotating the crown in a specific position.
- **Dual Time / Day-Night Indicator:** The watch includes dual time and day/night indicators, which are typically integrated into one of the subdials or a separate aperture. Consult the specific markings on your dial to interpret these functions.

MAINTENANCE

Cleaning

- **Case and Crystal:** Wipe the stainless steel case and mineral crystal dial window with a soft, dry, lint-free cloth. For stubborn smudges, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive materials.
- **Leather Band:** Clean the genuine leather band with a soft, slightly damp cloth. Do not immerse the leather band in water. Allow it to air dry completely away from direct sunlight or heat. Leather conditioners can be used periodically to maintain its suppleness.

Water Resistance

Your watch is water-resistant to 30 meters (99 feet) or 3 BAR. This rating means the watch is suitable for splashes or brief immersion in water, but **not** for swimming, showering, or diving. Always ensure the crown is fully pushed in before any contact with water. Prolonged exposure to water or steam can damage the watch.

Storage

When not wearing the watch, store it in a cool, dry place, preferably in its original box or a watch winder to keep the automatic movement running. Avoid exposing the watch to extreme temperatures, strong magnetic fields, or direct sunlight for extended periods.

TROUBLESHOOTING

- **Watch has stopped:** As an automatic watch, it requires motion to stay wound. If it has stopped, manually wind it by rotating the crown clockwise 20-30 times, then wear it regularly. If it still does not start, it may require servicing.
- **Time is inaccurate:** Mechanical watches can gain or lose a few seconds per day, which is normal. If the inaccuracy is significant (minutes per day), ensure the watch is fully wound. Exposure to strong magnetic fields can also affect accuracy; if suspected, a watchmaker can demagnetize it.
- **Condensation under crystal:** If you notice moisture or condensation under the crystal, this indicates a breach in the watch's water resistance. Stop using the watch immediately and seek professional servicing to prevent further damage to the movement.
- **Crown or pushers are stiff:** Do not force the crown or pushers. If they are difficult to operate, the watch may require cleaning or repair by a qualified watchmaker.

For issues not covered here, or if troubleshooting steps do not resolve the problem, it is recommended to contact a professional watch repair service or the seller.

SPECIFICATIONS

Feature	Detail
Model Number	IN2705WH
Movement Type	Automatic (Caliber 416)
Case Material	Stainless Steel
Case Diameter	44 mm

Feature	Detail
Case Thickness	14 mm
Band Material	Genuine Leather
Band Color	Black
Strap Width	22 mm
Dial Color	White (Skeleton)
Crystal Material	Mineral Crystal
Water Resistance	30 m (99 ft / 3 BAR)
Special Features	Skeleton Dial, Blue-lined Luminous Hands, Chronograph Subdials, Moon Phase Window, Dual Time, Day/Night Indicator
Clasp Type	Deployment Clasp with Buckle Closure
Item Weight	340 g

WARRANTY INFORMATION

The warranty type for this Ingersoll watch is "Contact seller of record". For any warranty claims or inquiries, please retain your proof of purchase and contact the seller from whom you purchased the watch directly. They will provide information regarding the specific warranty terms and conditions applicable to your purchase.

SUPPORT

Should you require further assistance, have questions about your watch's operation, or need professional servicing, please refer to the following:

- **Seller Contact:** For purchase-related support, warranty claims, or initial troubleshooting, contact the seller directly.
- **Authorized Service Centers:** For repairs or maintenance beyond basic user care, seek an authorized Ingersoll service center or a reputable watchmaker.
- **Online Resources:** Visit the official Ingersoll website for additional product information or FAQs.