

LIFETIME 4428

LIFETIME Fold-in-Half Adjustable Folding Table (Model 4428) Instruction Manual

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your LIFETIME Fold-in-Half Adjustable Folding Table, Model 4428.

1. PRODUCT OVERVIEW

The LIFETIME 4-Foot Light Commercial Fold-In-Half Adjustable Table is a versatile and durable solution for various needs. It features a 48-inch x 24-inch molded tabletop with a round folding frame. Designed for portability and convenience, this table offers multiple height settings to accommodate different activities and users.

Key Features:

- All-purpose table constructed of powder-coated steel and high-density polyethylene plastic.
- 48-inch x 24-inch molded tabletop with a white granite finish.
- Folds in half for easy storage and transport.
- Adjustable Height Settings: 22-inch, 24-inch, 29-inch, and 36-inch.
- Convenient carry handle for portability.
- Table weight: 19 lbs.
- Table Top Thickness: 1.4 inch.
- Frame tubing diameter: 25mm.
- Seating Capacity: 4.



Figure 1: The LIFETIME 4-Foot Fold-in-Half Adjustable Folding Table in its fully extended position.



BROAD LEG STANCE
STURDY AND STRONG



DURABLE CORNERS
IMPACT RESISTANT



FOOT CAPS
PROTECT YOUR FLOOR



ADJUSTABLE HEIGHT
22", 24", 29", 36"



FOLDS IN HALF
COMPACT AND PORTABLE



CARRY HANDLE
QUALITY COMFORT

Figure 2: Visual representation of the table's key features, highlighting its design and functionality.

2. SAFETY INFORMATION

CALIFORNIA PROPOSITION 65 WARNING: This product can expose you to chemicals including nickel, which is known to the State of California to cause cancer and birth defects or

other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Always ensure the table is placed on a stable, level surface before use. Do not exceed the maximum weight recommendation of 750 pounds. Keep fingers clear of folding mechanisms when setting up or taking down the table to prevent pinching.

3. SETUP AND ASSEMBLY

3.1. Unfolding the Table

1. Place the folded table on a flat surface with the carry handle facing upwards.
2. Unclasp the locking mechanism located on the side of the table.
3. Gently unfold the table halves until they lie flat. Ensure the central hinge is fully extended.
4. Flip the table over so the tabletop is facing down.
5. Extend each leg assembly outwards until they lock into place. Listen for a click to confirm the legs are securely locked.
6. Flip the table upright.




Figure 3: The table in its compact, folded position, ready for transport or storage.



Figure 4: The underside of the table, illustrating the leg structure and how they fold and lock.

Your browser does not support the video tag.

Video 1: Official demonstration of unfolding and setting up the Lifetime 4-Foot Folding Table.

3.2. Adjusting Table Height

The table offers four adjustable height settings: 22-inch, 24-inch, 29-inch, and 36-inch.

1. Locate the orange push-pins on each leg.
2. Press the push-pin on one leg and slide the lower leg section to the desired height. Ensure the pin snaps securely into one of the pre-drilled holes.
3. Repeat this process for all four legs, ensuring they are all set to the same height for stability.



Figure 5: The table adjusted to its highest setting, suitable for standing tasks.

4. OPERATION

This versatile table is suitable for a wide range of activities, both indoors and outdoors. Its stain-resistant surface makes it easy to clean, and its compact folded size allows for convenient storage and transport.

- Ideal for crafting, painting, dining, hobbies, and as an extra workspace.
- Comfortably seats up to 4 individuals.
- The lightweight design and integrated carry handle facilitate effortless movement and setup.



Figure 6: The table in use for outdoor activities, demonstrating its practical application.



Figure 7: The table's seating capacity, indicating it can comfortably accommodate four people.

5. MAINTENANCE

To maintain the appearance and longevity of your LIFETIME folding table, follow these simple care instructions:

- Wipe the tabletop and frame with a damp cloth after each use.
- For stubborn stains, use a mild soap solution and a soft brush, then rinse thoroughly and dry.
- Avoid using abrasive cleaners or harsh chemicals, as these can damage the surface.
- Store the table in a dry, protected area when not in use to prevent exposure to extreme weather conditions.

6. TROUBLESHOOTING

- **Issue: Table feels wobbly at higher settings.**
Solution: Ensure all four legs are extended to the same height setting and that the push-pins are fully engaged and locked into their respective holes. Verify the table is on a flat, even surface.
- **Issue: Tabletop sections do not align perfectly when unfolded.**
Solution: While the table is designed to be flat, minor variations can occur. Ensure the central hinge is fully extended and locked. Applying gentle pressure across the tabletop may help settle the sections.
- **Issue: Difficulty folding or unfolding the table.**
Solution: Check for any obstructions in the folding mechanism or leg hinges. Ensure the locking clasps are fully disengaged before attempting to fold the table. Apply gentle, even pressure.

7. PRODUCT SPECIFICATIONS

Specification	Detail
Brand	LIFETIME
Model Number	4428
Product Dimensions (D x W x H)	24"D x 48"W x 22"H (lowest height)
Maximum Weight Recommendation	750 Pounds
Color	White Granite
Frame Material Type	Powder-coated Steel

Specification	Detail
Top Material Type	High-Density Polyethylene Plastic
Item Weight	19.2 Pounds
Number of Height Positions	3 (22-inch, 24-inch, 29-inch, 36-inch)
Is Foldable	Yes
Seating Capacity	4
Indoor/Outdoor Usage	Outdoor
UPC	841101002520

8. WARRANTY AND SUPPORT

Warranty Information:

This LIFETIME product comes with a **2-year limited manufacturer warranty**. Please retain your proof of purchase for warranty claims.

Customer Support:

For further assistance, product inquiries, or to report any issues, please visit the official LIFETIME website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's website.