



[Manuals.plus](#) /

> [Hampton Bay](#) /

> Hampton Bay 15 In. Flushmount Dome Instruction Manual

## Hampton Bay 385 589

# Hampton Bay 15 In. Flushmount Dome Instruction Manual

Model: 385 589

[Introduction](#)

[Safety Information](#)

[Package Contents](#)

[Setup & Installation](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

## 1. INTRODUCTION

Thank you for purchasing the Hampton Bay 15 In. Flushmount Dome light fixture. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new lighting product. Please read this manual thoroughly before beginning installation and retain it for future reference.

The Hampton Bay 3-Light Flushmount White Ceiling Dome Light features a frosted swirl pattern on its glass dome, offering a classic and understated style suitable for hallways or rooms.

## 2. SAFETY INFORMATION

**WARNING:** Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installing or servicing.

- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Contact a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- Use only UL or ETL listed wire connectors.
- Do not exceed the recommended wattage for bulbs. Refer to the fixture's marking for maximum wattage.
- Handle glass components with care to prevent breakage.
- Ensure the fixture is securely mounted to a structural element of the ceiling.
- Keep flammable materials away from the light fixture.

## 3. PACKAGE CONTENTS

Verify that all parts listed below are included in your package. If any part is missing or damaged, do not attempt to

assemble, install, or operate the product. Contact customer service for assistance.

- Light Fixture Base
- Glass Dome
- Finial
- Mounting Hardware (screws, wire nuts, mounting bracket)
- Instruction Manual



Figure 1: Hampton Bay 15 In. Flushmount Dome Light Fixture. This image shows the complete assembled light fixture, featuring a white base and a frosted glass dome with a subtle swirl pattern, illuminated from within.

## 4. SETUP & INSTALLATION

---

### 4.1. Tools Required (Not Included)

- Phillips Head Screwdriver
- Flat Head Screwdriver
- Wire Strippers
- Electrical Tape
- Safety Glasses
- Ladder (if necessary)

### 4.2. Pre-Installation

1. **Turn off power:** Before starting installation, ensure the power to the circuit is turned off at the main fuse box or circuit breaker.
2. **Prepare the area:** Clear the work area and ensure you have adequate lighting.
3. **Unpack contents:** Carefully remove all components from the packaging and inspect them for any damage.

### 4.3. Mounting the Fixture

1. **Attach mounting bracket:** Secure the mounting bracket to the electrical junction box in the ceiling using the provided screws. Ensure the bracket is firmly attached.
2. **Identify wires:** From the junction box, identify the following wires:
  - Black (Hot)
  - White (Neutral)
  - Green or Bare Copper (Ground)

From the fixture, identify the corresponding wires.

3. **Make electrical connections:**

- Connect the **black** wire from the fixture to the **black** (hot) wire from the junction box using a wire nut.
- Connect the **white** wire from the fixture to the **white** (neutral) wire from the junction box using a wire nut.
- Connect the **ground** wire from the fixture to the **ground** wire from the junction box (or to the green ground screw on the mounting bracket) using a wire nut.

Ensure all connections are secure and covered with wire nuts. Wrap electrical tape around wire nuts for added security if desired.

4. **Tuck wires:** Carefully tuck all connected wires into the junction box.
5. **Attach fixture base:** Align the holes in the fixture base with the screws on the mounting bracket. Secure the fixture base to the mounting bracket using the decorative nuts or screws provided.
6. **Install bulbs:** Screw the appropriate type and wattage of bulbs (not included) into the sockets. Refer to the fixture's label for maximum wattage.
7. **Attach glass dome:** Carefully place the glass dome onto the fixture base. Secure it by screwing the finial onto the threaded rod extending from the center of the fixture. Do not overtighten.

## 5. OPERATING INSTRUCTIONS

---

Once the fixture is securely installed and bulbs are in place, restore power at the main fuse box or circuit breaker. The light fixture can then be operated using the standard wall switch connected to the circuit.

## 6. MAINTENANCE

---

### 6.1. Cleaning

- Always turn off power to the fixture and allow it to cool before cleaning.
- Wipe the fixture with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or glass.

### 6.2. Bulb Replacement

- Turn off power to the fixture at the circuit breaker.
- Allow bulbs to cool completely before touching them.
- Unscrew the finial and carefully remove the glass dome.
- Unscrew the old bulbs and replace them with new bulbs of the same type and wattage (or lower). Do not exceed the maximum wattage specified on the fixture.
- Reattach the glass dome and secure it with the finial.
- Restore power.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Corrective Action
Light does not turn on.	<ul style="list-style-type: none"><li>• Power is off.</li><li>• Loose wire connections.</li><li>• Faulty bulb.</li><li>• Faulty wall switch.</li></ul>	<ul style="list-style-type: none"><li>• Check circuit breaker/fuse.</li><li>• Verify all wire connections are secure.</li><li>• Replace bulb.</li><li>• Consult a qualified electrician.</li></ul>
Flickering light.	<ul style="list-style-type: none"><li>• Loose bulb.</li><li>• Incorrect bulb type/wattage.</li><li>• Loose wire connections.</li></ul>	<ul style="list-style-type: none"><li>• Tighten bulb.</li><li>• Ensure correct bulb is used.</li><li>• Check wire connections.</li></ul>
Glass dome is difficult to remove/attach.	<ul style="list-style-type: none"><li>• Finial overtightened.</li><li>• Dome misaligned.</li></ul>	<ul style="list-style-type: none"><li>• Loosen finial gently.</li><li>• Ensure dome is seated correctly before tightening finial.</li></ul>

## 8. SPECIFICATIONS

- **Brand:** Hampton Bay
- **Model Number:** 385 589
- **Fixture Type:** Flush Mount Ceiling Light
- **Color:** White
- **Shade Material:** Glass
- **Number of Light Sources:** 3
- **Voltage:** 120 Volts
- **Power Source:** Corded Electric
- **Product Dimensions (L x W x H):** 6.7 x 16.25 x 16.13 inches
- **Item Weight:** 0.01 Ounces
- **Installation Type:** Flush Mount
- **Room Type:** Hallway (suitable for various rooms)

## 9. WARRANTY & SUPPORT

This Hampton Bay product is manufactured to high-quality standards and is backed by a manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact the retailer. For technical support or replacement parts, please contact Hampton Bay customer service.

**Manufacturer:** The Home Depot

