**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Janome TRTBB2684

# Janome 1/4 Inch Sewing Machine Foot Instruction Manual

## Introduction

This manual provides instructions for the proper installation, operation, and maintenance of the Janome 1/4 Inch Sewing Machine Foot (Part Number 200318000, Model TRTBB2684). This accessory is designed to assist in achieving precise 1/4 inch seam allowances for various sewing projects, including quilting and topstitching.

Please read these instructions carefully before using the product to ensure safe and effective operation.

## Product Overview





Image 1: Janome 1/4 inch Seam Foot in its retail packaging, displaying the product name and compatibility information.



Image 2: Close-up view of the Janome 1/4 inch Seam Foot, showing its metal construction, the guide, and the snap-on attachment mechanism.

The Janome 1/4 Inch Sewing Machine Foot is a specialized presser foot designed to help sewers achieve consistent 1/4 inch seam allowances. It features a metal construction with a built-in guide to ensure accuracy, making it ideal for quilting, patchwork, and precise topstitching.

## Setup and Installation

1. **Compatibility Check:** Ensure your sewing machine is a Janome, Kenmore, or New Home model that accepts snap-on presser feet. This foot is designed for such systems.
2. **Safety First:** Turn off and unplug your sewing machine before attempting to change any accessories.
3. **Raise Presser Foot:** Use the presser foot lifter lever to raise the current presser foot to its highest position.
4. **Remove Existing Foot:** If another presser foot is attached, locate the release button or lever on the back of the presser foot holder and press it to detach the foot.
5. **Attach 1/4 Inch Foot:** Position the Janome 1/4 Inch Sewing Machine Foot so that its crossbar aligns directly under the groove of the presser foot holder.
6. **Secure Attachment:** Slowly lower the presser foot lifter lever. The foot should snap securely into place. Gently tug on the foot to confirm it is firmly attached before proceeding.

## Operating Instructions

### Achieving a Consistent 1/4 Inch Seam

- **Fabric Alignment:** Place your fabric under the presser foot. Align the raw edge of your fabric precisely with the right-hand guide on the 1/4 inch foot. This guide acts as a consistent reference point.
- **Needle Position:** For most applications, ensure your sewing machine's needle is in the center position. This will ensure the stitch line is exactly 1/4 inch from the guide.
- **Sewing Technique:** Begin sewing slowly, keeping the fabric edge consistently against the guide. Avoid pushing or pulling the fabric, as the machine's feed dogs are designed to move it evenly.

### Applications

- **Quilting and Patchwork:** This foot is indispensable for piecing quilt blocks, where accurate 1/4 inch seams are critical for blocks to fit together correctly.
- **Topstitching:** Use the guide to create perfectly straight and evenly spaced topstitching lines, enhancing the professional finish of your projects.
- **Flat-Felled Seams:** The guide can also be beneficial when creating flat-felled seams, especially in areas where needle plate markings are not easily visible.

## Maintenance

- **Cleaning:** Regularly clean the presser foot to remove lint, dust, and fabric fibers that may accumulate. Use a soft brush or a lint roller. Avoid using water or chemical cleaners directly on the foot.
- **Storage:** Store the 1/4 inch foot in a dry, clean environment. Keeping it in its original packaging or a dedicated sewing accessory box will protect it from damage and prevent loss.
- **Inspection:** Periodically inspect the foot for any signs of wear, bending, or damage. A damaged foot can lead to inconsistent stitching or potential damage to your sewing machine. Replace if necessary.

## Troubleshooting

- **Foot Does Not Fit Securely:**
  - Ensure your sewing machine is compatible with snap-on presser feet.
  - Verify that the foot's crossbar is correctly aligned with the presser foot holder's groove.
  - Consult your sewing machine's instruction manual for specific guidance on attaching presser feet.
- **Seams Are Not Exactly 1/4 Inch:**
  - Confirm that the raw edge of your fabric is consistently aligned with the guide on the foot throughout the entire seam.
  - Check your machine's needle position; it should typically be centered for this foot.
  - Ensure proper thread tension for both the upper thread and bobbin thread.
- **Needle Hits the Presser Foot:**
  - Immediately stop sewing.
  - Verify the presser foot is correctly and securely installed.
  - Check that your needle is straight and not bent.
  - Ensure the needle position is set to straight stitch (center position) and not a zigzag or other stitch that might cause the needle to strike the foot.

## Specifications

| | |
|---|---|
| **Part Number** | Janome Part Number 200318000 |
| **Model Number** | TRTBB2684 |
| **Material** | Metal construction |
| **Weight** | Approximately 0.317 ounces (9 grams) |
| **Package Dimensions** | 5.91 x 2.56 x 0.87 inches |
| **Compatibility** | Janome, Kenmore, and New Home sewing machines that accept snap-on presser feet |
| **UPC** | 732212000812 |

## Warranty Information

Specific warranty information for the Janome 1/4 Inch Sewing Machine Foot is not provided within this manual. For details regarding warranty coverage, terms, and conditions, please refer to your original purchase documentation or contact Janome customer support directly.

## Customer Support

Should you require further assistance, have questions about your Janome 1/4 Inch Sewing Machine Foot, or need to locate an authorized service center, please utilize the following resources:

- **Official Janome Website:** Visit the official Janome website for product information, FAQs, and support contact details.
- **Janome Store on Amazon:** For additional Janome products and resources, you may visit the official Janome store: Janome Store


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B00405WY46**

More documents and user manuals: **https://manuals.plus/**