

## Acctim 12342

# Acctim Auric 12342 Superbrite Crescendo Digital Alarm Clock User Manual

Model: 12342

## INTRODUCTION

---

Thank you for purchasing the Acctim Auric 12342 Superbrite Crescendo Digital Alarm Clock. This manual provides detailed instructions for the setup, operation, and maintenance of your new alarm clock. Please read this manual thoroughly before use and retain it for future reference.

## IMPORTANT SAFETY INFORMATION

---

- Do not expose the unit to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the unit to strong impacts.
- Do not attempt to disassemble or modify the unit. This will void the warranty.
- Use only the specified battery type (2 x AA batteries).
- Dispose of old batteries responsibly according to local regulations.
- Keep out of reach of children.

## PACKAGE CONTENTS

---

- Acctim Auric 12342 Digital Alarm Clock
- User Manual (this document)

**Note:** 2 x AA batteries are required and are **not** included in the package.

## PRODUCT FEATURES

---



**Image 1:** Front view of the Acctim Auric 12342 digital alarm clock, showcasing its large LCD display and compact design.

- Large digit LCD display
- Battery operated for portability
- Superbrite blue backlight for clear visibility
- Crescendo alarm with increasing volume
- Snooze function
- Elegant design
- AM/PM indicator

## **PRODUCT OVERVIEW**

---

Familiarize yourself with the alarm clock's components before operation.



**Image 2:** Top view of the Acctim Auric 12342 alarm clock, illustrating the control buttons and approximate dimensions. The large button at the top is for SNOOZE/LIGHT. Below it are the MIN and HR buttons for setting time and alarm. A slider switch is visible for selecting Time Set (T.SET), Alarm Set (AL.SET), Alarm On (AL.ON), and Alarm Off (AL.OFF) functions.

1. **SNOOZE/LIGHT Button:** Activates the backlight and snooze function.
2. **HR Button:** Adjusts the hour for time and alarm settings.
3. **MIN Button:** Adjusts the minute for time and alarm settings.
4. **Function Slider Switch:**
  - **T.SET:** Time Setting mode.
  - **AL.SET:** Alarm Setting mode.
  - **AL.ON:** Alarm On.
  - **AL.OFF:** Alarm Off.
5. **LCD Display:** Shows time, AM/PM indicator, and alarm status.

## SETUP

### 1. Battery Installation

1. Locate the battery compartment cover on the back of the alarm clock.
2. Remove the cover by sliding or lifting it.
3. Insert 2 new AA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover securely.

The clock will power on automatically once batteries are inserted. The display may flash, indicating it's ready for time setting.

## OPERATING INSTRUCTIONS

### 1. Setting the Time

1. Slide the Function Switch to the **T.SET** position. The time digits will start flashing.
2. Press the **HR** button repeatedly to set the hour. Observe the AM/PM indicator for correct 12-hour format.
3. Press the **MIN** button repeatedly to set the minutes.
4. Once the desired time is set, slide the Function Switch back to the **AL.OFF** or **AL.ON** position to save the time.

## 2. Setting the Alarm

1. Slide the Function Switch to the **AL.SET** position. The alarm time digits will start flashing.
2. Press the **HR** button repeatedly to set the alarm hour. Observe the AM/PM indicator.
3. Press the **MIN** button repeatedly to set the alarm minutes.
4. Once the desired alarm time is set, slide the Function Switch back to the **AL.ON** position to activate the alarm, or **AL.OFF** to deactivate it.

## 3. Activating/Deactivating the Alarm

- To activate the alarm, slide the Function Switch to the **AL.ON** position. An alarm icon will appear on the display.
- To deactivate the alarm, slide the Function Switch to the **AL.OFF** position. The alarm icon will disappear.

## 4. Using the Snooze and Backlight Function

- When the alarm sounds, press the large **SNOOZE/LIGHT** button on top of the clock to temporarily stop the alarm. The alarm will sound again after approximately 4-5 minutes.
- To activate the blue backlight at any time, press the large **SNOOZE/LIGHT** button. The backlight will illuminate for a few seconds.

## MAINTENANCE

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** When the display dims or the alarm function becomes unreliable, replace both AA batteries with new ones. Follow the battery installation steps in the Setup section.
- **Storage:** If the clock will not be used for an extended period, remove the batteries to prevent leakage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is blank or dim.	Batteries are low or incorrectly installed.	Replace with new AA batteries, ensuring correct polarity.
Alarm does not sound.	Alarm is not activated (AL.OFF). Alarm time is incorrectly set.	Slide the Function Switch to <b>AL.ON</b> . Check and reset the alarm time.
Time or alarm cannot be set.	Function Switch is not in the correct position.	Ensure the Function Switch is set to <b>T.SET</b> for time or <b>AL.SET</b> for alarm.

Problem	Possible Cause	Solution
Backlight does not work.	Batteries are low.	Replace with new AA batteries.

## SPECIFICATIONS

---

- **Brand:** Acctim
- **Model Number:** 12342
- **Color:** White
- **Material:** Plastic
- **Display Type:** Digital LCD
- **Power Source:** Battery powered (2 x AA batteries, not included)
- **Product Dimensions (L x W x H):** 5.21 x 3.81 x 10.49 cm (approximately 2.05 x 1.5 x 4.13 inches)
- **Item Weight:** 102 grams (approximately 0.22 lbs)
- **Special Features:** Alarm, Snooze, Superbrite Blue Backlight, Crescendo Alarm
- **Indoor/Outdoor Use:** Indoor

## WARRANTY AND SUPPORT

---

The Acctim Auric 12342 Digital Alarm Clock comes with **one-year warranty** from the date of purchase, covering manufacturing defects. For warranty claims, technical support, or any inquiries, please contact Acctim customer service through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty purposes.