

[manuals.plus](#) /› [KRUPS](#) /› [KRUPS Dolce Gusto KP1006 Piccolo Single-Serve Beverage Machine User Manual](#)

KRUPS KP1006

KRUPS Dolce Gusto KP1006 Piccolo Single-Serve Beverage Machine User Manual

Model: KP1006

1. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.

2. PRODUCT OVERVIEW

The KRUPS Dolce Gusto KP1006 Piccolo is a compact single-serve beverage machine designed for quick and easy preparation of various hot and cold drinks using specialized capsules. Its sleek design fits well in any kitchen space.



Image: Front view of the KRUPS Dolce Gusto KP1006 Piccolo Single-Serve Beverage Machine in red, showcasing its compact size and modern design.

Key Features:

- **Compact Design:** Space-saving footprint for any kitchen counter.
- **Capsule System:** Uses easy-to-use, mess-free capsules for a variety of beverages.
- **Hot and Cold Beverages:** Capable of preparing both hot and cold drinks.
- **Fast Heating:** 1500 watts of power for rapid heating in under a minute.
- **High Pressure System:** 15-bar Thermoblock pump pressure for optimal flavor extraction and frothy crema.
- **Removable Water Tank:** 21-ounce capacity for convenient refilling.
- **Adjustable Drip Tray:** Accommodates various cup and glass sizes.
- **Auto Shut-off:** Energy-saving feature for automatic power off.

3. SETUP

Before first use, ensure all packaging materials are removed and the machine is placed on a stable, flat surface.

Initial Preparation:

1. **Clean Components:** Wash the removable water tank and drip tray with warm, soapy water. Rinse thoroughly and dry.
2. **Fill Water Tank:** Fill the 21-ounce removable water tank with fresh, clean water. Place it back onto the machine securely.
3. **Power Connection:** Plug the machine into a suitable electrical outlet.
4. **First Rinse Cycle:** Before making your first beverage, perform a rinse cycle without a capsule. Insert the capsule holder, secure the locking handle, and slide the selection lever to hot. Allow water to run through

the machine into a cup. Repeat for the cold setting. This primes the system and cleans any manufacturing residue.

4. OPERATING INSTRUCTIONS

The KRUPS Dolce Gusto KP1006 Piccolo is designed for simple, single-serve beverage preparation.

Making a Beverage:

- Fill Water Tank:** Ensure the 21-ounce water tank is filled with fresh water.
- Power On:** Press the 'on' button. The machine will heat up, indicated by a light. It heats in less than a minute.
- Insert Capsule:** Open the locking handle and pull out the magnetic capsule holder. Insert your desired Dolce Gusto capsule into the holder.
- Secure Capsule:** Push the capsule holder back into the machine and firmly close the locking handle.
- Position Cup:** Place your cup or glass on the adjustable drip tray. Adjust the drip tray height if necessary to minimize splashing.
- Select Temperature and Volume:** Use the custom control lever to select either hot or cold water. For multi-capsule drinks, follow the capsule instructions for strength and mixture.
- Brew:** The machine will dispense the beverage into your cup. Monitor the volume and return the lever to the neutral position once the desired amount is reached.
- Remove Capsule:** Once brewing is complete, open the locking handle, remove the used capsule, and discard it. Rinse the capsule holder if needed.
- Auto Shut-off:** The machine features an energy-saving auto shut-off function after a period of inactivity.

5. MAINTENANCE

Regular cleaning and maintenance ensure optimal performance and longevity of your beverage machine.

Cleaning:

- Daily Cleaning:** After each use, remove and rinse the capsule holder. Empty and rinse the drip tray. Wipe the exterior of the machine with a damp cloth.
- Water Tank:** Clean the removable water tank regularly with warm, soapy water. Rinse thoroughly.
- Dishwasher-Safe Parts:** The drip tray and capsule holder are dishwasher-safe for convenient cleaning.

Descaling:

Over time, mineral deposits can build up in the machine, affecting performance. Descaling your machine periodically, depending on water hardness and frequency of use. Refer to the official KRUPS Dolce Gusto descaling instructions or use a compatible descaling solution following its specific directions.

6. TROUBLESHOOTING

If you encounter issues with your KRUPS Dolce Gusto KP1006 Piccolo, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outlet issue.	Ensure the power cord is securely plugged into a working outlet.
No water flow or slow flow.	Water tank empty; air bubble in system; machine needs descaling.	Refill water tank. Perform a rinse cycle to clear air. Descale the machine.
Beverage is not hot enough.	Machine not fully heated; descaling needed.	Wait for the machine's indicator light to show it's ready. Descale the machine.
Leaking from machine.	Water tank not properly seated; capsule not correctly inserted.	Ensure water tank is firmly in place. Check capsule insertion and locking handle.

7. SPECIFICATIONS

Feature	Detail
Brand	KRUPS
Model Number	KP1006
Product Dimensions	8.66 x 6.26 x 11.3 inches
Item Weight	7.75 pounds
Water Tank Capacity	21 ounces (approx. 0.62 liters)
Power	1500 watts
Pump Pressure	15 bar Thermoblock system
Operation Mode	Fully Automatic
Special Feature	Removable Tank, Hot/Cold Selection, Auto Shut-off
Dishwasher Safe Parts	Yes (Drip Tray, Capsule Holder)

8. WARRANTY AND SUPPORT

Warranty Information:

This KRUPS Dolce Gusto KP1006 Piccolo beverage machine carries a **one-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use. Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, warranty service, or to inquire about replacement parts, please contact KRUPS customer support. Refer to the official KRUPS website or the documentation included with your product for the most current contact information.

When contacting support, please have your model number (KP1006) and date of purchase available.

© 2023 KRUPS. All rights reserved.