

[Manuals.plus](#) /

> [Inter Link](#) /

> Inter Link Rick Bunk Bed for Children - Solid Pine Wood, White Lacquer, 90x190 cm Instruction Manual

Inter Link Rick (Model 20900260)

Inter Link Rick Bunk Bed Instruction Manual

MODEL: RICK (20900260)

1. Introduction

Thank you for choosing the Inter Link Rick Bunk Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new bunk bed. Please read these instructions carefully before beginning assembly and retain them for future reference. Proper assembly and adherence to safety guidelines are crucial for the longevity and safe use of the product.

2. Safety Information

Your safety and the safety of your children are paramount. Please observe the following safety warnings:

- **Important:** The upper bunk is not suitable for children under 6 years of age.
- **Strangulation Hazard:** Keep cords, ropes, belts, harnesses, or similar items away from the bed to prevent entanglement and strangulation.
- Ensure all assembly hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- Do not allow children to play on or under the bunk bed without supervision.
- Use only mattresses of the specified size to ensure proper fit and safety rail effectiveness.
- Always use the ladder for accessing the upper bunk. Do not jump on or off the bed.
- Do not attach or suspend items from any part of the bunk bed that are not designed for use with the bed.

3. Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact your retailer for assistance.

- Bunk Bed Frame (Solid Pine Wood, White Lacquer)
- 2 x Slatted Bed Bases

- Ladder
- Assembly Hardware (screws, bolts, dowels, etc.)
- Instruction Manual

4. Setup and Assembly Instructions

Assembly typically requires two adults. Please follow the steps below carefully. Do not use power tools for tightening screws, as this may damage the wood.

1. **Preparation:** Clear a spacious area for assembly. Lay out all components and hardware. Keep small parts out of reach of children.
2. **Assemble Bed Ends:** Attach the side rails to the headboards and footboards for both the upper and lower beds. Ensure all connections are secure.
3. **Attach Slatted Bases:** Insert the slatted bed bases into the designated slots or attach them to the support rails for both bed frames.
4. **Connect Upper and Lower Beds:** Carefully lift the upper bed frame and align it with the lower bed frame, securing them with the provided connectors. This step requires two people.
5. **Install Ladder:** Attach the ladder securely to the upper bunk as indicated in the diagrams.
6. **Final Checks:** Ensure all screws and bolts are tightened. The bed should be stable and not wobble.

Conversion to Two Single Beds: This bunk bed is designed to be convertible into two separate single beds. To do this, carefully detach the upper bed from the lower bed by reversing the connection steps. Then, attach the appropriate leg extensions or caps (if provided) to convert them into standalone single beds.



Figure 1: Overview of bunk bed components and structure.



Figure 2: Detail of the secure screw connections for the bed frame.



Figure 3: Illustration of the slatted bed base fitting into the frame.



Figure 4: View of the robust corner joint and hardware.

5. Operating Instructions (Usage)

The Inter Link Rick Bunk Bed is designed for sleeping and resting. Adhere to the following guidelines for safe use:

- **Weight Capacity:** Ensure that the weight on each bunk does not exceed the recommended limit (typically around 100 kg per bunk, though specific limits should be confirmed with manufacturer if available).
- **Ladder Use:** Always use the ladder to access the upper bunk. Face the ladder when climbing up or down.
- **Safety Barrier:** The integrated safety barrier on the upper bunk is crucial for preventing falls. Ensure it is always in place and undamaged.
- **Mattress Placement:** Place mattresses securely on the slatted bases. The top surface of the mattress on the upper bunk must be at least 16 cm below the top edge of the safety barrier.



Figure 5: The Inter Link Rick Bunk Bed in a typical room setup.



Figure 6: The bunk bed ready for use, showing the ladder and safety rail.



Figure 7: The bunk bed disassembled and configured as two separate single beds.

6. Maintenance

Regular maintenance will help preserve the condition and safety of your bunk bed.

- **Cleaning:** The product is water-resistant and easy to clean. Wipe surfaces with a damp cloth and then dry with a clean, dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Hardware Check:** Periodically inspect all screws, bolts, and connections. Re-tighten any loose hardware to ensure structural integrity.
- **Structural Integrity:** Check the wooden frame for any signs of damage, cracks, or splinters. Address any issues promptly to prevent further damage or injury.

7. Troubleshooting

If you encounter any issues with your bunk bed, refer to the following common problems and solutions:

- **Wobbling or Instability:** This is usually caused by loose hardware. Re-check and tighten all screws and bolts, especially those connecting the main frame components. Ensure the bed is on a level surface.
- **Squeaking Noises:** Squeaking can result from loose connections or friction between wood parts. Tighten all hardware. If squeaking persists, a small amount of furniture wax or silicone spray on contact points (avoiding areas that bear weight) might help.
- **Ladder Feels Loose:** Ensure the ladder's attachment points to the upper bunk are securely fastened. Check for any damage to the ladder rungs or side rails.
- **Difficulty Converting to Single Beds:** Ensure all connecting hardware between the upper and lower bunks has been completely removed. Refer to the assembly instructions for the correct detachment procedure.

If problems persist after attempting these solutions, please contact the manufacturer or your retailer for further assistance.

8. Specifications

Feature	Detail
Brand	Inter Link
Model Name	Rick
Model Number	20900260
Material	Solid Pine Wood
Color	White Lacquer
Product Dimensions (L x W x H)	200 x 102 x 148 cm
Mattress Size (each bunk)	90 x 190 cm (mattresses not included)
Item Weight	48 Kilograms
Special Feature	Convertible to two single beds

9. Warranty and Support

Information regarding specific warranty terms for the Inter Link Rick Bunk Bed is not provided in this manual. For warranty details, please refer to the documentation included with your purchase or contact your retailer or the manufacturer directly.

For technical support, missing parts, or further inquiries, please contact the Inter Link customer service or your point of purchase.

© 2023 Inter Link. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0042RYFQW>

More documents and user manuals: <https://manuals.plus/>