Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jeep Liberty

2004 Jeep Liberty Owner's Manual

Your comprehensive guide to operating and maintaining your vehicle.

Introduction

Welcome to the world of Jeep Liberty. This manual contains important information regarding the operation, maintenance, and safety of your 2004 Jeep Liberty. Please read it thoroughly to ensure a full understanding of your vehicle's features and capabilities. Keep this manual in your vehicle for quick reference.



Figure 1: Front cover of the 2004 Jeep Liberty Owner's Manual. This image displays the official manual for the vehicle, featuring the Jeep logo and model year.

Safety Information

Your safety and the safety of your passengers are paramount. This section outlines critical safety precautions, including information on airbags, seat belts, child restraints, and general driving safety tips. Always adhere to local traffic laws and exercise caution while operating your vehicle.

- Always wear your seat belt and ensure all passengers are properly restrained.
- Never place a rear-facing child seat in the front passenger seat if equipped with an active front airbag.
- Familiarize yourself with the location and function of all safety features.

Controls and Features

This section provides a detailed overview of your Jeep Liberty's interior and exterior controls and features. Understanding

these will enhance your driving experience and ensure proper use of all vehicle functions.

Dashboard Layout

Learn about the instrument cluster, warning lights, gauges, and the various switches and buttons located on your dashboard.

Interior Features

- Climate Control System: Operation of heating, ventilation, and air conditioning.
- Audio System: Radio, CD player, and speaker controls.
- Power Windows and Locks: How to operate the electric windows and central locking system.

Exterior Features

- Lighting: Headlights, fog lights, turn signals, and hazard lights.
- Wipers and Washers: Front and rear windshield wiper operation.
- Fuel Filler Cap: Location and proper opening procedure.

Starting and Operating

This section covers the procedures for starting your vehicle and provides guidance on various driving conditions and operational aspects.

Starting the Engine

1. Ensure the parking brake is engaged.
2. Place the transmission in PARK (P) for automatic or NEUTRAL (N) for manual.
3. Insert the key into the ignition and turn to the START position. Release the key once the engine starts.

Driving Tips

- **Automatic Transmission:** Understand the gear selector positions (P, R, N, D, 2, 1).
- **Four-Wheel Drive (4WD):** Instructions for engaging and disengaging 4WD modes (2WD, 4WD Part-Time, 4WD Full-Time, 4WD Low) if applicable.
- **Braking System:** Information on ABS (Anti-lock Braking System) and proper braking techniques.

Maintenance and Service

Regular maintenance is crucial for the longevity and performance of your Jeep Liberty. This section details recommended service schedules and basic checks you can perform.

Scheduled Maintenance

Refer to the separate Maintenance Schedule booklet (if provided) for detailed service intervals based on mileage and time. Adhering to this schedule helps maintain your vehicle's warranty and ensures optimal operation.

Owner Checks

- **Engine Oil:** Check level regularly and top up as needed.
- **Coolant:** Ensure coolant level is between MIN and MAX marks when the engine is cold.
- **Brake Fluid:** Verify fluid level is within recommended range.
- **Tire Pressure:** Check tire pressure monthly, including the spare, and adjust to specifications found on the tire

placard.

- **Wiper Blades:** Inspect for wear and replace if necessary.

Troubleshooting

This section provides guidance on identifying and resolving common issues you might encounter with your Jeep Liberty. For more complex problems, consult an authorized service center.

Problem	Possible Cause	Solution
Engine will not start	Dead battery, faulty starter, no fuel	Check battery terminals, jump-start, check fuel level, consult service.
Warning light illuminated	Low fluid, system malfunction	Refer to specific warning light section in manual, check fluid levels, seek professional diagnosis.
Tire pressure low	Puncture, temperature change	Inflate to correct pressure, inspect for damage, repair or replace tire.

Specifications

Key technical specifications for the 2004 Jeep Liberty. These values are approximate and may vary based on trim level and optional equipment.

Feature	Specification
Engine Options	2.4L I4, 3.7L V6
Fuel Tank Capacity	Approx. 19.5 gallons (73.8 liters)
Overall Length	Approx. 174.4 inches (4430 mm)
Wheelbase	Approx. 104.3 inches (2649 mm)
Curb Weight	Approx. 3,600 - 4,000 lbs (1633 - 1814 kg)

Warranty Information

Your 2004 Jeep Liberty is covered by a comprehensive warranty. Details regarding coverage periods, terms, and conditions for the Basic Limited Warranty, Powertrain Limited Warranty, and Corrosion Perforation Limited Warranty are provided in a separate Warranty Information Booklet. Please review this document thoroughly to understand your rights and responsibilities. This manual also includes information related to the **Lemon Law Guide**, outlining consumer protection laws regarding defective vehicles.

Customer Assistance

Should you require further assistance, have questions not covered in this manual, or need to locate an authorized service center, please contact Jeep Customer Service. Contact information can typically be found in the Warranty Information Booklet or on the official Jeep website.
For general inquiries, you may visit the officialJeep website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00435E1QW

More documents and user manuals: **https://manuals.plus/**