

Manuals.plus /

- › Westminster Teak /
- › Westminster Teak Vogue 5 Ft Bench Instruction Manual

Westminster Teak 23200

Westminster Teak Vogue 5 Ft Bench Instruction Manual

1. INTRODUCTION

Thank you for choosing the Westminster Teak Vogue 5 Ft Bench. This manual provides essential information for the safe assembly, proper use, and effective maintenance of your new bench. Please read these instructions carefully before assembly and retain them for future reference.



Image 1.1: The Westminster Teak Vogue 5 Ft Bench, showcasing its contemporary design with teak slats and stainless steel frame, situated in a lush garden environment.

The Vogue 5 ft. bench combines Grade A Teak with premium stainless steel, offering a durable and stylish seating solution for both indoor and outdoor environments. Its design is intended to complement various settings, from home gardens to dining areas.

2. SAFETY INFORMATION

Always prioritize safety during assembly and use. Failure to follow these safety guidelines may result in injury or damage to the product.

- **Weight Capacity:** Do not exceed the maximum recommended weight of **500 pounds (approximately 227 kg)**. Overloading can cause structural failure and injury.
- **Stable Surface:** Always place the bench on a flat, stable, and level surface to prevent tipping.
- **Children:** Keep children away from the assembly area. Small parts can be a choking hazard. Supervise children when they are near or using the bench.
- **Assembly:** Ensure all bolts and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- **Moving the Bench:** When moving the bench, lift it rather than dragging it to prevent damage to the legs or the surface it rests on.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact Westminster Teak customer support.

- Bench Seat and Backrest Assembly (Teak)
- Left Arm/Leg Frame (Stainless Steel)
- Right Arm/Leg Frame (Stainless Steel)
- Hardware Pack (Bolts, Washers, Allen Wrench)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended that two adults perform the assembly to ensure safety and ease.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Attach Side Frames:** Align one stainless steel arm/leg frame with the pre-drilled holes on one side of the teak seat and backrest assembly. Insert the provided bolts with washers and hand-tighten them.
3. **Attach Second Side Frame:** Repeat the process for the other stainless steel arm/leg frame on the opposite side of the teak assembly.
4. **Final Tightening:** Once all bolts are in place and hand-tightened, use the included Allen wrench to fully tighten all bolts. Ensure they are snug but do not overtighten, as this can damage the material.
5. **Check Stability:** Gently rock the bench to ensure it is stable and all connections are secure. If any wobbling occurs, re-check the tightness of all bolts.



Image 4.1: Front view of the assembled Westminster Teak Vogue 5 Ft Bench, illustrating the clean lines and material combination.

5. OPERATION AND USAGE

The Westminster Teak Vogue 5 Ft Bench is designed for comfortable seating in various settings.

- **Intended Use:** This bench is designed for seating purposes only. Do not stand on the bench or use it as a step stool.
- **Placement:** The bench is suitable for both indoor and outdoor use. Its plastic glides protect surfaces.
- **Environmental Exposure:** While teak is highly durable and weather-resistant, prolonged exposure to extreme weather conditions (e.g., heavy snow, intense sun without cover) may affect its appearance over time.

6. MAINTENANCE

Proper care will ensure the longevity and beauty of your Westminster Teak Vogue 5 Ft Bench.

- **Cleaning:** Wipe the bench with a dry cloth regularly to remove dust and dirt. For deeper cleaning, use a soft cloth dampened with mild soap and water, then rinse thoroughly and dry. Avoid harsh chemicals or abrasive cleaners.
- **Teak Wood:** Over time, teak wood will naturally weather to a soft, silvery-gray patina. This is a natural process and does not affect the structural integrity of the wood. If you prefer to maintain the original golden-brown color, specialized teak sealers or oils can be applied, following the product manufacturer's instructions.
- **Stainless Steel:** Clean stainless steel components with a soft cloth and a stainless steel cleaner to remove smudges or fingerprints. Avoid abrasive materials that can scratch the finish.
- **Winter Storage:** In regions with harsh winters, consider storing the bench indoors or covering it with a breathable furniture cover to protect it from extreme elements.

7. TROUBLESHOOTING

If you encounter any issues with your bench, refer to the following common solutions:

- **Wobbling Bench:** Ensure the bench is on a level surface. Check all assembly bolts and re-tighten them if loose.
- **Discoloration of Teak:** Natural weathering to a silvery-gray is normal for teak. This is not a defect. Refer to the maintenance section for options to restore the original color.
- **Scratches on Stainless Steel:** Minor scratches can sometimes be buffed out with a fine-grit abrasive pad

designed for stainless steel, always rubbing in the direction of the grain. For deeper scratches, professional repair may be needed.

If problems persist, please contact Westminster Teak customer support.

8. SPECIFICATIONS

Product Model	Vogue 5 Ft Bench (Model 23200)
Dimensions (L x W x H)	65 inches x 23.5 inches x 35.5 inches (165.1 cm x 59.7 cm x 90.2 cm)
Seat Height	16.5 inches (41.9 cm)
Item Weight	62 pounds (28.1 kg)
Material	Grade A Teak, Premium Stainless Steel
Maximum Weight Recommendation	500 pounds (227 kg)
Assembly Required	Yes
Product Care	Wipe with Dry Cloth



Image 8.1: A diagram illustrating the key dimensions of the Westminster Teak Vogue 5 Ft Bench, including length, width, and height.

9. WARRANTY AND SUPPORT

Westminster Teak stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Westminster Teak website.

For customer support, missing parts, or any inquiries, please contact Westminster Teak directly through their official channels. Have your model number (23200) and purchase information ready when contacting support.