

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Casio](#) /
- > [Casio Watch Strap Band Instruction Manual](#)

Casio 70622792

Casio Watch Strap Band Instruction Manual

Models: AD-300, AQ-61, DW-280, DW-290, DW-290G, DW-290MV

INTRODUCTION

This manual provides essential information for the installation, use, and maintenance of your new Casio replacement watch strap band. This genuine Casio strap is designed to fit various Casio watch models, including AD-300, AQ-61, DW-280, DW-290, DW-290G, and DW-290MV, ensuring a perfect fit and restoring the functionality and appearance of your timepiece.

PRODUCT OVERVIEW



Figure 1: Casio Watch Strap Band Components

This image displays the two parts of the Casio replacement watch strap band. The upper part features the black plastic buckle and a keeper loop. The lower part is the longer strap with multiple adjustment holes, designed for securing the watch on the wrist.

The Casio watch strap band is constructed from durable resin material, designed for longevity and comfort. It features a robust tang buckle made of stainless steel, ensuring secure fastening. The band is designed for easy replacement using standard watch spring bars (not included, typically reused from the original band or purchased separately).

SETUP AND INSTALLATION

Proper installation is crucial for the secure fit and longevity of your watch band. It is recommended to use a spring bar tool for this process to prevent damage to your watch or the new band.

- 1. Preparation:** Lay your watch face down on a soft, clean surface to prevent scratches. Ensure you have a spring bar tool and the new watch strap.
- 2. Remove Old Band:**
 - Locate the spring bar at one end of the existing watch band where it connects to the watch lug.
 - Using the forked end of the spring bar tool, gently push in the flange of the spring bar.
 - While holding the spring bar compressed, carefully pull the band away from the watch lug until the spring bar detaches.
 - Repeat for the other side of the same band piece, then for the second band piece.
 - Keep the old spring bars if they are in good condition, as they are often reused with the new band.
- 3. Install New Band:**
 - Insert one end of a spring bar into one of the holes on the watch lug.
 - Align the new watch band piece with the watch lug.
 - Using the spring bar tool, compress the other end of the spring bar and guide it into the corresponding hole on the opposite watch lug.
 - Gently wiggle the band to ensure the spring bar is securely seated in both lug holes. A slight click may be heard.
 - Repeat this process for the second piece of the watch band.
- 4. Final Check:** Once both pieces are installed, gently pull on each side of the band to confirm it is securely attached to the watch.

OPERATING (USAGE)

To wear your watch with the new strap:

1. Place the watch on your wrist.
2. Thread the longer strap through the buckle.
3. Insert the buckle pin into the appropriate hole on the strap for a comfortable and secure fit. The fit should be snug enough to prevent the watch from sliding freely, but not so tight as to restrict circulation.
4. Secure the excess strap length through the keeper loop(s) to prevent it from flapping.

MAINTENANCE

To ensure the longevity and appearance of your Casio watch strap band, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the band with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used. Rinse thoroughly with clean water and dry completely before wearing. Avoid harsh chemicals or abrasive cleaners.
- **Avoid Extreme Conditions:** While the resin material is durable, prolonged exposure to direct sunlight, extreme temperatures, or strong chemicals (e.g., solvents, gasoline) can cause degradation or discoloration.
- **Storage:** When not in use, store the watch in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically inspect the band for any signs of wear, cracks, or damage, especially around the spring bar attachment points and buckle.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Band does not fit watch lugs.	Incorrect band size or incompatible model.	Verify your watch model number against the compatible models listed (AD-300, AQ-61, DW-280, DW-290, DW-290G, DW-290MV). Ensure you are using the correct spring bars.
Difficulty installing spring bars.	Spring bar not fully compressed or misaligned.	Ensure the spring bar tool is properly engaging the spring bar flange. Angle the band correctly to align the spring bar with the lug holes. Apply gentle, consistent pressure.
Band feels uncomfortable or causes irritation.	Band is too tight or too loose; skin sensitivity.	Adjust the buckle to a different hole for a more comfortable fit. Ensure the band is not excessively tight. If irritation persists, clean the band thoroughly or consult a dermatologist if you suspect a material allergy.

SPECIFICATIONS

- **Product Model Number:** 70622792
- **Compatible Casio Models:** AD-300, AQ-61, DW-280, DW-290, DW-290G, DW-290MV
- **Material:** Resin (Band), Stainless Steel (Buckle)
- **Clasp Type:** Tang Buckle
- **Product Dimensions:** 7.68 x 1.97 x 0.59 inches (approximate, as per product listing)
- **Item Weight:** 0.63 ounces (approximate, as per product listing)

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support for your Casio watch strap band, please refer to the official Casio website or contact Casio customer service directly. Keep your purchase receipt as proof of purchase. For additional resources, you may visit the [Casio Store on Amazon](#).

