Westclox LCD Digital Bedside Alarm Clock (B0044FV5G0)

Westclox LCD Digital Bedside Alarm Clock

User Instruction Manual

Introduction

Thank you for purchasing the Westclox LCD Digital Bedside Alarm Clock. This compact and stylish alarm clock is designed for convenience and reliability, featuring a clear blue backlit display, a simple alarm function with snooze, and battery-powered flexibility for placement anywhere in your home. Please read this manual carefully to ensure proper operation and to get the most out of your new clock.



Figure 1: Front view of the Westclox LCD Digital Bedside Alarm Clock.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Open the battery compartment cover.
3. Insert **two (2) AAA batteries** (not included) according to the polarity indicators (+ and -) inside the compartment.
4. Close the battery compartment cover securely.

Note: Always use fresh batteries. Remove batteries if the clock will not be used for an extended period to prevent leakage.

2. Initial Time Setting

1. Locate the control switches on the top of the clock. You will see "HOUR", "MINUTE" buttons and a "SET / TIME RUN ALARM" slide switch.
2. Slide the "SET / TIME RUN ALARM" switch to the**SET** position. The time display will begin to flash.

3. Press the **HOUR** button repeatedly to set the current hour. Pay attention to the PM indicator (if present on your model) for correct AM/PM setting.
4. Press the **MINUTE** button repeatedly to set the current minute.
5. Once the correct time is set, slide the "SET / TIME RUN ALARM" switch back to the **TIME** position to save the time and resume normal operation.



Figure 2: Control buttons and switches for setting time and alarm.

Operating Instructions

1. Setting the Alarm Time

1. Slide the "SET / TIME RUN ALARM" switch to the **ALARM** position. The alarm time will be displayed and may flash.
2. Press the **HOUR** button repeatedly to set the desired alarm hour.
3. Press the **MINUTE** button repeatedly to set the desired alarm minute.
4. Once the alarm time is set, slide the "SET / TIME RUN ALARM" switch back to the **TIME** position. The alarm icon (often a bell or "AL") will appear on the display, indicating the alarm is set.

2. Turning the Alarm On/Off

- To turn the alarm **ON**: Locate the "ALARM ON / OFF" slide switch on the top right of the clock. Slide it to the **ON** position. The alarm icon will be visible on the display.
- To turn the alarm **OFF**: Slide the "ALARM ON / OFF" switch to the **OFF** position. The alarm icon will disappear from the display.

3. Snooze / Light Function

- When the alarm sounds, press the large **SNOOZE / LIGHT** button located on the front of the clock. The alarm will temporarily stop and sound again after approximately 4 minutes.
- To activate the blue backlight for 5 seconds, press the **SNOOZE / LIGHT** button at any time when the alarm is not sounding. This is useful for checking the time in the dark.



Figure 3: Clear blue backlit LCD display for easy reading.

Maintenance

Cleaning

To clean your clock, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the finish or internal components. Avoid getting moisture into the clock's openings.

Battery Replacement

When the display becomes dim or the alarm function weakens, it is time to replace the batteries. Follow the "Battery Installation" steps in the Setup section to replace the two AAA batteries. Dispose of old batteries responsibly according to local regulations.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Display is blank or dim.	Batteries are dead or inserted incorrectly.	Check battery polarity. Replace with fresh AAA batteries.
Alarm does not sound.	Alarm is not set or "ALARM ON/OFF" switch is in OFF position.	Ensure alarm time is set and the "ALARM ON/OFF" switch is in the ON position. Check batteries.
Time is incorrect.	Time was not set correctly or batteries were removed.	Re-set the time following the "Initial Time Setting" instructions.
Backlight not working.	Batteries are low or dead.	Replace batteries.

Specifications

Feature	Detail
Brand	Westclox
Model	LCD Digital Bedside Alarm Clock (B0044FV5G0)
Color	Black
Display Type	Digital, LCD with Blue Backlight
Special Features	Alarm, Snooze, Backlight
Product Dimensions	3.8"W x 3.6"H
Power Source	2 x AAA Batteries (not included)
Room Type	Bedroom

Warranty and Support

For warranty information or technical support regarding your Westclox LCD Digital Bedside Alarm Clock, please refer to the product packaging or contact the retailer where the product was purchased. You may also visit the official Westclox brand store for additional information and contact details:

Visit the Westclox Store on Amazon

Please have your product model number (B0044FV5G0) and purchase details ready when contacting support.

© 2023 Westclox. All rights reserved.