

manuals.plus /

- › [LEGO](#) /
- › [LEGO Star Wars Obi-Wan's Jedi Starfighter \(10215\) Instruction Manual](#)

LEGO 10215

LEGO Star Wars Obi-Wan's Jedi Starfighter (10215) Instruction Manual

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and care of your LEGO Star Wars Obi-Wan's Jedi Starfighter (Set 10215). This collector-series model allows you to construct a detailed replica of Obi-Wan Kenobi's Delta-7 Aethersprite-class Jedi starfighter, as seen in *Star Wars: The Clone Wars*. The set is designed for enthusiasts aged 14 and up, offering an engaging building experience and a display-worthy finished product.

The model features twin laser cannons, a detailed cockpit interior, and a rotating R4-P17 astromech droid dome. Once assembled, it measures approximately 9 inches (23 cm) high on its stand, 18 inches (47 cm) long, and 9 inches (22 cm) wide. Please read all instructions carefully before beginning assembly.



Image: The fully assembled LEGO Obi-Wan's Jedi Starfighter (10215) model, showcasing its detailed design and display stand.

ASSEMBLY INSTRUCTIONS

The LEGO Star Wars Obi-Wan's Jedi Starfighter (10215) set contains 676 pieces. Follow the step-by-step visual instructions provided in the physical instruction booklet included with your set. Ensure you have a clean, well-lit workspace to prevent loss of small parts.

Preparation:

- Unpack all bags and sort pieces by color and type. This will significantly speed up the building process.
- Verify all numbered bags are present according to the instruction booklet's checklist.

Building Process:

1. Begin with Bag 1 and follow the corresponding steps in the instruction booklet.
2. Carefully connect bricks as shown, ensuring a firm connection for structural integrity.
3. Pay close attention to the orientation of specialized pieces and stickers (if applicable).
4. Proceed through each numbered bag sequentially until all sections are complete.
5. Assemble the display stand as per the instructions to securely hold the finished model.



Image: The product box for LEGO Star Wars Obi-Wan's Jedi Starfighter (10215), indicating the set number and age recommendation.

OPERATING FEATURES

Once assembled, your Obi-Wan's Jedi Starfighter model offers several interactive elements for display and appreciation.

Cockpit:

The canopy of the cockpit can be opened to reveal a detailed interior, designed to accommodate a LEGO minifigure (not included in this set). This allows for dynamic display options.




Image: A detailed view of the Jedi Starfighter's cockpit with the canopy open, showing the interior controls.

R4-P17 Astromech Droid Dome:

The dome representing Obi-Wan's astromech droid, R4-P17, is mounted on the wing and can be rotated. This adds an authentic detail to the model.



Image: A close-up of the R4-P17 astromech droid dome, featuring intricate detailing on its surface.

Display Stand and Plaque:

The included display stand is designed to securely hold the starfighter in an elevated position, making it ideal for showcasing. A decorative plaque with key information about the Delta-7 Aethersprite-class Light Interceptor is also provided to enhance the display.



Image: The black display stand and informational plaque, detailing specifications of the Delta-7 Aethersprite-class Light Interceptor.

MAINTENANCE

To keep your LEGO model in excellent condition, follow these simple maintenance guidelines:

- **Cleaning:** Dust your model regularly with a soft brush or a can of compressed air. For deeper cleaning, gently wash individual bricks with mild soap and lukewarm water (not hot water, as it can deform plastic). Rinse thoroughly and air dry. Do not use abrasive cleaners or harsh chemicals.
- **Storage:** Store the model away from direct sunlight and extreme temperatures to prevent discoloration and warping of plastic elements.
- **Handling:** Handle the model carefully, especially when moving it, to avoid accidental detachment of

parts.

TROUBLESHOOTING

If you encounter any issues during or after assembly, consider the following common solutions:

- **Missing Pieces:** If you find a piece is missing, first double-check all packaging and your workspace. Sometimes small pieces can be overlooked. If a piece is genuinely missing, contact LEGO Customer Service for replacement parts.
- **Assembly Errors:** If a section of your model does not look correct or is unstable, carefully retrace your steps in the instruction booklet. Disassemble the problematic section and reassemble it, paying close attention to piece orientation and connection points.
- **Loose Connections:** Ensure all LEGO bricks are firmly pressed together. Loose connections can lead to instability in the model.

SPECIFICATIONS

Product Dimensions	14.96 x 2.76 x 18.9 inches
Item Weight	2.87 pounds
Item Model Number	10215 (Set Number) / 4559647 (Internal)
Manufacturer Recommended Age	14 - 18 years
Release Date	February 1, 2011
Manufacturer	Lego

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. This product contains small parts and is not suitable for children under 3 years of age. Adult supervision is recommended during assembly, especially when younger individuals are present. Ensure all small pieces are kept out of reach of infants and toddlers.

WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. While specific warranty details for individual sets are not typically provided, LEGO offers excellent customer service for missing or defective parts. If you require assistance with your set, including replacement parts or assembly guidance, please visit the official LEGO customer service website or contact their support line.

For further support and to order replacement parts, please visit the official LEGO website:

www.lego.com/service